


Operator's Manual SLK-Class



Order No. 6515 3255 13 Part No. 171 584 76 81 USA Edition A 2006



Mercedes-Benz

SLK 280 SLK 350 SLK 55 AMG Our company and staff congratulate you on the purchase of your new Mercedes-Benz.

Your selection of our product is a demonstration of your trust in our company name. Furthermore, it exemplifies your desire to own an automobile that will be as easy as possible to operate and provide

years of service.

Your Mercedes-Benz represents the efforts of many skilled engineers and craftsmen. To help assure your driving pleasure, and also the safety of you and your passengers, we ask you to make a small investment of time:

- Please read this manual carefully, then return it to your vehicle where it will be handy for your reference.
- Please follow the recommendations contained in this manual. They are designed to acquaint you with the operation of your Mercedes-Benz.

 Please pay attention to the warnings and cautions contained in this manual.
 They are designed to help improve the safety of the vehicle operator and occupants.

We extend our best wishes for many miles of safe, pleasurable driving.

Mercedes-Benz USA, LLC A DaimlerChrysler Company

Introduction	9
Product information	9
Operator's Manual	10
Service and warranty information	10
Important notice for California	
retail buyers and lessees of	
Mercedes-Benz automobiles	11
Maintenance	12
Roadside Assistance	12
Change of address or ownership	12
Operating your vehicle outside	
the USA or Canada	13
Where to find it	14
Symbols	15
Operating safety	16
Proper use of the vehicle	16
Problems with your vehicle	17
Reporting safety defects	18
Reporting safety defects	18
Vehicle data recording	19
Information regarding electronic	
recording devices	19

At a glance	21
Cockpit	22
Instrument cluster	24
Multifunction steering wheel	26
Center console	28
Upper part	28
Lower part	29
Overhead control panel	30
Door control panel	31

Getting started	33
Unlocking	34
Unlocking with the SmartKey	34
Starter switch positions	36
Adjusting	38
Seats	38
Steering wheel	42
Mirrors	45
Driving	47
Fastening the seat belts	47
Starting the engine	50
Parking brake	52
Driving	53
Switching on headlamps	55
Turn signals	55
Windshield wipers	56
Problems while driving	58
Parking and locking	59
Parking brake	59
Switching off headlamps	60
Turning off engine	61
Locking	62

Contents

Safety and Security	63
Occupant safety	64
Air bags	65
Seat belts	71
Children in the vehicle	75
Panic alarm	80
Activating	81
Deactivating	81
Driving safety systems	82
ABS	82
BAS	83
ESP®	84
Anti-theft systems	87
Immobilizer	87
Anti-theft alarm system	87
Tow-away alarm	88

Controls in detail	91
Locking and unlocking	92
SmartKey	92
Opening the doors from the inside.	97
Opening the trunk	98
Closing the trunk	99
Trunk lid emergency release	100
Automatic central locking	101
Locking and unlocking from	
the inside	102
Seats	104
Seat heating*	104
AIRSCARF neck-level heating*	105
Memory function*	107
Storing positions into memory	108
Recalling positions from memory.	108
Storing exterior rear view mirror	
parking position (parking aid)	108
Lighting	110
Exterior lamp switch	110
Combination switch	114
Corner-illuminating front fog	
lamps* (SLK 280, SLK 350: with	
Bi-Xenon* headlamps and without	
	115

Hazard warning flasher	117
Interior lighting	117
Door entry lamps	119
nstrument cluster	120
Instrument cluster illumination	120
Tachometer	121
Outside temperature indicator	121
Trip odometer	122
Clock	122
Control system	123
Multifunction display	123
Multifunction steering wheel	124
Menus	126
Standard display menu	128
AUDIO menu	129
NAV* menu	132
Vehicle status message	
memory menu	132
Settings menu	134
Trip computer menu	149
TEL menu*	151
Manual transmission	155
Shifting into reverse	156
Automatic transmission*	157
Gear selector lever position	159
Gear ranges	160

Driving tips Automatic shift program		Automatic climate control* 190 Deactivating the climate	Power windows
Gear selector lever one-touch		control system194	windows24
gearshifting	164	Operating the climate control	Synchronizing power windows 25
Steering wheel gearshift control		system in automatic mode 194	Retractable hardtop
one-touch gearshifting	165	Setting the temperature 195	Opening and closing the
Manual shift program		Adjusting air distribution 196	retractable hardtop 25
SLK 55 AMG	169	Adjusting air volume 197	Wind screen 25
Emergency operation		Defrosting windshield 197	Driving systems
(Limp Home Mode)	172	Maximum cooling MAX COOL 199	Cruise control 26
Good visibility	173	Air recirculation mode 199	Loading 26
Headlamp cleaning system*	173	Air conditioning 200	Roof rack 26
Rear view mirrors	173	Residual heat and ventilation 202	Useful features
Sun visors	176	Audio system	Storage compartments 26
Rear window defroster	177	Audio and telephone*, operation 203	Shelf behind roll bars 26
Climate control	178	Operating safety 203	Cup holder26
Switching climate control		Operating and display elements 204	Ashtray 26
system on/off	181	Button and soft key operation 206	Cigarette lighter 27
Setting the temperature	181	Operation 206	Power outlet 27
Adjusting air distribution	182	Radio operation 209	Floormat (driver's side only) 27
Adjusting air volume	183	Introduction to satellite radio*	Telephone* 27
Basic settings	183	(USA only)214	Tele Aid 27
Defrosting windshield	184	CD mode	Garage door opener* 28
Air recirculation mode	185	GSM network phones 229	Heated steering wheel*
Air conditioning	187	TDMA or CDMA network phones 236	(SLK 280, SLK 350, Canada only). 28
Residual engine heat utilization	188	Emergency calls "911" 243	

Contents

	At the gas station 304	DOT, Tire Identification Number	
Operation 291	Refueling	(TIN)	3
The first 1000 miles (1500 km) 292	Check regularly and before	Maximum tire load 3	
Oriving instructions	a long trip 305	Maximum tire inflation pressure 3	4
Drive sensibly - save fuel 293	Engine compartment 307	Uniform Tire Quality Grading	
Drinking and driving 293	Hood 307	Standards (U.S. vehicles) 3	4
Pedals 293	Engine oil 308	Tire ply material 3	4:
Power assistance 293	Transmission fluid level* 313	Tire and loading terminology 3	4
Brakes 294	Coolant level 313	Rotating tires 3	4
Driving off 296	Battery 314	Winter driving 3	48
Parking 296	Windshield washer system and	Winter tires 3	48
Tires 297	headlamp cleaning system* 315	Snow chains 3	4
Hydroplaning 297	Tires and wheels 317	Maintenance 3	5(
Tire traction	Important guidelines 317	Clearing the maintenance	
Tire speed rating 298	Tire care and maintenance 318	service indicator 3	5
Winter driving instructions 299	Direction of rotation 320	Maintenance service term	
Standing water 300	Loading the vehicle 320	exceeded 3	5
Passenger compartment 301	Recommended tire inflation	Calling up the maintenance	
Driving abroad 301	pressure 327	service indicator 3	5
Control and operation of radio	Checking tire inflation pressure 329	Resetting the maintenance	
transmitter 301	MOExtended system* 333	service indicator 3	5
Catalytic converter 302	Tire labeling 334	Vehicle care 3	5:
Emission control 302	Load identification 338	Cleaning and care of vehicle 3	5
Coolant temperature 303			

Practical hints	361
What to do if	362
Lamps in instrument cluster	362
Lamp in center console	367
Vehicle status messages in the	
multifunction display	368
Where will I find?	388
First aid kit	388
Vehicle tool kit, vehicle jack	388
Spare wheel with collapsible tire	391
Spare wheel bolts	392
Unlocking/locking in an emergency	394
Unlocking the vehicle	394
Locking the vehicle	395
Manually unlocking the gear	
selector lever	
(automatic transmission*)	396
Opening/closing in an emergency	397
Raising retractable hardtop	
manually	397
Replacing SmartKey batteries	398
SmartKey	399

Replacing bulbs 400
Bulbs 401
Replacing bulbs for front lamps 403
Replacing bulbs for rear lamps 405
Replacing wiper blades 406
Removing wiper blades 406
Installing wiper blades 407
Flat tire
Preparing the vehicle 408
Sealing tires with TIREFIT 408
Mounting the spare wheel 412
Battery 421
Disconnecting the battery 422
Removing the battery 422
Charging and reinstalling battery 423
Reconnecting the battery 423
Jump starting 424
Towing the vehicle426
Installing towing eye bolt 428
Fuses
Aids for replacing fuses 430
Main fuse box in passenger
compartment 431
Fuse box in engine compartment 432

433
434
435
435
436
437
437
437
438
439
441
443
445
446
447
448

Contents

Capacities	49
Engine oil additives	49
Air conditioning refrigerant	51
Brake fluid	51
Premium unleaded gasoline	51
Fuel requirements	51
Gasoline additives	52
Coolants 4	52
	53
Windshield washer system and	53
Willustileiu wastiet system and	
headlamp cleaning system* 4	56

Technical terms	457
Index	465

Product information

▼ Product information

Please observe the following in your own best interest:

We recommend using genuine Mercedes-Benz parts as well as conversion parts and accessories explicitly approved by us for your vehicle model.

We have tested these parts to determine their reliability, safety and special suitability for Mercedes-Benz vehicles. We are unable to make an assessment for other products and therefore cannot be held responsible for them, even if in individual cases an official approval or authorization by governmental or other agencies should exist. Use of such parts and accessories could adversely affect the safety, performance or reliability of your vehicle. Please do not use them.

Genuine Mercedes-Benz parts as well as conversion parts and accessories approved by us are available at your authorized Mercedes-Benz Center where you will receive comprehensive information, also on permissible technical modifications, and where proper installation will be performed.

This Operator's Manual contains a great deal of useful information. We urge you to read it carefully and familiarize yourself with the vehicle before driving.

For your own safety and longer service life of the vehicle, we urge you to follow the instructions and warnings contained in this manual. Ignoring them could result in damage to the vehicle or personal injury to you or others. Vehicle damage caused by failure to follow instructions is not covered by the Mercedes-Benz Limited Warranty.

Your vehicle may have some or all of the equipment described in this manual. Therefore, you may find explanations for optional equipment not installed in your vehicle. If you have any questions about the operation of any equipment, your authorized Mercedes-Benz Center will be glad to demonstrate the proper procedures.

We continuously strive to improve our product, and ask for your understanding that we reserve the right to make changes in design and equipment. Therefore, information, illustrations and descriptions in this Operator's Manual might differ from your vehicle.

Optional equipment is also described in this manual, including operating instructions wherever necessary. Since they are special-order items, the descriptions and illustrations herein may vary slightly from the actual equipment of your vehicle.

If there are any equipment details that are not shown or described in this Operator's Manual, your authorized Mercedes-Benz Center will be glad to inform you of correct care and operating procedures.

The Operator's Manual and Maintenance Booklet are important documents and should be kept with the vehicle.

Service and warranty information

The Service and Warranty Information Booklet contains detailed information about the warranties covering your Mercedes-Benz, including:

- New Car Limited Warranty
- Emission System Warranty
- Emission Performance Warranty
- California, Maine, Massachusetts, and Vermont Emission Control System Warranty (California, Maine, Massachusetts, and Vermont only)
- State Warranty Enforcement Laws (Lemon Laws)

Important notice for California retail buyers and lessees of Mercedes-Benz automobiles

Under California law you may be entitled to a replacement of your vehicle or a refund of the purchase price or lease price, if Mercedes-Benz USA, LLC and/or its authorized repair or service facilities fail to fix one or more substantial defects or malfunctions in the vehicle that are covered by its express warranty after a reasonable number of repair attempts. During the period of 18 months from original delivery of the vehicle or the accumulation of 18000 miles (approx. 29000 km) on the odometer of the vehicle, whichever occurs first, a reasonable number of repair attempts is presumed for a retail buyer or lessee if one or more of the following occurs:

- the same substantial defect or malfunction results in a condition that is likely to cause death or serious bodily injury if the vehicle is driven, that defect or malfunction has been subject to repair two or more times, and you have directly notified Mercedes-Benz USA, LLC in writing of the need for its repair,
- (2) the same substantial defect or malfunction of a less serious nature than category (1) has been subject to repair four or more times and you have directly notified us in writing of the need for its repair, or

(3) the vehicle is out of service by reason of repair of the same or different substantial defects or malfunctions for a cumulative total of more than 30 calendar days.

Written notification should be sent to us, not a dealer, at Mercedes-Benz USA, LLC, Customer Assistance Center, One Mercedes Drive, Montvale, NJ 07645-0350.

Maintenance

The Maintenance Booklet describes all the necessary maintenance work which should be performed at regular intervals.

Always have the Maintenance Booklet with you when you take the vehicle to your authorized Mercedes-Benz Center for service. The service advisor will record each service in the booklet for you.

Roadside Assistance

The Mercedes-Benz Roadside Assistance Program provides factory-trained technical help in the event of a breakdown. Calls to the toll-free Roadside Assistance number

1-800-FOR-MERCedes (in the USA) 1-800-387-0100 (in Canada)

will be answered by Mercedes-Benz Customer Assistance Representatives 24 hours a day, 365 days a year.

For additional information refer to the Mercedes-Benz Roadside Assistance Program Brochure in your vehicle literature portfolio.

Change of address or ownership

If you change your address, be sure to send in the "Change of Address Notice" found in the Service and Warranty Information Booklet, or simply call the Mercedes-Benz Customer Assistance Center (in the USA) at 1-800-FOR-MERCedes, or Customer Service (in Canada) at 1-800-387-0100. It is in your own interest that we can contact you should the need arise.

If you sell your Mercedes, please leave all literature with the vehicle to make it available to the next operator.

If you bought this vehicle used, be sure to send in the "Notice of Purchase of Used Car" found in the Service and Warranty Information Booklet, or call the Mercedes-Benz Customer Assistance Center (in the USA) at 1-800-FOR-MERCedes, or Customer Service (in Canada) at 1-800-387-0100.

Operating your vehicle outside the USA or Canada

If you plan to operate your vehicle in foreign countries, please be aware that:

- service facilities or replacement parts may not be readily available,
- unleaded gasoline for vehicles with catalytic converters may not be available; the use of leaded fuels will damage the catalysts,
- gasoline may have a considerably lower octane rating, and improper fuel can cause engine damage.

Certain Mercedes-Benz models are available for delivery in Europe under our European Delivery Program. For details, consult an authorized Mercedes-Benz Center or write to:

In the USA:

Mercedes-Benz USA, LLC European Delivery Department One Mercedes Drive Montvale, NJ 07645-0350

In Canada:

Mercedes-Benz Canada Inc. European Delivery Department 98 Vanderhoof Avenue Toronto, Ontario M4G 4C9

Where to find it

This Operator's Manual is designed to provide comprehensive support information for you, the vehicle operator. Each section has its own reference color.

At a glance

Here you will find an overview of all the controls that can be operated from the driver's seat.

Getting started

Here you will find all the information you need for your first drive. You should read this section first if this is your first Mercedes-Benz vehicle or if you are renting or borrowing this vehicle.

Safety and Security

Here you will find descriptions of the safety and security features of your vehicle.

Controls in detail

Here you will find detailed information about the equipment installed in your vehicle. This section expands on the "Getting started" section and also describes technical innovations. If you are already familiar with the basic functions of your vehicle, this section will be of particular interest to you.

Operation

Here you will find all the information you need for the proper operation of your vehicle.

Practical hints

This section provides fast assistance for dealing with problems you may encounter.

Technical data

All important technical data for your vehicle can be found in this section.

Indexes

The glossary provides explanations of the most important technical terms.

The table of contents and the index are designed to help you find information quickly and easily.

The following publications are part of your vehicle documentation:

- this Operator's Manual
- the Maintenance Booklet

Separate operating instructions will be provided as required depending on the equipment options installed in your vehicle.

Symbols

▼ Symbols

Trademarks:

- ESP® is a registered trademark of DaimlerChrysler.
- HomeLink® is a registered trademark of Prince, a Johnson Controls Company.
- BabySmart[™] is a trademark of Siemens Automotive Corp.
- SIRIUS and related marks are trademarks of Sirius Satellite Radio Inc.

The following symbols are found in this Operator's Manual:

* Optional equipment is identified with an asterisk. Since standard equipment varies between models, the descriptions and illustrations in this manual may differ slightly from the actual equipment of your vehicle.

Warning!



Warning notices draw your attention to hazards that may endanger your health or life, or the health or life of others.

!

Highlights hazards that may result in damage to your vehicle.



Helpful hints or further information you may find useful.

- This symbol points to instructions for you to follow.
- ► A number of these symbols appearing in succession indicates a multiple-step procedure.
- Page This symbol tells you where to look for further information on a topic.
- This continuation symbol marks an interrupted procedure which will be continued on the next page.
- -> In the glossary of technical terms, this symbol is used to indicate cross-references to term definitions.
- Display Words appearing in the multifunction display are printed in the type shown here.

Operating safety

Warning!



Work improperly carried out on electronic components and associated software could cause them to cease functioning. Because the vehicle's electronic components are interconnected, any modification made may produce an undesired effect on other systems.

See an authorized Mercedes-Benz Center for repairs or modifications to electronic components.

Other improper work or modifications on the vehicle could also have a negative impact on the operating safety of the vehicle.

Some safety systems only function while the engine is running. You should therefore never turn off the engine while driving.

Warning!



Heavy blows against the vehicle undercarriage or tires/wheels, for example when running over an obstacle, road debris or a pothole, may cause serious damage and impair the operating safety or your vehicle. If you feel a sudden significant vibration or ride disturbance, or you suspect that damage to your vehicle has occurred, you should turn on your hazard warning flashers, carefully slow down, and drive with caution to an area which is a safe distance from the road.

Inspect the vehicle undercarriage or tires/wheels for possible damage. If the vehicle appears unsafe, have it towed to the nearest authorized Mercedes-Benz Center or other qualified maintenance or repair facility for further inspection or repairs.

Proper use of the vehicle

Proper use of the vehicle requires that you are familiar with the following information and rules:

- the safety precautions in this manual
- the "Technical data" section
 (▷ page 433) in this manual
- the traffic rules and regulations
- the motor vehicle laws and safety standards

Warning!



Various labels are attached to your vehicle. These warning labels are intended to make you and others aware of various risks. You should not remove any of these warning labels unless explicitly instructed to do so by information on the label itself. Removal of any of these labels may cause you and others to be unaware of certain risks which may result in an accident and/or personal injury.

Problems with your vehicle

▼ Problems with your vehicle

If you should experience a problem with your vehicle, particularly one that you believe may affect its safe operation, we urge you to immediately contact an authorized Mercedes-Benz Center to have the problem diagnosed and corrected if required. If the matter is not handled to your satisfaction, please discuss the problem with the Mercedes-Benz Center management, or if necessary contact us at one of the following addresses:

In the USA:

Customer Assistance Center Mercedes-Benz USA, LLC One Mercedes Drive Montvale, NJ 07645-0350

In Canada:

Customer Relations Department Mercedes-Benz Canada Inc. 98 Vanderhoof Avenue Toronto, Ontario M4G 4C9

Introduction

Reporting safety defects

For the USA only:

The following text is published as required of manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

Reporting safety defects

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Mercedes-Benz USA, LLC.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Mercedes-Benz USA, LLC.

To contact NHTSA, you may either call the Auto Safety Hotline toll-free at 1-888-327-4236 (or 366-0123 in Washington, D.C. area) or write to: NHTSA, U.S. Department of Transportation, Washington, D.C. 20590. You can also obtain other information about motor vehicle safety from the Hotline.

Vehicle data recording

▼ Vehicle data recording

Information regarding electronic recording devices

(Including notice pursuant to California Code § 9951)

Please note that your vehicle is equipped with devices that can record vehicle systems data and, if equipped with the Tele Aid system, may transmit some data in certain accidents.

This information helps, for example, to diagnose vehicle systems after a collision and to continuously improve vehicle safety. DaimlerChrysler may access the information and share it with others

- for safety research or vehicle diagnosis purposes
- with the consent of the vehicle owner or lessee
- in response to an official request by law enforcement or other government agency
- for use in dispute resolution involving DaimlerChrysler, its affiliates or sales/service organization and/or
- as otherwise required or permitted by law.

Please check the Tele Aid subscription service agreement for details regarding the information that may be recorded or transmitted via that system.

Cockpit

Instrument cluster

Multifunction steering wheel

Center console

Overhead control panel

Door control panel



Cockpit



Cockpit

	Item	Page
1	Automatic transmission*: Steering wheel gearshift control*	165
	SLK 55 AMG: Steering wheel gearshift control	167
2	Multifunction steering	26,
	wheel	124
3	Horn	
4	Instrument cluster	24, 120
5	Overhead control panel	30, 117
6	Glove box	266
7	Center console	28, 29
8	Sun sensor for automatic climate control*	
9	Starter switch	36

	Item	Page
10	Steering wheel adjustment handle, manual	42
11)	Steering wheel adjustment lever, electrical*	43
	Heated steering wheel* (SLK 280, SLK 350, Canada only)	288
12	Headlamp cleaning* switch	173
13	Hood lock release	307
14)	Exterior lamp switch	55, 110
15)	Combination switch	
	Turn signals	55
	Windshield wipers	56
	High beam headlamps	55
16	Power window switches	246
17	Door handle	97
(18)	Cruise control lever	260

Instrument cluster




Instrument cluster

	Item	Dogo
	item	Page
1	Multifunction display with:	
	Main odometer	128
	Trip odometer	122
	Automatic transmission*: Gear range indicator	51, 158
	Automatic transmission*: Program mode	163, 169
	Outside temperature indicator (or actual speed when selected)	138
2	Tachometer with:	
	Engine malfunction indicator lamp, USA only	364
	Engine malfunction indicator lamp, Canada only	364

	Item	Page
	Seat belt telltale	71, 366
	High beam headlamp indicator lamp	55, 114
3	Fuel gauge with:	
	Fuel reserve warning lamp	365
	The arrow indicates that the fuel filler flap is on the rear right-hand side.	304
4	Clock	122
(5)	Speedometer with:	
	SRS Supplemental Restraint System (SRS) indicator lamp	64, 366
	Antilock Brake System (ABS) indicator lamp	82, 362

	Item		Page
	¢	Left turn signal indicator lamp	55
	₿	Right turn signal indicator lamp	
	\triangle	Electronic Stability Program (ESP®) warning lamp	84, 365
	BRAKE	Brake warning lamp, USA only	59, 363
	(())	Brake warning lamp, Canada only	363
6	Reset	button	120
7		s for instrument er illumination	120

Multifunction steering wheel



	Item	Page
1	Multifunction display	120
	Operating control system	123
2	Selecting a submenu or set- ting the volume: Press button	
	+ up/to increase	
	down/to decrease	
3	Telephone*: Press button	
	to take a call, or to dial a call	
	to end a call, or to reject an incoming call	

	Item	Page
4	Moving within a menu: Press button	
	for next display	
	for previous display	
5	Menu systems: Press button	
	for next menu	
	for previous menu	

Multifunction steering wheel



SLK 55 AMG:

The steering wheel in this vehicle will vary from steering wheel shown. However, multifunction steering wheel symbols and feature description apply to AMG vehicles as well.

Center console

Upper part



	Item	Page
1	Cup holder	268
2	Audio system, or	129
	COMAND* (see separate operating instructions)	
3	AIRSCARF neck-level heating* switch, passenger-side	105
4	Seat heater* switch, passenger-side	104
5	Central unlocking switch	101
6	Hazard warning flasher switch	117
7	Central locking switch	101
8	ESP® switch	84
9	Seat heater* switch, driver's side	104

	Item	Page
10	AIRSCARF neck-level heating* switch, driver's side	105
11)	Passenger front air bag off	77,
	indicator lamp	367
12	Climate control	178
	Automatic climate control*	190
	Rear window defroster switch	177
(13)	Cigarette lighter	270
14)	Ashtray	269

Center console


Lower part



	Item	Page
1	Automatic transmission*: Gear selector lever	157
	Manual transmission: Gearshift lever	155
2	Retractable hardtop opening/closing switch	252
3	Tow-away alarm deactivation switch	89
4	Parking brake lever	52
5	Storage compartment	266
	Telephone* compartment	

	Item	Page
6	Passenger-side exterior rear view mirror switch	45, 173
7	Driver's side exterior rear view mirror switch	45, 173
8	Exterior rear view mirrors adjustment switch	45, 173
9	Automatic transmission*: Program mode selector switch	163, 169

Overhead control panel



	Item	Page
1	Interior lighting on/off	117
2	Interior lighting automatic control switch	119
3	Right reading lamp on/off	117
4	Tele Aid (emergency call system) button	273
5	Garage door opener*	281
6	Sensor for auto-dimming mirrors*	174
7	Interior rear view mirror	45, 173
8	Left reading lamp on/off	119

Door control panel


▼ Door control panel



	Item	Page
1	Door handle	97
2	Power window switch for opening/closing passenger-side window	246
3	Power window switch for opening/closing driver's side window	246

Getting started

Unlocking
Adjusting
Driving
Parking and locking




Getting started

Unlocking

The "Getting started" section provides an overview of the vehicle's most basic functions. First-time Mercedes-Benz owners should pay special attention to the information given here.

If you are already familiar with the basic functions described here, the "Controls in detail" section (> page 91) will provide you with further information. The corresponding page references are located at the end of each segment.

Unlocking with the SmartKey



SmartKey with remote control

- (1) Lock button
- 2 S Unlock button for trunk lid
- 3 Unlock button
 - PANIC Panic button (▷ page 80)

- ► Press unlock button on the SmartKey.
 - All turn signal lamps flash once. The locking knobs in the doors move up. The anti-theft alarm system is disarmed.
- ► Get in the vehicle and insert the SmartKey in the starter switch.

Unlocking



Opening a door causes the windows on that side of the car to open slightly. They will return to the up position when the door is closed.



The side windows will not open or close if the battery is discharged or the windows are covered with ice. As a result, you may no longer be able to properly close the door. Do not attempt to force the door shut. Doing so may damage the door or the side window. Correct the condition that prevents the windows from operating before attempting to close the door.



Without the antenna on the left rear side of the vehicle installed, the SmartKey signaling range is considerably reduced. Hold the SmartKey in close proximity towards the antenna base when locking or unlocking the vehicle.

For more information, see "Locking and unlocking" (▷ page 92).

Getting started

Unlocking

Starter switch positions

Warning!



When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause an accident and/or serious personal injury.

SmartKey



Starter switch

- O For removing the SmartKey The steering is locked when the SmartKey is removed from the starter switch.
- 1 Power supply for some electrical consumers, such as seat adjustment.
- 2 Ignition (power supply for all electrical consumers) and driving position.

 All lamps (except high beam headlamp indicator lamp and turn signal indicator lamps unless activated) in the instrument cluster come on. If a lamp in the instrument cluster fails to come on when the ignition is switched on, have it checked and replaced if necessary. If a lamp in the instrument cluster remains on after starting the engine or comes on while driving, refer to see "Lamps in instrument cluster" (▷ page 362).
- 3 Starting position.

Unlocking



When you switch on ignition, the indicator and warning lamps (except high beam headlamp indicator lamp and turn signal indicator lamps unless activated) in the instrument cluster come on. The indicator and warning lamps (except high beam headlamp indicator lamp and turn signal indicator lamps if activated) will go out when the engine is running. This indicates that the respective systems are operational.



Vehicles with automatic transmission*: The SmartKey can only be removed from the starter switch with the gear selector lever in position **P**.

!

If the SmartKey cannot be turned in the starter switch, the vehicle battery may not be sufficiently charged.

- Check the vehicle battery and charge it if necessary (> page 421).
- Get a jump start (> page 424).

To prevent accelerated vehicle battery discharge or a completely discharged vehicle battery, always remove the SmartKey from the starter switch when the engine is not in operation.

For information on starting the engine, see $(\triangleright page 50)$.

Warning!



All seat, head restraint, steering wheel, and rear view mirror adjustments, as well as fastening of seat belts, must be done before the vehicle is put into motion.

Seats

The seats can be adjusted either manually or electrically, depending on the vehicle's equipment.

For more information, see "Seats" (⊳ page 104).

Warning!



Do not adjust the driver seat while driving. Adjusting the seat while driving could cause the driver to lose control of the vehicle.

Never ride in a moving vehicle with the seat back in an excessively reclined position as this can be dangerous. You could slide under the seat belt in a collision. If you slide under it, the belt would apply force at the abdomen or neck. That could cause serious or fatal injuries. The seat back and seat belts provide the best restraint when the wearer is in a nearly upright position and belts are properly positioned on the body. Your seat must be adjusted so that you can correctly fasten your seat belt (> page 47).

Never place hands under the seat or near moving parts while the seat is being adjusted.

Warning!



When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle.

Even with the SmartKey removed from the starter switch, the power seats* can be operated when the respective door is open. Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause an accident and/or serious personal injury.

Warning!



Children 12 years old and under must never ride in this vehicle, except in a Mercedes-Benz authorized BabySmartTM compatible child seat, which operates with the BabySmartTM system installed in the vehicle to deactivate the passenger front air bag when it is properly installed. Otherwise they will be struck by the air bag when it inflates in a crash. If this happens, serious or fatal injury will result.

Infants and small children must be seated in an appropriate BabySmartTM compatible infant or child restraint system, which is properly secured with the vehicle's seat belt, fully in accordance with the child seat manufacturer's instructions.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and the child is not properly secured in the child restraint.

!

When moving the seats, make sure there are no items in the footwell or behind the seats. Otherwise you could damage the seats.

Manual seat adjustment



- ① Seat fore and aft adjustment
- 2 Seat height
- (3) Backrest tilt

Seat fore and aft adjustment

- ▶ Pull handle ①.
 - Adjust seat to the desired position.

 Adjust seat to a comfortable seating position that allows you to reach the accelerator/brake pedal safely. The position should be as far rearward as possible, consistent with ability to properly operate controls.
- ► Allow handle ① to reengage with an audible click.
- ► Check for proper engagement before driving.

Seat height

 Pull or push handle ② up or down and adjust the seat height until your legs are slightly supported.

Backrest tilt


- ► Pull handle ③ and adjust the backrest until your arms are slightly angled when holding the steering wheel.
- ► Release handle ③ when the desired backrest tilt is reached.

When you hear an audible click, the backrest is again fixed into place.

For more information, see "Seats" (▷ page 104).

Power seat* adjustment

The seat adjustment switches are located on the outer side of each seat.



- (1) Seat fore and aft adjustment
- ② Seat height
- (3) Backrest tilt
- (4) Seat cushion tilt
- Switch on the ignition (▷ page 36).

or

Open the respective door.



The memory function* (▷ page 107) lets you store the settings for power seats*, steering wheel adjustment (electrical)*, and exterior rear view mirrors.

Seat fore and aft adjustment

Press the horizontal switch forward or backward in direction of arrow (1).

Adjust seat to a comfortable seating position that still allows you to reach the accelerator/brake pedal safely. The position should be as far rearward as possible, consistent with ability to properly operate controls.

Seat height

 Press the horizontal switch up or down in direction of arrow ② and adjust the seat height until your legs are slightly supported.

Backrest tilt

Press the vertical switch forward or backward in direction of arrow (3) until your arms are slightly angled when holding the steering wheel.

Seat cushion tilt

Press the horizontal switch up or down in direction of arrow (4) until your upper legs are lightly supported.

Head restraint height

Warning!



For your protection, drive only with properly positioned head restraints.

Adjust head restraint so that the head restraint supports the back of the head at eye level. This will reduce the potential for injury to the head and neck in the event of an accident or similar situation.

Do not drive the vehicle without the seat head restraints. Head restraints are intended to help reduce injuries during an accident.



Head restraint

Adjust the height of head restraints manually by pulling them upwards or pushing them downwards.



Adjust the head restraint in such a way that it is as close to the head as possible.

Steering wheel

Warning!



Do not adjust the steering wheel while driving. Adjusting the steering wheel while driving, or driving without the steering wheel adjustment feature locked could cause the driver to lose control of the vehicle.

When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle.

Even with the SmartKey removed from the starter switch, the electrical steering wheel adjustment feature* can be operated when the driver's door is open. Therefore, do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause an accident and/or serious personal injury.

Steering wheel adjustment, manual



- 1 Adjustment handle
- ► To unlock the steering column, pull handle (1) out to its stop limit.
- Move the steering wheel to the desired position.
- Push handle ① back to its original position to relock the steering column.

When you hear an audible click, the steering column is again fixed into place.

Make sure the steering column is securely locked by trying to move the steering wheel up and down, in and out before driving off.



Do not drive the vehicle until you have properly locked the steering column.

Warning!




Only adjust the steering wheel with the vehicle at a standstill and make sure the steering column is securely locked in place before driving off.

Driving without the steering column locked may cause an unexpected steering wheel movement which could cause the driver to lose control of the vehicle. Make sure the steering column is securely locked by trying to move it up and down, and in and out before driving off.

Steering wheel adjustment, electrical*

The lever for the electrical steering wheel adjustment is located on the steering column (lower left).



- (1) Adjusting steering column, in or out
- ② Adjusting steering column, up or down
- ► Switch on the ignition (> page 36).

or

Open the driver's door.



The memory function* (> page 107) lets you store the settings for the steering wheel together with the settings for the exterior rear view mirrors and the driver's seat position.

Adjusting steering column in or out

► Move the lever in direction of arrows ① until a comfortable steering wheel position is reached with your arms slightly bent at the elbow.

Adjusting steering column up or down

Move the lever in direction of arrows ②.

Make sure your legs can move freely and all the displays (including malfunction and indicator lamps) on the instrument cluster are clearly visible.

Easy-entry/exit feature*

This feature allows for easier entry into and exit from the vehicle.

The easy-entry/exit feature can be activated or deactivated in the Convenience submenu of the control system (> page 147).

Warning!



You must make sure no one can become trapped or injured by the moving steering wheel when the easy-entry/exit feature is activated.

To cancel steering wheel movement, do one of the following:

- Move steering column lever* (▷ page 43).
- Press one of the memory position buttons* or the memory button M*
 (▷ page 107).

Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could open the driver's door and unintentionally activate the easy-entry/exit feature, which could result in an accident and/or serious personal injury.

With the easy-entry/exit feature activated, the steering wheel will return to its last set position when you:

 close the driver's door with the ignition switched on,

or

 insert the SmartKey into the starter switch with the driver's door closed.



The last set steering wheel position is stored when

- the ignition is switched off
- the position is stored in memory (▷ page 107)

With the easy-entry/exit feature activated, the steering wheel tilts upwards when you:

 remove the SmartKey from the starter switch,

or

 open the driver's door with the SmartKey in starter switch position 0 or 1.



If the current position for the steering wheel is in the uppermost tilt position, the steering wheel will no longer be able to move upward when the easy-entry/exit feature is activated.

The adjustment procedure is briefly interrupted when the engine is started.

Warning!



Let the system complete the adjustment procedure before setting the vehicle in motion. All steering wheel adjustment must be completed before setting the vehicle in motion. Driving off with the steering wheel still adjusting could cause the driver to lose control of the vehicle.

Mirrors

Adjust the interior and exterior rear view mirrors before driving so that you have a good view of the road and traffic conditions.

Warning!



In case of an accident, liquid electrolyte may escape the mirror housing if the mirror glass breaks.

Electrolyte has an irritating effect. Do not allow the liquid to come into contact with eyes, skin, clothing, or respiratory system. In case it does, immediately flush affected area with water, and seek medical help if necessary.

!

Electrolyte drops coming into contact with the vehicle paint finish can only be completely removed while in their liquid state and by applying plenty of water.

Interior rear view mirror

Adjust the interior rear view mirror manually.

For more information, see "Rear view mirrors" (\triangleright page 173).

Exterior rear view mirrors

Warning!



Exercise care when using the passenger-side exterior rear view mirror. The mirror surface is convex (outwardly curved surface for a wider field of view). Objects in mirror are closer than they appear. Check your interior rear view mirror or glance over your shoulder before changing lanes.

!

If an exterior rear view mirror housing is forcibly pushed forward (hit from the rear) or rearward (hit from the front), reposition it by applying firm pressure until it snaps into place. The exterior rear view mirror housing is now properly positioned and you can adjust the mirror normally.

The switches are located on the lower part of the center console.



- 1 Driver's side exterior rear view mirror
- 2 Adjustment switch
- ③ Passenger-side exterior rear view mirror



The memory function (▷ page 107) lets you store the settings for the exterior rear view mirrors together with the settings for the steering wheel and the driver's seat position.

- Switch on the ignition (▷ page 36).
- Press switch ① or ③ to select the respective exterior rear view mirror.

The indicator lamp in the respective switch comes on. If you do not adjust the selected exterior rear view mirror by pressing adjustment switch ②, the indicator lamp in the switch will switch off automatically after approximately 10 seconds.

 Press adjustment switch ② forward, rearward, left, or right according to the desired setting.



At low ambient temperatures, the exterior rear view mirrors will be heated automatically.

!

Before driving the vehicle through an automatic car wash, fold the exterior mirrors in. Otherwise they may get damaged.

For more information, see "Storing exterior rear view mirror parking position (parking aid)" (▷ page 108).

▼ Driving

Warning!



Do not lay any objects in the driver's footwell. Be careful that floor mats or carpets in the driver's footwell have sufficient clearance for the pedals.

During sudden driving or braking maneuvers the objects could get caught between the pedals. You could then no longer brake or accelerate.

Fastening the seat belts

Warning!



Always fasten your seat belt before driving off. Always make sure your passengers are properly restrained, even pregnant women.

Failure to wear and properly fasten and position your seat belt greatly increases your risk of injuries and their likely severity in an accident. You and your passenger should always wear seat belts.

If you are ever in an accident, your injuries can be considerably more severe without your seat belt properly buckled. Without your seat belt buckled, you are much more likely to hit the interior of the vehicle or be ejected from it. You can be seriously injured or killed.

In the same crash, the possibility of injury or death is lessened if you are wearing your seat belt. The air bags can only provide the protection they were designed to afford if the occupants are using their seat belts $(\triangleright \text{ page } 64)$.

Warning!



Children 12 years old and under must never ride in the front seat, except in a Mercedes-Benz authorized BabySmartTM compatible child seat, which operates with the BabySmartTM system installed in the vehicle to deactivate the passenger front air bag when it is properly installed. Otherwise they will be struck by the air bag when it inflates in a crash. If this happens, serious or fatal injury will result.

Infants and small children must be seated in an appropriate BabySmartTM compatible infant or child restraint system, which is properly secured with the vehicle's seat belt, fully in accordance with the child seat manufacturer's instructions.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and the child is not properly secured in the child restraint.

Warning!



Never let more people ride in the vehicle than there are seat belts available. Be sure everyone riding in the vehicle is correctly restrained with a separate seat belt. Never use a seat belt for more than one person at a time.

Warning!



Never ride in a moving vehicle with the seat backrest in an excessively reclined position as this can be dangerous. You could slide under the seat belt in a collision. If you slide under it, the belt would apply force at the abdomen or neck. That could cause serious or even fatal injuries. The seat backrest and seat belt provide the best restraint when the wearer is in a nearly upright position and the belt is properly positioned on the body.

Warning!



Read and observe the additional warning notices printed in the "Safety and Security" section (\triangleright page 68) and (\triangleright page 71).



- 1 Loop for seat belt guidance
- 2 Latch plate
- (3) Release button
- (4) Buckle

- ► With a smooth motion, pull the belt from the belt outlet.
- ► Place the shoulder portion of the belt across the top of your shoulder and the lap portion across your hips.
- ► Push latch plate ② into buckle ④ until it engages.
- If necessary, tighten the lap portion to a snug fit by pulling shoulder portion up.

For more information, see "Safety guidelines for the seat belt, emergency tensioning device and air bag" (> page 68).

Proper use of seat belts

- Do not twist the seat belt when fastening.
- Adjust seat belt so that the shoulder portion is located as close as possible to the middle of the shoulder (it should not touch the neck). Never pass the shoulder portion of the belt under your arm.
- Position the lap belt as low as possible on your hips (over hip joint) and not across the abdomen.
- Place the seat backrest in a nearly upright position.

Getting started

Driving

- Never use a seat belt for more than one person at a time.
- Do not fasten a seat belt around a person and another object at the same time.
- When using a seat belt to secure infant or toddler restraints or children in booster seats, always follow the child seat manufacturer's instructions.
- Check your seat belt during travel to make sure it is properly positioned.
- Make sure the seat belt is always fitted snugly. Take special care of this when wearing loose clothing.

Warning!



Do not pass belts over sharp edges. They could tear.

Do not allow the belt to get caught in the door or in the seat adjustment mechanism. This could damage the belt.

Never attempt to make modifications to seat belts. This could impair the effectiveness of the belts.

Do not bleach or dye seat belts as this may severely weaken them. In a crash, they may not be able to provide adequate protection.

Damaged seat belts or belts that were highly stressed in an accident must be replaced. Contact an authorized Mercedes-Benz Center.

Starting the engine

Warning!



Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide, and inhaling it can cause unconsciousness and possible death.

Do not run the engine in confined areas (such as a garage) which are not properly ventilated. If you think that exhaust gas fumes are entering the vehicle while driving, have the cause determined and corrected immediately. If you must drive under these conditions, drive only with at least one window fully open.

Manual transmission



Gearshift pattern for manual transmission For more information, see "Manual transmission" (⊳ page 155).

Starting


- Depress brake pedal.
- ► Make sure the gearshift lever is in neutral position (no gear selected).
- ► Fully depress clutch pedal.

Otherwise the engine cannot be started due to the integrated safety interlock.

- Do not depress accelerator.
- ► Turn the SmartKey in the starter switch to position **3** (▷ page 36) and hold until the engine starts.

For information on turning off the engine, see "Turning off engine" (> page 61).

Automatic transmission*



Gearshift pattern for automatic transmission

- **P** Park position with gear selector lever lock
- **R** Reverse gear
- N Neutral position
- **D** Drive position

For more information, see "Automatic transmission*" (▷ page 157).

Starting

- ▶ Place the gear selector lever in position P.
- Do not depress accelerator.
- Turn the SmartKey in the starter switch to position 3 (▷ page 36) and release it again immediately. The engine starts automatically.

For information on turning off the engine, see "Turning off engine" (▷ page 61).

Starting difficulties

If the engine does not start as described, carry out the following steps:

- Turn the SmartKey in the starter switch to position 0 and repeat the starting procedure.
 - Remember that extended starting attempts can drain the vehicle battery.
- ► Get a jump start (> page 424).

If the engine does not start after several starting attempts, there could be a malfunction in the engine electronics or in the fuel supply system.

Notify an authorized Mercedes-Benz Center.

Parking brake

Warning!



When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could release the parking brake, which could result in an accident and/or serious injury.



- 1 Parking brake lever
- (2) Release button
- ▶ Pull up slightly on parking brake lever ① and press release button ②.
- ► Push parking brake lever ① down to its original position.

The brake warning lamp BRAKE (USA only) or (Canada only) in the speedometer dial goes out.

Driving

Warning!



On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.



If you hear a warning signal and the message Release parking brake appears in the multifunction display when driving off, you have forgotten to release the parking brake.

!

Simultaneously depressing the accelerator pedal and the brake pedal reduces engine performance and causes premature brake and drivetrain wear.



Once the vehicle is in motion, the automatic central locking system engages and the locking knobs drop down.

For more information, see "Automatic central locking" (> page 101).

Manual transmission

- Depress the brake pedal.
- ► Fully depress the clutch pedal.
- Move gearshift lever to first gear to drive forward, or to reverse gear to drive rearward.
- Simultaneously release the brake pedal and slowly the clutch pedal.
- Carefully depress the accelerator pedal.

Automatic transmission*



Wait for the gear selection process to complete before setting the vehicle in motion.

- ▶ Depress the brake pedal.
- Move gear selector lever to position D to drive forward, or to position R to drive rearward.
- ► Release the brake pedal.
- Carefully depress the accelerator pedal.



During the brief warm-up, transmission upshifting is delayed. This allows the catalytic converter to heat up more quickly to operating temperature.

Warning!



Vehicles with automatic transmission*: It is dangerous to shift the gear selector lever out of $\bf P$ or $\bf N$ if the engine speed is higher than idle speed. If your foot is not firmly on the brake pedal, the vehicle could accelerate quickly forward or in reverse. You could lose control of the vehicle and hit someone or something. Only shift into gear when the engine is idling normally and when your right foot is firmly on the brake pedal.

Switching on headlamps

Low beam headlamps

The exterior lamp switch is located on the dashboard to the left of the steering wheel.



Exterior lamp switch

- 1) Off
- ② Low beam headlamps on
- ► Turn exterior lamp switch to position □ .

High beam

The combination switch is located on the left of the steering column.



Combination switch


- 1 High beam
- ② High beam flasher
- Push combination switch in direction of arrow ①.

The high beam headlamp indicator lamp ☐ in the instrument cluster comes on (▷ page 24).

For more information on headlamps, see "Lighting" (▷ page 110).

Turn signals

The combination switch is located on the left of the steering column.



Combination switch

- 1 Turn signals, right
- 2 Turn signals, left

Getting started

Driving

▶ Press combination switch in direction of arrow ① or ②.

The corresponding turn signal indicator lamp or in the instrument cluster flashes (> page 24).

The combination switch resets automatically after major directional changes.



To signal minor directional changes, press combination switch only to point of resistance and release. The corresponding turn signals will flash three times.

Windshield wipers

The combination switch is located on the left of the steering column.



Combination switch

- 1 Single wipe Wiping with windshield washer fluid
- 2 Switching on windshield wipers
- ► Switch on the ignition (> page 36).

!

Do not operate the windshield wipers when the windshield is dry. Dust that accumulates on a windshield might scratch the glass and/or damage the wiper blades when wiping occurs on a dry windshield. If it is necessary to operate the wipers in dry weather conditions, always operate the windshield wipers with windshield washer fluid (> page 57).

Switching on windshield wipers

- Turn the combination switch to the desired position depending on the intensity of the rain.
 - 0 Windshield wipers off
 - I Intermittent wiping
 - II Normal wiper speed
 - III Fast wiper speed

Intermittent wiping



Vehicles with rain sensor*:

Do not leave windshield wipers in intermittent setting when vehicle is taken to an automatic car wash or during windshield cleaning. Windshield wipers will operate in the presence of water sprayed on the windshield, and windshield wipers may be damaged as a result.

Vehicles with rain sensor*: Intermittent wiping interval is dependent on wetness of windshield.

► Turn the combination switch to position **I**.

Vehicles with rain sensor*: After the initial wipe, pauses between wipes are automatically controlled by the rain sensor.



Intermittent wiping is interrupted when the vehicle is at a standstill and a door is opened. This helps to avoid people being sprayed with water from wiper action when getting into and out of the vehicle.

Intermittent wiping will be continued when

· all doors are closed

and

or

- the clutch pedal is depressed (vehicles with manual transmission)
- the gear selector lever is in position **D** or **R** (vehicles with automatic transmission*)
- the wiper setting is changed using the combination switch

Single wipe

► Press the combination switch briefly in direction of arrow 1 to the resistance point.

The windshield wipers wipe one time without washer fluid.

Wiping with windshield washer fluid

Press the combination switch in direction of arrow 1 past the resistance point.

The windshield wipers operate with washer fluid.



To prevent smears on the windshield, wipe with windshield washer fluid every now and then even when it is raining.

For information on filling up the washer reservoir, see "Windshield washer system and headlamp cleaning system*" (> page 315).



If anything blocks the windshield wipers (leaves, snow, etc.), switch them off immediately.

- For safety reasons, stop the vehicle in a safe location, turn off the engine and remove the SmartKey from the starter switch before attempting to remove any blockage.
- · Remove blockage.
- Turn the windshield wipers on again.

If the windshield wipers fail to function at all with combination switch in position I,

- set combination switch to the next higher wiper speed
- have the windshield wipers checked at the nearest authorized Mercedes-Benz Center

Problems while driving

The engine runs erratically and misfires

- An ignition cable may be damaged.
- The engine electronics may not be operating properly.
- Unburned gasoline may have entered the catalytic converter and damaged it.
- Give very little gas.
- Have the problem repaired by an authorized Mercedes-Benz Center as soon as possible.

The coolant temperature is above 248°F (120°C)

The coolant is too hot and is no longer cooling the engine.

- Stop the vehicle as soon as possible and turn off the engine. Allow engine and coolant to cool.
- ► Check the coolant level and add coolant if necessary (> page 313).

In case of accident

If the vehicle is leaking gasoline:

- ► Do not start the engine under any circumstances.
- Notify local fire and/or police authorities.

If the extent of the damage cannot be determined:

 Notify an authorized Mercedes-Benz Center.

If no damage can be determined on the

- Major assemblies
- Fuel system
- · Engine mount
- Start the engine in the usual manner.

Parking and locking

▼ Parking and locking

You have now completed your first drive. You have properly stopped and parked your vehicle. End your drive as follows.

Warning!



Vehicles with manual transmission: Wait until the vehicle is stationary before removing the SmartKey from the starter switch. The vehicle cannot be steered when the SmartKey is removed.

Warning!



With the engine not running, there is no power assistance for the brake and steering system. In this case, it is important to keep in mind that a considerably higher degree of effort is necessary to brake and steer the vehicle.

Warning!




Do not park this vehicle in areas where combustible materials such as grass, hay or leaves can come into contact with the hot exhaust system, as these materials could be ignited and cause a vehicle fire.

To reduce the risk of personal injury as a result of vehicle movement, before turning off the engine and leaving the vehicle always:

- Keep right foot on brake pedal.
- Pull up the parking brake lever firmly.
- Move the gear selector lever* to position P (manual transmission: first or reverse gear).
- Slowly release brake pedal.
- When parked on an incline, turn front wheels towards the road curb.
- Turn the SmartKey in the starter switch to position 0 and remove the SmartKey from the starter switch.
- Take the SmartKey and lock vehicle when leaving.

Parking brake



- 1 Parking brake lever
- (2) Release button
- ► Pull up parking brake lever ① firmly.

When the ignition is switched on or the engine is running, the brake warning lamp BRAKE (USA only) or (Canada only) in the speedometer dial comes on.

Getting started

Parking and locking

Warning!



Getting out of your vehicle with the gear selector lever* not fully engaged in position **P** (manual transmission: first or reverse gear) is dangerous. Also, when parked on an incline, position **P** (manual transmission: first or reverse gear) alone may not prevent your vehicle from moving, possibly hitting people or objects.

Always set the parking brake in addition to shifting to position **P** (manual transmission: first or reverse gear).

When parked on an incline, turn the front wheels towards the road curb.

Warning!



When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could release the parking brake and/or move the gear selector lever* from position **P** (manual transmission: into Neutral), either of which could result in an accident and/or serious injury.

Switching off headlamps

Turn exterior lamp switch to □(▷ page 55).

For more information, see "Lighting" (⊳ page 110).

Parking and locking

Turning off engine

- Manual transmission: Move the gearshift lever into first or reverse gear.
- ► Automatic transmission*: Place the gear selector lever in position **P**.



Always set the parking brake in addition to shifting into first or reverse gear (automatic transmission*: gear selector lever in position **P**).

On slopes, turn the front wheels towards the road curb.

► Turn the SmartKey in the starter switch to position **0** and remove the SmartKey from the starter switch.

The immobilizer is activated.



Vehicles with automatic transmission*: The SmartKey can only be removed from the starter switch with the gear selector lever in position **P**.

- Press the seat belt release button (▷ page 49).
- Guide the latch plate to allow the retractor to completely rewind the seat belt.



Make sure the seat belt retracts fully so that the seat belt and/or latch plate cannot get caught or pinched in the door or in the seat mechanism. This can damage the seat belt and impair the effectiveness of the seat belt, and/or cause damage to the door and/or door trim panel. Such damage is not covered by the Mercedes-Benz Limited Warranty.

Damaged seat belts must be replaced. Contact an authorized Mercedes-Benz Center.



With the SmartKey removed from the starter switch and the driver's door open, a warning sounds if the parking lamps or low beam headlamps are switched on (> page 110).

The message Turn off lights appears in the multifunction display.

Getting started

Parking and locking



Opening a door causes the windows on that side of the car to open slightly. They will return to the up position when the door is closed.



The side windows will not open or close if the battery is discharged or the windows are covered with ice. As a result, you may no longer be able to properly close the door. Do not attempt to force the door shut. Doing so may damage the door or the side window. Correct the condition that prevents the windows from operating before attempting to close the door.

Locking

Warning!



To prevent possible personal injury, always keep hands and fingers away from the door openings when closing the doors. Be especially careful when small children are around.

Before closing doors, make sure there is no possibility of someone getting caught in a door during closing.

Warning!



When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause an accident and/or serious personal injury.

- Exit the vehicle and close all doors.
- ► Press the lock button on the SmartKey (▷ page 34).

With the trunk and all doors closed, all turn signal lamps flash three times. The locking knobs on the doors move down.

The anti-theft alarm system is armed now (\triangleright page 87).



Without the antenna on the left rear side of the vehicle installed, the SmartKey signaling range is considerably reduced. Hold the SmartKey in close proximity towards the antenna base when locking or unlocking the vehicle.

For more information, see "Locking and unlocking" (> page 92).

Occupant safety
Panic alarm
Driving safety systems
Anti-theft systems



Occupant safety

In this section you will learn the most important facts about the restraint systems of the vehicle.

The restraint systems are

- · Seat belts
- Emergency tensioning device (ETD)
- Air bags
- Child seats
- Child seat recognition

As independent systems, their protective effects work in conjunction with each other.



For information on infants and children traveling with you in the vehicle and restraint systems for infants and children, see "Children in the vehicle" (> page 75).

The sns indicator lamp in the speedometer dial (▷ page 24) comes on

- for about 4 seconds when you turn the SmartKey in the starter switch to position 1. It then goes out briefly, comes on again and remains lit until you start the engine.
- for about 4 seconds when you start the engine by turning the SmartKey.



The SRS indicator lamp remains lit if the SmartKey is turned to position 2 and left there. The indicator lamp will go out when you start the engine.

The **SRS** indicator lamp goes out shortly after you start the engine. This shows that the restraint systems are operational.

A malfunction in the system has been detected if the srs indicator lamp

- fails to extinguish after approximately 4 seconds with the SmartKey in the starter switch position 1
- does not come on at all
- · comes on after the engine was started
- · comes on while driving

For safety reasons, we strongly recommend that you visit an authorized Mercedes-Benz Center immediately to have the system checked.

For more information, see "Practical hints" (▷ page 366).

Occupant safety

Warning!



In the event that the sess indicator lamp comes on during driving or does not come on at all, the SRS self-check has detected a malfunction. For your safety, we strongly recommend that you visit an authorized Mercedes-Benz Center immediately to have the system checked; otherwise the SRS may not be activated when needed in an accident, which could result in serious or fatal injury, or it might deploy unexpectedly and unnecessarily which could also result in injury.

In addition, improper work on the SRS creates a risk of rendering the SRS inoperative or causing unintended air bag deployment. Work on the SRS must therefore only be performed by qualified technicians. Contact an authorized Mercedes-Benz Center.

Air bags

Warning!



Air bags are designed to reduce the potential of injury in certain frontal impacts (front air bags, kneebags), or side impacts (head-thorax air bags) which may cause significant injuries. However, no system available today can totally eliminate injuries and fatalities.

The activation of the air bags temporarily releases a small amount of dust from the air bags. This dust, however, is neither injurious to your health, nor does it indicate a fire in the vehicle. The dust might cause some temporary breathing difficulty for people with asthma or other breathing trouble. To avoid this, you may wish to get out of the vehicle as soon as it is safe to do so. If you have any breathing difficulty but cannot get out of the vehicle after the air bag inflates, then get fresh air by opening a window or door.

Warning!



To reduce the risk of injury when the front air bags inflate, it is very important for the driver and passenger to always be in a properly seated position and to wear their seat belts.

For maximum protection in the event of a collision always be in normal seated position with your back against the backrest. Fasten your seat belt and ensure it is properly positioned on your body.

Since the air bag inflates with considerable speed and force, a proper seating and hands on steering wheel position will help to keep you at a safe distance from the air bag. Occupants who are unbelted, out of position or too close to the air bag can be seriously injured or killed by an air bag as it inflates with great force in the blink of an eye:

 Sit properly belted in a nearly upright position with your back against the seat backrest.



Occupant safety

DD

- Adjust the driver seat as far as possible rearward, still permitting proper operation of vehicle controls. The distance from the center of the driver's breastbone to the center of the air bag cover on the steering wheel must be at least ten inches (25 cm) or more. You should be able to accomplish this by a combination of adjustments to the seat and the steering wheel. If you have any problems, please see an authorized Mercedes-Benz Center.
- Do not lean with your head or chest close to the steering wheel or dashboard.
- Keep hands on the outside of the steering wheel rim. Placing hands and arms inside the rim can increase the risk and potential severity of hand/arm injury when driver front air bag inflates.
- Adjust the passenger seat as far as possible rearward from the dashboard when the seat is occupied.

- Occupants, especially children, should never lean their heads in the area of the door where the head-thorax air bag inflates. This could result in serious injuries or death should the air bag be triggered. Always sit nearly upright, properly use the seat belts and appropriately sized infant or child restraint system.
- Children 12 years old and under must never ride in this vehicle, except in a Mercedes-Benz authorized BabySmartTM compatible child seat, which operates with the BabySmartTM system installed in the vehicle to deactivate the passenger front air bag when it is properly installed. Otherwise, they will be struck by the air bag when it inflates in a crash. If this happens, serious or fatal injury will result.

Failure to follow these instructions can result in severe injuries to you or other occupants.

If you sell your vehicle, it is important that you make the buyer aware of this safety information. Be sure to give the buyer this Operator's Manual.

Occupant safety

Warning!



Accident research shows that the safest place for children in an automobile is in the rear seat. Should you choose to place a child 12 years old or under in the passenger seat of your vehicle, you must properly use a BabySmartTM child restraint which will turn off the passenger front air bag. BabySmartTM will not, however, turn off any head-thorax air bag.

It should be noted, however, that there is a possibility of a head-thorax air bag related injury if occupants, especially children, are not properly seated or restrained when next to a head-thorax air bag which needs to deploy rapidly in a side impact in order to do its job.

To help avoid the possibility of injury, please follow these guidelines:

- (1) Occupants, especially children, should never place their bodies or lean their heads in the area of the door where the head-thorax air bag inflates. This could result in serious injuries or death should the head-thorax air bag be activated.
- (2) Always sit nearly upright, properly use the seat belts and use an appropriately sized infant or child restraint system for all children 12 years old or under.

(3) Always wear seat belts properly.

If you believe that, even with the use of these guidelines, it would be safer for your passenger seat occupants to have the passenger head-thorax air bag deactivated, then deactivation can be accomplished upon your written request to do so at an authorized Mercedes-Benz Center at an additional cost.

Please contact your local authorized Mercedes-Benz Center or call our Customer Assistance Center at 1-800-FOR-MERCedes (1-800-367-6372) for details.

Occupant safety



Air bags are designed to activate only in certain frontal impacts (front air bags, kneebags), or side impacts (head-thorax air bags) which exceed preset thresholds.

Only during these types of impacts, if of sufficient severity to meet the deployment thresholds, will they provide their supplemental protection.

The driver and passenger should always wear their seat belts. Otherwise it is not possible for the air bags to provide their supplemental protection.

In cases of other frontal impacts, angled impacts, roll-overs, other side impacts, rear collisions, or other accidents, the air bags will not be activated. The driver and the passenger will then be protected by the fastened seat belts.

We caution you not to rely on the presence of the air bags in order to avoid wearing your seat belt.

Your vehicle was originally equipped with air bags that are designed to activate in certain impacts exceeding a preset threshold to reduce the potential and severity of injury. It is important to your safety and that of your passengers that you replace deployed air bags and repair any malfunctioning air bags to make sure the vehicle will continue to provide supplemental crash protection for occupants.

Safety guidelines for the seat belt, emergency tensioning device and air bag

Warning!



- Damaged seat belts or belts that were highly stressed in an accident must be replaced and their anchoring points must also be checked. Only use belts installed or supplied by an authorized Mercedes-Benz Center.
- Air bags and emergency tensioning devices (ETDs) are designed to function on a one-time-only basis. An air bag or ETD that was activated must be replaced.
- No modifications of any kind may be made to any components or wiring of the SRS. This includes changing or removing any component or part of the SRS, the installation of additional trim material, badges etc. over the steering wheel hub, passenger air bag cover, outboard sides of the seat backrests, door trim panels, or door frame trims,

Occupant safety

and installation of additional electrical/electronic equipment on or near SRS components and wiring. Keep area between air bags and occupants free from objects (e.g. packages, purses, umbrellas, etc.).

- Do not pass belts over sharp edges.
 They could tear.
- Do not make any modification that could change the effectiveness of the belts.
- Do not bleach or dye seat belts as this may severely weaken them. In a crash they may not be able to provide adequate protection.
- Never place your feet on the instrument panel, or on the seat. Always keep both feet on the floor in front of the seat.
- Air bag system components will be hot after an air bag has inflated. Do not touch.

- In addition, improper repair work on the SRS creates a risk of rendering the SRS inoperative or causing unintended air bag deployment. Work on the SRS must therefore only be performed by qualified technicians. Contact an authorized Mercedes-Benz Center.
- For your protection and the protection of others, when scrapping the air bag unit or emergency tensioning device, our safety instructions must be followed. These instructions are available from your authorized Mercedes-Benz Center.
- Given the considerable deployment speed and the textile structure of the air bags, there is the possibility of abrasions or other injuries resulting from air bag deployment.

Warning!



Only use seat covers which have been tested and approved by Mercedes-Benz for your vehicle model. Using other seat covers may interfere with or prevent the deployment of the head-thorax airbags. Contact your authorized Mercedes-Benz Center for availability.

When you sell your vehicle, we strongly urge you to give notice to the subsequent owner that it is equipped with an SRS by alerting them to the applicable section in the Operator's Manual.

Occupant safety

Front air bags



- 1) Driver's air bag
- 2 Passenger air bag
- (3) Kneebag (passenger side)
- (4) Kneebag (driver's side)

Driver and passenger air bags are deployed

- in the event of certain frontal impacts
- if impact exceeds a preset deployment threshold
- independently of the head-thorax air bags

The air bags will not deploy in impacts which do not exceed the system's deployment thresholds. You will then be protected by the fastened seat belts.

The passenger air bag will only be deployed if

- · the passenger seat is occupied
- the PASSARBAGOFF indicator lamp in the center console is not lit (▷ page 77)
- the impact exceeds a preset deployment threshold

!

Do not place objects heavier than 20 lbs (9 kg) on the passenger seat. This could cause the front air bag or head-thorax air bag on the passenger side to deploy in a crash which exceeds the system's deployment threshold.

Kneebags

The driver-side kneebag is located on the driver's side lower instrument panel. The passenger-side kneebag is located on the passenger side below the glove box. They are designed to operate together with the air bags in certain frontal impacts exceeding a preset threshold. The kneebags operate best in conjunction with properly positioned and fastened seat belts.

Occupant safety

Head-thorax air bags



1 Head-thorax air bag

The head-thorax air bags are deployed

- on the impacted side of the vehicle
- in impacts exceeding a preset deployment threshold
- independently of the front air bags

The passenger-side head-thorax air bag will only deploy if the system senses that the passenger seat is occupied.

The head-thorax air bags are not deployed in impacts which do not exceed the system's deployment threshold.

Seat belts

When the engine is started, the seat belt telltale illuminates for a maximum of 6 seconds and a warning chime sounds to remind you and your passenger to fasten your seat belt.

If after these 6 seconds, the driver's or the passenger's seat belt (with the passenger seat occupied) are not fastened with all doors closed,

and the vehicle speed does not exceed 15 mph (25 km/h), the seat belt telltale remains illuminated for as long as either the driver's or passenger's seat belt is not fastened.

and the vehicle speed exceeds 15 mph (25 km/h), the seat belt telltale starts flashing and a warning chime sounds with increasing intensity until both the driver's and passenger's seat belt are fastened, or for a maximum of 60 seconds from the time the vehicle speed exceeded 15 mph (25 km/h) if either the driver's or passenger's seat belt remains unfastened.

If the driver's or passenger's seat belt remains unfastened after 60 seconds, the seat belt telltale stops flashing and the warning chime stops sounding. The seat belt telltale then continues to be illuminated for as long as either the driver's or passenger's seat belt are not fastened.

The seat belt telltale will only go out if both the driver's and passenger's seat belt (with the passenger seat occupied) are fastened, or the vehicle is standing still and a door is opened.

Occupant safety

Always wear your seat belt. All vehicle occupants always need to have their seat belts fastened and wear them properly.

In addition, applicable motor vehicle safety laws require you to wear seat belts. Even where this is not the case, we strongly recommend that all vehicle occupants have their seat belts fastened and wear them properly.

For more information, see "Fastening the seat belts" (\triangleright page 47).



For information on infants and children traveling with you in the vehicle and restraint systems for infants and children, see "Children in the vehicle" (> page 75).

Warning!



Always fasten your seat belt before driving off. Always make sure your passenger is properly restrained, even pregnant women.

Failure to wear and properly fasten and position your seat belt greatly increases your risk of injuries and their likely severity in an accident. You and your passenger should always wear seat belts.

If you are ever in an accident, your injuries can be considerably more severe without your seat belt properly buckled. Without your seat belt buckled, you are much more likely to hit the interior of the vehicle or be ejected from it. You can be seriously injured or killed.

In the same crash, the possibility of injury or death is lessened if you are properly wearing your seat belt. Air bags can only protect as they are designed if the occupants are properly wearing their seat belts.

Warning!



Never ride in a moving vehicle with the seat backrest in an excessively reclined position as this can be dangerous. You could slide under the seat belt in a collision. If you slide under it, the belt would apply force at the abdomen or neck. That could cause serious or even fatal injuries. The seat backrest and seat belt provide the best restraint when the wearer is in a nearly upright position and the belt is properly positioned on the body.

Warning!



Never let more people ride in the vehicle than there are seat belts available. Be sure everyone riding in the vehicle is correctly restrained with a separate seat belt. Never use a seat belt for more than one person at a time.

Occupant safety

Warning!



Damaged seat belts or belts that were highly stressed in an accident must be replaced and their anchoring points must also be checked.

Only use seat belts which have been approved by Mercedes-Benz.

Do not make any modifications to the seat belts. This can lead to unintended activation of the ETDs or to failure.

Do not bleach or dye seat belts as this may severely weaken them. In a crash they may not be able to provide adequate protection.

Have all work carried out only by qualified technicians. Contact an authorized Mercedes-Benz Center.

Warning!



USE SEAT BELTS PROPERLY

- Seat belts can only work when used properly. Never wear seat belts in any other way than as described in this section, as that could result in serious injuries in case of an accident.
- Each occupant should wear his or her seat belt at all times, because seat belts help reduce the likelihood and potential severity of injuries in accidents, including rollovers. The integrated restraint system includes SRS (driver air bag, passenger air bag, kneebags, head-thorax air bags) and ETD (seat belt emergency tensioning device).

The system is designed to enhance the protection offered to properly belted occupants in certain frontal (front air bags, kneebags, and EDT) and side (head-thorax air bags and EDT) impacts which exceed preset deployment thresholds.

- Never wear the shoulder belt under your arm, against your neck or off your shoulder. In a crash, your body would move too far forward. That would increase the chance of head and neck injuries. The belt would also apply too much force to the ribs or abdomen, which could severely injure internal organs such as your liver or spleen.
- Never wear belts over rigid or breakable objects in or on your clothing, such as eyeglasses, pens, keys, etc., as these might cause injuries.
- Position the lap belt as low as possible on your hips and not across the abdomen. If the belt is positioned across your abdomen, it could cause serious injuries in a crash.
- Never use a seat belt for more than one person at a time. Do not fasten a seat belt around a person and another person or other objects.



Occupant safety

DD

- Belts should not be worn twisted. In a crash, you wouldn't have the full width of the belt to manage impact forces. The twisted belt against your body could cause injuries.
- Pregnant women should also use a lap-shoulder belt. The lap belt portion should be positioned as low as possible on the hips to avoid any possible pressure on the abdomen.
- Never place your feet on the instrument panel, dashboard or on the seat. Always keep both feet on the floor in front of the seat.

Emergency tensioning device (ETD), seat belt force limiter

The seat belts are equipped with emergency tensioning devices (ETDs) and seat belt force limiters.

The ETD is designed to activate in the following cases:

- in frontal or rear-end impacts exceeding a preset severity level.
- if the restraint systems are operational and functioning correctly, see
 sns indicator lamp (> page 64).



The ETDs for the seats will only activate if the respective seat belt is fastened (latch plate properly inserted into buckle).

In an impact emergency tensioning devices remove slack from the belts in such a way that the seat belts fit more snugly against the body. Belt force limiters reduce the force exerted by the seat belts on occupants during a crash.

Warning!



An emergency tensioning device (ETD) that was activated must be replaced.

When scrapping the emergency tensioning device, our safety instructions must be followed. These are available at your authorized Mercedes-Benz Center.

Occupant safety



Do not place objects heavier than 20 lbs (9 kg) on the passenger seat. This could cause the front air bag or head-thorax air bag on the passenger side and, with the seat belt fastened to secure the object, the ETD to deploy in a crash which exceeds the system's deployment threshold.

Children in the vehicle

If an infant or child is traveling with you in the vehicle:

- Secure the child using an infant or child restraint appropriate to the age and size of the child.
- Ensure the infant or child is properly secured at all times while the vehicle is in motion.

Infant and child restraint seats and information on choosing an appropriate restraint system can be obtained from any Mercedes-Benz Center.

Infant and child restraint systems

Use only a BabySmart[™] compatible child restraint for the passenger seat in this vehicle.

We recommend all infants and children be properly restrained at all times while the vehicle is in motion.

The passenger lap-shoulder belt has a special seat belt retractor for secure fastening of child restraints.

To fasten a child restraint, follow child restraint instructions for mounting. Then pull the shoulder belt out completely and let it retract. During seat belt retraction, a ratcheting sound can be heard to indicate that the special seat belt retractor is activated. The belt is now locked. Push down on child restraint to take up any slack.

To deactivate, release seat belt buckle and let seat belt retract completely. The seat belt can again be used in the usual manner.

Occupant safety

Warning!



Never release the seat belt buckle while the vehicle is in motion, since the special seat belt retractor will be deactivated.



The use of infant or child restraints is required by law in all 50 states, the District of Columbia, the U.S. territories and all Canadian provinces.

Infants and small children should be seated in an appropriate infant or child restraint system properly secured by a lap-shoulder belt that complies with U.S. Federal Motor Vehicle Safety Standards 213 and 225 and Canadian Motor Vehicle Safety Standards 213 and 210.2.

A statement by the child restraint manufacturer of compliance with this standard can be found on the instruction label on the restraint and in the instruction manual provided with the restraint.

When using any infant or child restraint system, be sure to carefully read and follow all manufacturer's instructions for installation and use.

Please read and observe warning labels affixed to inside of vehicle and to infant or child restraints.

Warning!



Children 12 years old and under must never ride in this vehicle, except in a Mercedes-Benz authorized BabySmartTM compatible child seat, which operates with the BabySmartTM system installed in the vehicle to deactivate the passenger front air bag when it is properly installed. Otherwise they will be struck by the air bag when it inflates in a crash. If this happens, serious or fatal injury can result.

Infants and small children must be seated in an appropriate BabySmartTM compatible infant or child restraint system, which is properly secured with the vehicle's seat belt, fully in accordance with the child seat manufacturer's instructions.

Infants and small children should never share a seat belt with another occupant. During an accident, they could be crushed between the occupant and seat belt.

Occupant safety

Children too big for child restraint systems should use regular seat belts. Position the shoulder belt across chest and shoulder, not face or neck. A booster seat may be necessary to achieve proper belt positioning for children from 41 lbs until they reach a height where a lap/shoulder belt fits properly without a booster.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and the child is not properly secured in the child restraint.

When the child restraint is not in use, remove it from the vehicle or secure it with the seat belt to prevent the child restraint from becoming a projectile in the event of an accident.

Do not leave children unattended in the vehicle; even if the children are secured in a child restraint system. Unsupervised children in a child restraint system may use vehicle equipment and may cause serious personal injury.

BabySmart[™] air bag deactivation system



1) PASS AIR BAG OFF 💢 indicator lamp

Special BabySmartTM compatible child seats, designed for use with the Mercedes-Benz system and available at any authorized Mercedes-Benz Center are required for use with the BabySmartTM air bag deactivation system. With the special child seat properly installed, the passenger front air bag will not deploy.

The state of the indicator lamp will be illuminated, except with the SmartKey removed or in starter switch position **0**.



The system does not deactivate the head-thorax air bag and the ETD (emergency tensioning device).

Occupant safety

Self-test BabySmart™ without special child seat installed

After turning the SmartKey in the starter switch to position 1 or 2, the indicator lamp comes on for approximately 6 seconds and then goes out.

If the SSAR SSOR IN IT I

For more information, see "Practical hints" (▷ page 367).

Warning!



The BabySmartTM air bag deactivation system will ONLY work with a special child seat designed to operate with it. It will not work with child seats which are not BabySmartTM compatible.

Never place anything between seat cushion and child seat (e.g. pillow), since it reduces the effectiveness of the deactivation system. The bottom of the child seat must make full contact with the passenger seat cushion. An incorrectly mounted child seat could cause injuries to the child in case of an accident, instead of protecting the child.

Follow the manufacturer's instructions for installation of special child seats.

Warning!



When using a BabySmartTM compatible child seat on the passenger seat, the front passenger air bag will not deploy only if the indicator lamp remains illuminated.

Please be sure to check the indicator lamp every time you use the special system child seat. Should the search is indicator lamp go out while the restraint is installed, please check installation. If the search indicator lamp remains out, do not use the BabySmart indicator lamp restraint to transport children on the passenger seat until the system has been repaired.

Occupant safety

Warning!



Do not place powered-on laptops, cell phones, electronic tags such as those used in ski passes, and like electronic devices on the passenger seat. Signals from such devices may interfere with the BabySmartTM system. Such signal interference, for example, may cause the signal interference indicator lamp not to come on during self-test or be continuously lit, indicating that the system is not functioning.

Panic alarm

An audible alarm and flashing exterior lamps will operate for approximately $2^{1}/_{2}$ minutes.



(1) PANIC button



USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.



Canada only:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Activating

► Press and hold button ① for at least 1 second.



Without the antenna on the left rear side of the vehicle installed, the SmartKey signaling range for the panic alarm is considerably reduced. The panic alarm then only functions if the SmartKey is held in close proximity towards the antenna base.

Deactivating

▶ Press button (1) again.

or

Insert the SmartKey in the starter switch.

Driving safety systems

In this section you will find information on the following driving safety systems:

- ABS (<u>A</u>ntilock <u>B</u>rake <u>S</u>ystem)
- · BAS (Brake Assist System)
- ESP® (<u>E</u>lectronic <u>S</u>tability <u>P</u>rogram)



In winter operation, the maximum effectiveness of the ABS, the BAS, and the ESP® is only achieved with winter tires (> page 348), or snow chains as required.

Warning!



The following factors increase the risk of accidents:

- Excessive speed, especially in turns
- Wet and slippery road surfaces
- Following another vehicle too closely

The ABS, BAS, and ESP® cannot reduce this risk.

Always adjust your driving style to the prevailing road and weather conditions.

ABS

Warning!



Do not pump the brake pedal. Use firm, steady brake pedal pressure instead. Pumping the brake pedal defeats the purpose of the ABS and significantly reduces braking effectiveness.

The Antilock Brake System (ABS) regulates the brake pressure so that the wheels do not lock during braking. This allows you to maintain the ability to steer your vehicle.

The ABS is functional above a speed of approximately 5 mph (8 km/h) independent of road surface conditions.

On slippery road surfaces, the ABS will respond even to light brake pressure.

The indicator lamp in the speedometer dial (▷ page 24) comes on when you switch on the ignition. It goes out when the engine is running.

Driving safety systems

Braking

At the instant one of the wheels is about to lock up, a slight pulsation can be felt in the brake pedal, indicating that the ABS is in the regulating mode.

► Keep firm and steady pressure on the brake pedal while experiencing the pulsation.

Continuous, steady brake pedal pressure yields the advantages provided by the ABS, namely braking power and the ability to steer the vehicle.

The pulsating brake pedal can be an indication of hazardous road conditions and functions as a reminder to take extra care while driving.

Emergency brake maneuver

Keep continuous full pressure on the brake pedal.

Warning!



The ABS cannot prevent the natural laws of physics from acting on the vehicle, nor can it increase braking or steering efficiency beyond that afforded by the condition of the vehicle brakes and tires or the traction afforded. The ABS cannot prevent accidents, including those resulting from excessive speed in turns, following another vehicle too closely, or hydroplaning. Only a safe, attentive, and skillful driver can prevent accidents. The capabilities of an ABS equipped vehicle must never be exploited in a reckless or dangerous manner which could jeopardize the user's safety or the safety of others.

For more information, see "Practical Hints" (▷ page 362).

BAS

The Brake Assist System (BAS) operates in emergency situations. If you apply the brakes very quickly, the BAS automatically provides full brake boost, thereby potentially reducing braking distance. Apply continuous full braking pressure until the emergency braking situation is over. The ABS will prevent the wheels from locking.

When you release the brake pedal, the brakes function again as normal. The BAS is then deactivated.

Warning!



If the BAS is malfunctioning, the brake system is still functioning normally, but without the additional brake boost available that BAS would normally provide in an emergency braking maneuver. Therefore, the braking distance may increase.

Driving safety systems

Warning!



The BAS cannot prevent the natural laws of physics from acting on the vehicle, nor can it increase braking efficiency beyond that afforded by the condition of the vehicle brakes and tires or the traction afforded. The BAS cannot prevent accidents, including those resulting from excessive speed in turns, following another vehicle too closely, or hydroplaning. Only a safe, attentive, and skillful driver can prevent accidents. The capabilities of a BAS equipped vehicle must never be exploited in a reckless or dangerous manner which could jeopardize the user's safety or the safety of others.

ESP®

The Electronic Stability Program (ESP®) is operational as soon as the engine is running and monitors the vehicle's traction (force of adhesive friction between the tires and the road surface) and handling.

The ESP® recognizes when a wheel is spinning or if the vehicle starts to skid. By applying brakes to the appropriate wheel and by limiting engine output, the ESP® works to stabilize the vehicle. The ESP® is especially useful while driving off and on wet or slippery road surfaces. The ESP® also stabilizes the vehicle during braking maneuvers.

The ESP® warning lamp in the speed-ometer dial flashes when the ESP® is engaged.

The ESP® warning lamp in the speed-ometer dial comes on when you switch on the ignition. It goes out when the engine is running.

Warning!



Never switch off the ESP® when you see the ESP® warning lamp flashing in the speedometer dial. In this case, proceed as follows:

- While driving off, apply as little throttle as possible.
- While driving, ease up on the accelerator.
- Adapt your speed and driving style to the prevailing road conditions.

Failure to observe these guidelines could cause the vehicle to skid.

The ESP® cannot prevent accidents resulting from excessive speed.

Driving safety systems

Warning!



The ESP® cannot prevent the natural laws of physics from acting on the vehicle, nor can it increase the traction afforded. The ESP® cannot prevent accidents, including those resulting from excessive speed in turns, or hydroplaning. Only a safe, attentive, and skillful driver can prevent accidents. The capabilities of an ESP® equipped vehicle must never be exploited in a reckless or dangerous manner which could jeopardize the user's safety or the safety of others.



The ESP® will only function properly if you use wheels of the recommended tire size (▷ page 439).

!

Because of the ESP®'s automatic operation, the engine must be turned off (SmartKey in starter switch position **0** or **1**) when

- the parking brake is being tested on a brake test dynamometer
- the vehicle is being towed with the front axle raised

Active braking action through the ESP® may otherwise seriously damage the brake system.

For more information, see "Practical Hints" (> page 365).

Switching off the ESP®

Warning!



The ESP® should not be switched off during normal driving other than in the circumstances described below. Disabling of the system will reduce vehicle stability in standard driving maneuvers.

Do not switch off the ESP® when a spare wheel with collapsible tire is mounted.

To improve the vehicle's traction, turn off the ESP® in driving situations where it would be advantageous to have the drive wheels spin and thus cut into surfaces for better grip such as:

- · when driving with snow chains
- in deep snow
- in sand or gravel

Driving safety systems



Turn on the ESP® immediately if the aforementioned circumstances do not apply anymore.

When you switch off the ESP®

- the ESP® does not stabilize the vehicle
- the engine output is not limited, which allows the drive wheels to spin and thus cut into surfaces for a better grip
- the traction control will still brake a spinning wheel
- the ESP® continues to operate when you are braking



When the ESP® is switched off and one or more drive wheels are spinning, the ESP® warning lamp in the speedometer dial flashes. However, the ESP® will then not stabilize the vehicle.

The switch is located on the upper part of the center console.



- 1 ESP® switch (off/on)
- ► With the engine running, press ESP® switch ①.

The ESP® warning lamp in the speedometer dial comes on.

The ESP® is switched off.

Warning!



When the ESP® warning lamp is illuminated continuously, the ESP® is switched off.

Adapt your speed and driving to the prevailing road conditions and to the non-operating status of the ESP[®].



Avoid spinning of a drive wheel for an extended period with the ESP® switched off. This may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.

Switching on the ESP®

► Press ESP® switch ①.

The ESP® warning lamp in the speedometer dial goes out.

You are now again in normal driving mode with the ESP® switched on.

Anti-theft systems

▼ Anti-theft systems

Immobilizer

The immobilizer prevents unauthorized persons from starting your vehicle.

Activating

 Remove the SmartKey from the starter switch.

Deactivating

Switch on the ignition (▷ page 36).



Starting the engine will also deactivate the immobilizer.

In case the engine cannot be started (yet the vehicle's battery is charged), the system is not operational. Contact an authorized Mercedes-Benz Center or call 1-800-FOR-MERCedes (in the USA), or 1-800-387-0100 (in Canada).

Anti-theft alarm system

Once the alarm system has been armed, a visual and audible alarm is triggered when someone opens

- a door
- the trunk lid
- the hood
- the glove box
- the storage compartment in the center console

The alarm system will also be triggered when

- someone attempts to raise the vehicle
- opening the vehicle with the mechanical key
- someone opens a door from the inside
- someone opens the trunk lid with the emergency release button



The alarm will stay on, even if the activating element (e.g. a door) is immediately closed.



If the alarm stays on for more than 30 seconds, a call to the Response Center is initiated automatically by the Tele Aid system (\triangleright page 273), provided Tele Aid service was subscribed to and properly activated, and that necessary cellular service and GPS coverage are available (\triangleright page 273).

Anti-theft systems

Arming the alarm system

► Lock your vehicle with the SmartKey.

The turn signal lamps flash three times to indicate that the alarm system is activated.

The indicator lamp in the central locking switch starts flashing (\triangleright page 102).



If the turn signal lamps do not flash three times, one of the following elements may not be properly closed:

- a door
- the trunk lid
- the fuel filler flap
- the glove box
- the storage compartment under the armrest

Close the respective element and lock the vehicle again.

Disarming the alarm system

Unlock your vehicle with the SmartKey. The turn signal lamps flash once to indicate that the alarm system is disarmed.

Canceling the alarm

To cancel the alarm:

► Press the or button on the SmartKey.

or

Insert the SmartKey in the starter switch.

Tow-away alarm

Once the tow-away alarm is armed, a visual and audible alarm will be triggered when someone attempts to raise the vehicle.



The tow-away protection alarm is triggered, for example, if the vehicle is lifted on one side.

If the alarm stays on for more than 30 seconds, a call to the Response Center is initiated automatically by the Tele Aid system (\triangleright page 273), provided Tele Aid service was subscribed to and properly activated, and that necessary cellular service and GPS coverage are available (\triangleright page 273).

Anti-theft systems

Arming tow-away alarm

► Lock your vehicle with the SmartKey.

The tow-away alarm is automatically armed after about 30 seconds.




When you unlock your vehicle, the tow-away protection disarms automatically. The tow-away alarm remains disarmed until you lock the vehicle again.

Disarming tow-away alarm

To prevent triggering the tow-away alarm, switch off the tow-away alarm feature before towing the vehicle, or when parking on a surface subject to movement, such as a ferry or auto train.

The switch is located on the lower part of the center console.



- 1 Indicator lamp
- ② Tow-away alarm deactivation switch
- ► Switch off the ignition (> page 36).
- Remove the SmartKey from the starter switch.



You cannot disarm the tow-away alarm while the ignition is switched on.

 Press tow-away alarm deactivation switch (2).

Indicator lamp ① in the tow-away alarm deactivation switch comes on briefly.

- ► Exit your vehicle.
- Lock your vehicle with the SmartKey.

The tow-away alarm remains disarmed until you lock your vehicle again.

Canceling tow-away alarm

To cancel the alarm:

► Press the or button on the SmartKey.

or

► Insert the SmartKey in the starter switch.

Locking and unlocking

Seats

Memory function*

Lighting

Instrument cluster

Control system

Manual transmission

Automatic transmission*

Good visibility

Climate control

Automatic climate control*

Audio system

Power windows

Retractable hardtop

Driving systems

Useful features



Locking and unlocking

In the "Controls in detail" section you will find detailed information on how to operate the equipment installed in your vehicle. If you are already familiar with the basic functions of your vehicle, this section will be of particular interest to you.

To quickly familiarize yourself with the basic functions of the vehicle, refer to the "Getting started" section of this manual. The corresponding page numbers are given at the beginning of each segment.

For more information on unlocking and locking, see (\triangleright page 34) and (\triangleright page 59).

SmartKey


Your vehicle comes supplied with two SmartKeys, each with remote control and a removable mechanical key.

The locking tabs for the mechanical key portion of the two SmartKeys are a different color to help distinguish each SmartKey unit.

The SmartKey provides an extended operating range. To prevent theft, however, it is advisable to only unlock the vehicle when you are in close proximity to it.

The SmartKey centrally locks and unlocks:

- the doors
- the trunk lid
- the fuel filler flap
- the glove box
- the storage compartment under the armrest



SmartKey with remote control

- 1) 🔒 Lock button
- (2) Unlock button for the trunk lid
- (3) Mechanical key locking tab
- (4) Unlock button
- (5) Battery check lamp
- 6 PANIC Panic button (▷ page 80)

Locking and unlocking



Opening a door causes the windows on that side of the car to open slightly. They will return to the up position when the door is closed.

!

The side windows will not open or close if the battery is discharged or the windows are covered with ice. As a result, you may no longer be able to properly close the door. Do not attempt to force the door shut. Doing so may damage the door or the side window. Correct the condition that prevents the windows from operating before attempting to close the door.



Without the antenna on the left rear side of the vehicle installed, the SmartKey signaling range is considerably reduced. Hold the SmartKey in close proximity towards the antenna base when locking or unlocking the vehicle.

Warning!



When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. It is possible for children to open a locked door from the inside, which could result in an accident and/or serious injury.



To prevent possible malfunction, avoid exposing the SmartKey to high levels of electromagnetic radiation.

Locking and unlocking



USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.



Canada only:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

Any unauthorized modification to this device could void the user's authority to operate the equipment.



You can also open and close the retractable hardtop using the SmartKey* (▷ page 257).

Factory setting

Global unlocking

Press button

All turn signal lamps flash once. The locking knobs on the doors move up. The anti-theft alarm system is disarmed (\triangleright page 87).

The vehicle will lock again automatically and reactivate the anti-theft alarm system within approximately 40 seconds of unlocking if:

- neither door nor trunk is opened
- the SmartKey is not inserted in the starter switch
- the central locking switch is not activated

Locking and unlocking

Global locking

▶ Press button <a>□.

With the trunk and all doors closed, all turn signal lamps flash three times. The locking knobs on the doors move down.

The anti-theft alarm system is armed now (\triangleright page 87).



If the turn signal lamps do not flash three times, one of the following elements may not be properly closed:

- a door
- · the trunk lid
- the fuel filler flap
- the glove box
- the storage compartment under the armrest

Close the respective element and lock the vehicle again.

Selective setting

If you frequently travel alone, you may wish to reprogram the SmartKey so that pressing button only unlocks the driver's door, the storage compartment under the armrest, the glove box, and the fuel filler flap.

► Press and hold buttons of and simultaneously for about 6 seconds.

Battery check lamp 5 flashes twice.

The SmartKey will then function as follows:

Unlocking driver's door and fuel filler flap

▶ Press button once.

All turn signal lamps flash once. The locking knob on the driver's door move up. The anti-theft alarm system is disarmed (▷ page 87).

Global unlocking

▶ Press button twice.

All turn signal lamps flash once. The locking knobs on the doors move up. The anti-theft alarm system is disarmed (\triangleright page 87).

Global locking

Press button
?

With the trunk and all doors closed, all turn signal lamps flash three times. The locking knobs on the doors move down.

The anti-theft alarm system is armed now (\triangleright page 87).

Locking and unlocking

Restoring to factory setting

Press and hold buttons and simultaneously for about 6 seconds.
 Battery check lamp (5) flashes twice.
 The SmartKey is set to the factory setting again.



If you can no longer lock or unlock the vehicle with the SmartKey, then the batteries in the SmartKey are discharged, the SmartKey is malfunctioning, or the vehicle battery is drained.

- Check the batteries in the SmartKey and replace them if necessary (> page 398).
- Use the mechanical key to lock/unlock the driver's door (> page 394).
- Use the mechanical key to lock/unlock the trunk lid as required (> page 395).
- Have the vehicle battery and the battery connections checked (▷ page 421).

If the SmartKey is malfunctioning, contact an authorized Mercedes-Benz Center.

Unlocking the trunk lid

You can unlock and open the trunk lid separately.

► Press and hold button on the SmartKey until the trunk lid unlocks.

the trunk" (\triangleright page 98).

For opening the trunk, see "Opening



The trunk lid can only be opened when the vehicle is not in motion and the retractable hardtop is fully opened or closed.

Locking and unlocking

Checking the batteries

Press button or .

Battery check lamp (5) comes on briefly to indicate that the SmartKey batteries are in order.



If battery check lamp (5) does not come on briefly during check, then the SmartKey batteries are discharged.

Replace the batteries (▷ page 398).

You can obtain the required batteries at any authorized Mercedes-Benz Center.



If the batteries are checked within signal range of the vehicle, pressing button or will lock or unlock the vehicle accordingly.

Loss of SmartKey or mechanical key


If you lose a SmartKey or mechanical key, you should do the following:

- ► Have the SmartKey deactivated by an authorized Mercedes-Benz Center.
- ► Report the loss of the SmartKey or the mechanical key to your car insurance company immediately.
- ► If necessary have the mechanical lock replaced.

Your authorized Mercedes-Benz Center will be glad to supply you with a replacement.

Opening the doors from the inside

You can open a locked door from the inside. Open door only when conditions are safe to do so.



- 1) Inside door handle
- 2 Locking knob
- ▶ Pull on door handle ① of the desired door.

If the door was locked, locking knob ② will move up.

Locking and unlocking

 $\triangleright \triangleright$



If the vehicle has previously been centrally locked with the SmartKey, opening a door from the inside will trigger the anti-theft alarm system.

To cancel the alarm, do one of the following:

- Press button or on the SmartKey.
- Insert the SmartKey in the starter switch.



Opening a door causes the windows on that side of the car to open slightly. They will return to the up position when the door is closed.



The side windows will not open or close if the battery is discharged or the windows are covered with ice. As a result, you may no longer be able to properly close the door. Do not attempt to force the door shut. Doing so may damage the door or the side window. Correct the condition that prevents the windows from operating before attempting to close the door.

Opening the trunk

A minimum height clearance of 5.78 ft (1.76 m) is required to open the trunk lid.

The handle is located above the rear license plate recess.

- ▶ Pull on the handle.
- ▶ Lift the trunk lid.



When the trunk lid is lifted slightly, it swings open upwards automatically. Always make sure there is sufficient overhead clearance.

Locking and unlocking



The vehicle or trunk lid must be unlocked before the trunk lid can be opened.

The trunk lid can only be opened when the vehicle is not in motion and the retractable hardtop is fully opened or closed.

The trunk lid can also be opened from its inside in an emergency, see "Trunk lid emergency release" (> page 100).

Closing the trunk



1 Handle

- ► Lower the trunk lid using handle ①.
- Close the trunk lid with hands placed flat on the trunk lid.

Warning!



To prevent possible personal injury, always keep hands and fingers away from the trunk lid opening when closing the trunk lid. Be especially careful when small children are around.

Warning!



When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. It is possible for children to open a locked door from the inside, which could result in an accident and/or serious injury.

Locking and unlocking

Warning!



Only drive with the trunk lid closed as, among other dangers such as blocked visibility, exhaust fumes may enter the vehicle interior.



Do not place the SmartKey in the open trunk. You may lock yourself out.




If the vehicle was previously centrally locked, the trunk lid will lock automatically when closed. The turn signal lamps will flash three times to confirm locking.

Trunk lid emergency release

The emergency release button is located on the inside of the trunk lid.

With the emergency release button, the trunk can be opened from inside the trunk.



- (1) Emergency release button
- Briefly press emergency release button (1).

The trunk lid unlocks and opens slightly.

Push up the trunk lid to fully open.



The emergency release button unlocks the trunk while the vehicle is standing still or in motion.

Illumination of the emergency release button:

- The button flashes for 30 minutes after opening the trunk.
- The button flashes for 60 minutes after closing the trunk.



The emergency release button does not unlock the trunk if the vehicle battery is discharged or disconnected.

Locking and unlocking



If the vehicle has previously been centrally locked with the SmartKey, opening the trunk from the inside will trigger the anti-theft alarm system.

To cancel the alarm, do one of the following:

- Press button or on the SmartKey.
- Insert the SmartKey in the starter switch.

Automatic central locking

The doors and the trunk automatically lock when the ignition is switched on and the wheels are turning at vehicle speeds of approximately 9 mph (15 km/h).

You can open a locked door from the inside. Open door only when conditions are safe to do so.



The doors unlock automatically after an accident if the force of the impact exceeds a preset threshold.

To prevent the vehicle door locks from locking, deactivate the automatic central locking when the vehicle

- is pushed or towed
- is on a test stand

You can deactivate the automatic locking using the control system, see "Setting automatic locking" (> page 147).

Locking and unlocking

Locking and unlocking from the inside

You can lock or unlock the doors and the trunk from inside using the central locking switch. This can be useful, for example, if you want to lock the vehicle before starting to drive.

The fuel filler flap will not be locked or unlocked with the central locking or unlocking switch, respectively.

Warning!



When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause an accident and/or serious personal injury.

The switches are located on the upper part of the center console.



- 1 Central locking switch
- 2 Central unlocking switch

Locking and unlocking



You can open a locked door from the inside. Open door only when conditions are safe to do so.

If the vehicle was previously centrally locked using the SmartKey, it will not unlock using the central unlocking switch (2).

If the vehicle was previously locked with the central locking switch ①

- while in the selective remote control mode, only the door opened from inside is unlocked.
- while in the global remote control mode, the vehicle is unlocked completely when a door is opened from the inside.

Locking

▶ Press central locking switch ①.
If all doors are closed, the vehicle locks.

Unlocking

Press central unlocking switch ②.
 The vehicle unlocks.

Seats

For information on seat adjustment, see "Adjusting" (▷ page 38).

Seat heating*

The switches are located on the upper part of the center console.



- (1) Seat heating switch (driver's side)
- 2 Indicator lamps

Red indicator lamps ② on the seat heating switch show which heating level you have selected:

Level	
3	Three indicator lamps on (highest level).
	After approximately 5 minutes, seat heating is automatically switched to level 2.
2	Two indicator lamps on.
	After approximately 10 minutes, seat heating is automatically switched to level 1.
1	One indicator lamp on (lowest level).
	After approximately 20 minutes, seat heating is automatically switched to off.
off	No indicator lamp on.

➤ Switch on the ignition (> page 36).

Switching on seat heating

- Press the desired seat heating switch.
 Three red indicator lamps ② on the respective seat heating switch come on.
- ► Press the seat heating switch repeatedly until the desired seat heating level is reached.

Seats

Switching off seat heating

 Press the desired seat heating switch repeatedly until all indicator lamps (2) on the seat heating switch go out.



If one or more of indicator lamps ② on the seat heating switch are flashing, there is insufficient voltage available since too many electrical consumers are turned on. The seat heating switches off automatically.

The seat heating will switch back on again automatically as soon as sufficient voltage is available.

AIRSCARF neck-level heating*

The AIRSCARF neck-level heating provides the area surrounding the occupants' necks with a heated air stream flowing from openings in the head restraints.

The switches are located on the upper part of the center console.



- 1) AIRSCARF switch (driver's side shown)
- ② Indicator lamps

Warning!



When switching on the AIRSCARF neck-level heating, the air streaming from the openings may be very hot. When in close proximity to the openings, you could be seriously burned. To help avoid serious personal injuries, switch the AIRSCARF to a lower heating level.

Seats

Red indicator lamps ② on the AIRSCARF switches show which heating level you have selected:

Level	
3	Three indicator lamps on (highest heating level).
2	Two indicator lamps on.
1	One indicator lamp on (lowest heating level).
off	No indicator lamp on.

Switch on the ignition (▷ page 36).

Switching on

Press the respective AIRSCARF switch for the desired side.

All three indicator lamps on the respective AIRSCARF switch come on. After a preheating time of approximately 7 seconds, the blower starts.

 Press the respective AIRSCARF switch repeatedly until the desired AIRSCARF heating level for the corresponding seat is reached.

Switching off

► Press the respective AIRSCARF switch repeatedly until all indicator lamps on the AIRSCARF switch go out.



After switching off the AIRSCARF neck-level heating, the AIRSCARF fan continues to operate for approximately 10 seconds to cool down the heater elements.



If one or more of indicator lamps ② on the AIRSCARF switch are flashing, there is insufficient voltage available since too many electrical consumers are turned on. The AIRSCARF neck-level heating switches off automatically.

The AIRSCARF neck-level heating will switch back on again automatically as soon as sufficient voltage is available.

Memory function*

▼ Memory function*

Prior to operating the vehicle, the driver should check and adjust the seat height, seat position fore and aft, and seat backrest angle if necessary, to ensure adequate control, reach and comfort. The head restraint should also be adjusted for proper height. See also the section on air bags for proper seat positioning (>> page 65).

In addition, adjust the steering wheel to ensure adequate control, reach, operation and comfort. Both the interior and exterior rear view mirrors should be adjusted for adequate rear vision.

Fasten seat belts. Infants and small children should be seated in a properly secured restraint system that complies with U.S. Federal Motor Vehicle Safety Standards 213 and 255 and Canadian Motor Vehicle Safety Standards 213 and 210.2.

The following settings are stored when using the buttons on the outer side of the respective seat:

Driver and passenger seat:

Seat and backrest position

Driver only:

- Steering wheel position
- Exterior rear view mirrors

Warning!



Do not activate the memory function while driving. Activating the memory function while driving could cause the driver to lose control of the vehicle.

The memory button and memory position switch are located on the outer side of each seat.



- (1) Memory button M
- ② Memory position switch
- ► Switch on the ignition (> page 36).

or

Open the respective door.

Memory function*

Storing positions into memory

- ► Adjust the seat, on the driver's side also the steering wheel and exterior rear view mirrors, to the desired positions (▷ page 38).
- ► Press memory button **M** ①.
- ▶ Release memory button M ① and press a memory position switch ② within 3 seconds.

All settings are stored to the selected position.

Recalling positions from memory



Do not operate the power seats using the memory position switches if the seat backrest is in an excessively reclined position. Doing so could cause damage to the seats.

Press and hold desired memory position switch ② until the seat, on the driver's side also the steering wheel and exterior rear view mirrors, have completely moved to the stored positions.



Releasing the memory position switches immediately stops movement to the stored positions.

Storing exterior rear view mirror parking position (parking aid)


For easier parking, you can adjust the passenger-side exterior rear view mirror so that you can see the right rear wheel as soon as you engage reverse gear **R**.

You can switch the parking position feature on and off via the control system (> page 148).

For information on activating the parking position feature, see "Activating exterior rear view mirror parking position*" (> page 175).

Memory function*

The switches are located on the lower part of the center console.



- 1 Driver's side exterior rear view mirror switch
- (2) Adjustment switch
- ③ Passenger-side exterior rear view mirror switch

- ► Switch on the ignition (> page 36).
- ► Press switch ③ to select the passenger-side exterior rear view mirror.
- ► Adjust the passenger-side exterior rear view mirror with adjustment switch ② so that you see the rear wheel and the road curb.
- ▶ Press memory button **M** (> page 107).
- Within 3 seconds, press adjustment switch (2) forward, backward, left, or right.

The parking position is stored if the mirror does not move.



If the mirror does move, repeat the above steps. After the setting is stored, you can move the mirror again.

Lighting

For information on how to switch on the headlamps and use the turn signals, see "Switching on headlamps" (▷ page 55) and "Turn signals" (▷ page 55).



If you drive in countries where vehicles drive on the other side of the road than the country in which the vehicle is registered, you must have the headlamps modified for symmetrical low beams. Relevant information can be obtained at your authorized Mercedes-Benz Center.

Exterior lamp switch

The exterior lamp switch is located on the dashboard to the left of the steering wheel.



Exterior lamp switch

- OffDaytime running lamp mode(▷ page 112)
- Automatic headlamp mode
 Daytime running lamp mode
 (▷ page 112)
- Parking lamps (also tail lamps, license plate lamps, side marker lamps, instrument panel lamps)
- Low beam headlamps (or high beam headlamps when the combination switch is pushed forward) and parking lamps
- Standing lamps, right (turn left one stop)
- **→P** Standing lamps, left (turn left two stops)
- Indicator lamp for parking lamps
- Indicator lamp for front fog lamps
- 0\$ Indicator lamp for rear fog lamp



With the SmartKey removed from the starter switch and the driver's door open, a warning sounds if the parking lamps or low beam headlamps are switched on.

The message Turn off lights appears in the multifunction display.

Manual headlamp mode

The low beam headlamps and the parking lamps can be switched on and off with the exterior lamp switch.

Automatic headlamp mode

The following lamps switch on and off automatically depending on the brightness of the ambient light:

- Low beam headlamps
- Tail and parking lamps
- License plate lamps
- Side marker lamps

Warning!



If the exterior lamp switch is set to AUTO

- the headlamps may switch off unexpectedly when the system senses bright ambient light, for example light from oncoming traffic.
- the headlamps will not be automatically switched on under foggy conditions.

To minimize risk to you and to others, activate headlamps by turning exterior lamp switch to when driving or when traffic and/or ambient lighting conditions require you to do so.

In low ambient lighting conditions, only switch from position AUTO to With the vehicle at a standstill in a safe location.

Switching from AUTO to Will briefly switch off the headlamps. Doing so while driving in low ambient lighting conditions may result in an accident.

The automatic headlamp feature is only an aid to the driver. The driver is responsible for the operation of the vehicle's lights at all times.

Turn the exterior lamp switch to position AUTO.

With the SmartKey in starter switch position 1 only the parking lamps will switch on and off automatically.

When the engine is running, the low beam headlamps, the tail and parking lamps, the license plate lamps, and the side marker lamps will switch on and off automatically.

Daytime running lamp mode

Turn exterior lamp switch to position o or AUTO.

When the engine is running, the low beam headlamps are switched on.

In low ambient light conditions, the following lamps will switch on additionally:

- Tail and parking lamps
- License plate lamps
- Side marker lamps

For nighttime driving you should turn the exterior lamp switch to position to permit activation of the high beam head-lamps.



With the daytime running lamp mode and the exterior lamp switch in position oyou cannot switch on the high beam headlamps.

The high beam flasher is available at all times.

Canada only:

The daytime running lamp mode is mandatory and therefore in a constant mode.

Vehicles with automatic transmission*: When the engine is running, and you shift from a driving position to position **N** or **P**, the low beam headlamps will switch off with a three-minute delay.

When the engine is running, and you

- turn the exterior lamp switch to position [300], the parking lamps switch on additionally.
- turn the exterior lamp switch to position , the manual headlamp mode has priority over the daytime running lamp mode.

The corresponding exterior lamps switch on (> page 110).

USA only:

By default, the daytime running lamp mode is deactivated. Activate the daytime running lamp mode using the control system, see "Setting daytime running lamp mode" (> page 143).

When the engine is running, and you turn the exterior lamp switch to position or or the manual head-lamp mode has priority over the daytime running lamp mode.

The corresponding exterior lamps switch on (\triangleright page 110).

Locator lighting and night security illumination

The locator lighting and the night security illumination are described in the "Control system" section, see (\triangleright page 144) and (\triangleright page 145).

Fog lamps

Warning!



In low ambient lighting or foggy conditions, only switch from position Auto to D with the vehicle at a standstill in a safe location. Switching from Auto to Will briefly switch off the headlamps. Doing so while driving in low ambient lighting conditions may result in an accident.



Fog lamps will operate with the parking lamps and/or low beam headlamps on. Fog lamps should only be used in conjunction with low beam headlamps. Consult your State or Province Motor Vehicle Regulations regarding allowable lamp operation.



Fog lamps cannot be switched on with the exterior lamp switch in position AUTO. To switch on the fog lamps, turn the exterior lamp switch to position First.

Lighting

Front fog lamps

Switch on the low beam headlamps (▷ page 110).



With the exterior lamp switch in the low beam headlamp position, pull out the exterior lamp switch to first stop.

The front fog lamps switch on.

The green indicator lamp

in the exterior lamp switch comes on (⊳ page 110).

▶ Push in the exterior lamp switch.

The front fog lamps switch off.

The green indicator lamp in the exterior lamp switch goes out.

Rear fog lamp (driver's side only)

- Switch on the front fog lamps (> page 114).
- Pull out the exterior lamp switch to second stop.

The rear fog lamp switches on.

The yellow indicator lamp 0 in the exterior lamp switch comes on (⊳ page 110).

Push in the exterior lamp switch to first stop.

The rear fog lamp switches off.

The yellow indicator lamp 0\$\frac{1}{2}\$ in the exterior lamp switch goes out.

The front fog lamps remain lit.

Combination switch

The combination switch is located on the left of the steering column.



- 1 High beam
- 2 High beam flasher

High beam

- ► Turn the exterior lamp switch to position or AUTO (> page 110).
- Push the combination switch in direction of arrow 1 to switch on the high beam.

The high beam headlamp indicator lamp ☐ in the instrument cluster comes on (▷ page 24).

 Pull the combination switch in direction of arrow ② to its original position to switch off the high beam.

The high beam headlamp indicator lamp in the instrument cluster goes out.

High beam flasher

▶ Pull the combination switch briefly in direction of arrow ②.

Corner-illuminating front fog lamps* (SLK 280, SLK 350: with Bi-Xenon* headlamps and without Sport Package*)

The corner-illuminating front fog lamps improve illumination of the road onto which you are turning.

The corner-illuminating front fog lamps will operate with the engine running and with

- the exterior lamp switch in position AUTO (▷ page 110) or
- the daytime running lamp mode activated (> page 112)



Corner-illuminating front fog lamps will only come on in low ambient lighting conditions.

The corner-illuminating front fog lamps function is not available at a vehicle speed above 25 mph (40 km/h).

Driving forward

Switching on corner-illuminating front fog lamps

▶ Depending on whether you are turning left or right, switch on the left or right turn signal (> page 55).

The respective front fog lamp comes on and illuminates the road onto which you are turning.

 $\triangleright \triangleright$



The respective corner-illuminating front fog lamp will stay lit until you switch off the turn signal, even if the steering wheel is in the straight-ahead position.

The respective corner-illuminating front fog lamp may stay on for a brief period after the turn signal is switched off.

The respective corner-illuminating front fog lamp stays on for a maximum of 3 minutes. After that period, it will go out even if the turn signal is still on.



The corner-illuminating front fog lamps will come on automatically depending on the steering angle, even if you did not switch on either turn signal. If the corner-illuminating front fog lamps came on automatically, they will also go out automatically depending on the steering angle.

Switching off corner-illuminating front fog lamps

The combination switch for the turn signal resets automatically after major steering wheel movements. This will switch off the corner-illuminating front fog lamps if they where activated by switching on the left or right turn signal.

If the turn signal should stay on after making the turn, the turn signal and corner-illuminating front fog lamp can be switched off by returning the combination switch to its original position.

Driving rearward

Switching on corner-illuminating front fog lamps

► Place the gearshift lever (gear selector lever*) in position **R**.

The inverse front fog lamp comes on automatically depending on the steering direction and steering angle.

Switching off corner-illuminating front fog lamps

► Place the gearshift lever (gear selector lever*) out of position **R**.

The respective front fog lamp goes out.

Hazard warning flasher

The hazard warning flasher can be switched on at all times, even with the SmartKey removed from the starter switch.

The hazard warning flasher switches on automatically when an air bag deploys.

The hazard warning flasher switch is located on the upper part of the center console.



1 Hazard warning flasher switch

Switching on hazard warning flasher

 Press hazard warning flasher switch (1).

All turn signal lamps are flashing.



With the hazard warning flasher activated and the combination switch set for either left or right turn, only the respective turn signals will operate when the SmartKey is in the starter switch position 1 or 2.

Switching off hazard warning flasher


Press hazard warning flasher switch 1 again.



If the hazard warning flasher has been activated automatically, press hazard warning flasher switch (1) once to switch it off.

Interior lighting

The controls are located in the overhead control panel.



- (1) Interior lighting on/off
- ② Automatic control on/off
- 3 Right reading lamp on/off
- 4 Left reading lamp on/off



Leaving an interior light switch in the ON position for extended periods of time with the engine turned off could result in a discharged battery.

Automatic control

Activating

 Press automatic control switch ② until it is flush to the other switches.

The interior lighting switches on in darkness, when you

- unlock the vehicle
- remove the SmartKey from the starter switch
- open a door

The interior lighting switches off automatically following a preset time delay.

For more information, see "Interior lighting delayed shut-off" (▷ page 146).



If the door remains open, the interior lighting switches off automatically after approximately 5 minutes when the SmartKey is in starter switch position **0** or removed.

Deactivating

 Press automatic control switch ② until it engages at a deeper position than the other switches.

The interior lighting remains switched off in darkness, even when you

- unlock the vehicle
- remove the SmartKey from the starter switch
- open a door



When you open the trunk, the trunk lighting switches on automatically.

If the trunk lid remains open, the trunk lighting switches off automatically after approximately 10 minutes.

Manual control

Interior lighting

- Press interior lighting switch ①.The interior lighting switches on.
- Press interior lighting switch ① again.
 The interior lighting switches off.



The footwell lighting* is switched on and off simultaneously with the manual control.

Reading lamps

The standard reading lamps are located to the left and right of the overhead control panel. Reading lamps as part of the interior lighting package* are located on the lower edge of the interior rear view mirror.

- ► Press reading lamp switch ③ or ④ to switch on the desired reading lamp.
- Press reading lamp switch ③ or ④ again to switch off the respective reading lamp.

Door entry lamps

For better orientation in the dark, the corresponding door entry lamps will switch on in darkness when you open a door and the automatic control is activated.

The door entry lamps switch off when the corresponding door is closed.



If you turn the SmartKey in the starter switch to position **0** and switch off the exterior headlamps, the door entry lamps will remain lit for approximately 5 minutes.

Instrument cluster

A full view illustration of the instrument cluster can be found in the "At a glance" section (▷ page 24).

The multifunction display in the instrument cluster is activated when you

- open a door
- · switch on exterior lighting
- switch on ignition (▷ page 36)
- press reset button
 (▷ page 24)



Opening a door or pressing the reset button **(R)** without switching on the ignition or the exterior lighting activates the multifunction display illumination only for 30 seconds.

For information on changing the instrument cluster settings, e.g. the language, see "Instrument cluster submenu" (> page 137).

Instrument cluster illumination

Adjusting

The knobs for adjusting the instrument cluster illumination are on the left side of the instrument cluster (▷ page 24).



- (1) Brightening illumination (knob +)
- 2 Dimming illumination (knob -)
- 3 Reset button



The instrument cluster illumination automatically adjusts to the ambient light.

You can only adjust the brightness of the instrument cluster illumination when it is dark outside.



With the exterior lighting switched on, the brightness of the switches in the center console will be adjusted when using knob + or -.

Brightening illumination

Press knob + briefly.

The instrument cluster illumination brightens.

Dimming illumination

Press knob - briefly.

The instrument cluster illumination dims.

Instrument cluster

Tachometer

The red marking on the tachometer (▷ page 24) denotes excessive engine speed.



Avoid driving at excessive engine speeds, as it may result in serious engine damage that is not covered by the Mercedes-Benz Limited Warranty.

To help protect the engine, the fuel supply is interrupted if the engine is operated within the red marking.

Outside temperature indicator

Warning!



The outside temperature indicator is not designed to serve as an ice-warning device and is therefore unsuitable for that purpose.

Indicated temperatures just above the freezing point do not guarantee that the road surface is free of ice. The road may still be icy, especially in wooded areas or on bridges.

The outside temperature is displayed in the multifunction display (\triangleright page 129).

The temperature sensor is located in the front bumper area. Due to its location, the sensor can be affected by road or engine heat during idling or slow driving. Therefore, the accuracy of the displayed temperature can only be verified by comparison to a thermometer placed next the sensor, not by comparison to external displays, e.g. bank signs, etc.

When moving the vehicle into colder ambient temperatures (e.g. when leaving your garage), you will notice a delay before the lower temperature is displayed.

A delay also occurs when ambient temperatures rise. This prevents inaccurate temperature displays caused by heat radiated from the engine during idling or slow driving.

Instrument cluster

Trip odometer

- Make sure you are viewing the standard display menu (▷ page 128).
- ▶ Press and hold reset button **(B)** until the trip odometer is reset.

Clock

Vehicles with COMAND*:

The clock in the instrument cluster can be synchronized with the time set in COMAND using the time synchronization with head unit feature (\triangleright page 139), or set independently from COMAND using the control system (\triangleright page 139) with the time synchronization with head unit feature set to 0ff.

For setting the time in COMAND, see separate COMAND operating instructions.

For setting the time with audio system, $(\triangleright page 139)$.

▼ Control system

The control system is activated as soon as the SmartKey in the starter switch is turned to position 1. The control system enables you to

- call up information about your vehicle
- change vehicle settings

For example, you can use the control system to find out when your vehicle is next due for service, to set the language for messages in the instrument cluster display, and much more.



The displays for the audio systems (radio, CD player) will appear in English, regardless of the language selected.

Warning!




A driver's attention to the road and traffic conditions must always be his/her primary focus when driving.

For your safety and the safety of others, selecting features through the multifunction steering wheel should only be done by the driver when traffic and road conditions permit it to be done safely.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

The control system relays information to the multifunction display.

Multifunction display




- 1 Main odometer
- 2 Trip odometer
- ③ Current program mode (automatic transmission* only)
- 4 Status indicator (outside temperature/digital speedometer)
- (5) Current gear selector lever position/gear range (automatic transmission* only)

Control system

Multifunction steering wheel

The displays in the multifunction display and the settings in the control system are controlled by the buttons on the multifunction steering wheel.



Multifunction display

Operating the control system

2 Selecting the submenu or setting the volume:

Press button

- + up/to increase
- down/to decrease
- Telephone*:
 Press button
 - to take a call, or
 - to end a call, or to reject an incoming call
- 4 Moving within a menu: Press button
 - for next display
 - for previous display
- Menu systems: Press button
 - for next menu
 - for previous menu

Pressing any of the buttons on the multifunction steering wheel will alter what is shown in the multifunction display.

The information available in the multifunction display are arranged in menus, each containing a number of functions or submenus.

The individual functions are then found within the relevant menu (radio or CD operations under Audio, for example). These functions serve to call up relevant information or to customize the settings for your vehicle.

It is helpful to think of the menus, and the functions within each menu, as being arranged in a circular pattern.

- If you press button or repeatedly, you will pass through each menu one after the other.
- If you press button or repeatedly, you will pass through each function display, one after the other, in the current menu.

Control system

In the Settings... menu, you will find a number of submenus instead of functions for calling up and changing settings. For instructions on using these submenus, see "Settings menu" (> page 134).

The number of menus available in the system depends on which optional equipment is installed in your vehicle.



The headings used in the menus table are designed to facilitate navigation within the system and are not necessarily identical to those shown in the control system displays.

The first function displayed in each menu will automatically show you which part of the system you are in.




SLK 55 AMG:

The steering wheel in this vehicle will vary from steering wheel shown. However, multifunction steering wheel symbols and feature description apply to AMG vehicles as well.

Menus

This is what you will see when you scroll through the menus.

The table below provides an overview of the individual menus.



Menus, submenus and functions


	Menu ①	Menu ②	Menu ③	Menu ④	Menu (5)	Menu ⑥	Menu ⑦
	Standard display	AUDIO	NAV*	Vehicle status message memory ¹	Settings	Trip computer	TEL*
	(⊳ page 128)	(⊳ page 129)	(⊳ page 132)	(⊳ page 132)	(⊳ page 134)	(⊳ page 149)	(⊳ page 151)
Commands/submenus	Run Flat Indicator*	Select radio station	Show route guidance instructions,	Call up vehicle malfunction, warning and	Reset to factory settings	Fuel consumption statistics after start	Load phone book
	Check coolant temperature	Select satellite radio station* (USA only)	current direction traveled	system status messages stored in	Instrument cluster submenu	Fuel consumption statistics since last reset	Search for name in phone book
		Operate the CD player		memory	Time/Date submenu	Call up range	Redialing
	Call up mainte- nance service indicator				Lighting submenu		
	Check engine oil level (SLK 55 AMG only)				Vehicle submenu Convenience submenu		

 $^{^{1}\,}$ The vehicle status message memory menu is only displayed if there is a message stored.

Control system

Standard display menu

The multifunction display shows the main odometer and trip odometer. This default setting is referred to as the standard display.



- 1 Main odometer
- 2 Trip odometer

If another display is shown instead of the standard display:


- ► Press button or repeatedly until you see the standard display.
- Press button or to select the functions in the standard display menu.

The following functions are available:

Function	Page
Run Flat Indicator*	329
Checking coolant temperature	128
Display digital speedometer or outside temperature	129
Calling up maintenance service indicator	350
Checking engine oil level (SLK 55 AMG only)	309

Checking coolant temperature

► When in the standard display menu, press button or repeatedly until you see the coolant temperature in the multifunction display.



During severe operating conditions, e.g. stop-and-go city traffic, the coolant temperature may rise close to 248°F (120°C).

The engine should not be operated with a coolant temperature above 248°F (120°C). Doing so may cause serious engine damage which is not covered by the Mercedes-Benz Limited Warranty.



Excessive coolant temperature triggers a warning message in the multifunction display (> page 376).

Warning!




- Driving when your engine is overheated can cause some fluids which may have leaked into the engine compartment to catch fire. You could be seriously burned.
- Steam from an overheated engine can cause serious burns and can occur just by opening the hood. Stay away from the engine if you see or hear steam coming from it.

Turn off the engine, get out of the car and do not stand near the vehicle until the engine has cooled down.

Displaying digital speedometer or outside temperature

Press button or repeatedly until you see the digital speedometer.
 The current vehicle speed is shown in the multifunction display.





You can select either the display of the digital speedometer or the outside temperature indicator (▷ page 138).

AUDIO menu

The functions in the AUDIO menu operate the audio equipment which you currently have turned on.

If no audio equipment is currently switched on, the message AUDIO off is shown in the multifunction display.

The following functions are available:

Function	Page
Selecting radio station	130
Selecting satellite radio station* (USA only)	130
Operating the CD player	131

Control system

Selecting radio station

- ➤ Switch on the radio (▷ page 209).

 Vehicles with COMAND*:

 Refer to the separate operating instructions.
- ► Press button or repeatedly until you see the currently tuned station in the multifunction display.



- 1 Waveband setting
- (2) Tuned station
- ► Press button or repeatedly until the desired station is found.



You can only store new stations using the corresponding feature on the radio (⊳ page 212).

Vehicles with COMAND*: Refer to the separate operating instructions.

Selecting satellite radio station* (USA only)

The Sirius satellite radio is treated as a radio application.

 Select satellite radio with the corresponding soft key (SAT) in the radio menu.



- (1) SAT mode and preset number
- (2) Channel name or number
- ▶ Press button or repeatedly until the desired channel is found.



For more information on satellite radio operation, see "Introduction to satellite radio* (USA only)" (> page 214).

Vehicles with COMAND*: Refer to separate operating instructions.

Operating the CD player

➤ Switch on the radio and select the CD player (> page 222).

Vehicles with COMAND*: Refer to the separate operating instructions.

Press button or repeatedly until the settings for the CD currently being played are shown in the multifunction display.



- ① Current CD (CDO for single CD drive in head unit, CD1 through CD6 for CD in CD changer*)
- 2 Current track

► Press button or repeatedly until the desired track is selected.



To select a CD from the magazine, press a number on the audio system or the COMAND* system key pad located in the center dashboard.

Control system

NAV* menu

The NAV menu contains the functions needed to operate your navigation system.

- Press button or repeatedly until you see the message NAV in the multifunction display.
 - If the COMAND system is switched off, the message NAV off is shown in the multifunction display.
 - With COMAND switched on but route guidance not activated, the direction of travel and, if available, the name of the street currently traveled on appear in the multifunction display.

 With COMAND switched on and route guidance activated, the direction of travel and maneuver instructions appear in the multifunction display.

Please refer to the COMAND* manual for instructions on how to activate the route guidance system.

Vehicle status message memory menu

Use the vehicle status message memory menu to scan malfunction and warning messages that may be stored in the system. Such messages appear in the multifunction display and are based on conditions or system status the vehicle's system has recorded.

The vehicle status message memory menu only appears if there are any messages stored in the system.

Warning!



Malfunction and warning messages are only indicated for certain systems and are intentionally not very detailed. The malfunction and warning messages are simply a reminder with respect to the operation of certain systems and do not replace the owner's and/or driver's responsibility to maintain the vehicle's operating safety by having all required maintenance and safety checks performed on the vehicle and by bringing the vehicle to an authorized Mercedes-Benz Center to address the malfunction and warning messages (> page 368).

Press button or repeatedly until the vehicle status message memory appears in the multifunction display.

If the vehicle status message memory menu does not appear, then there are no messages stored.

Vehicle status messages have been recorded

If conditions have occurred causing status messages to be recorded, the number of messages appears in the multifunction display:



- 1 Number of messages
- ► Press button 🗘 or 💎

The stored messages will now be displayed in the order in which they have occurred. For malfunction and warning messages, see "Vehicle status messages in the multifunction display" (▷ page 368).

Should the vehicle's system record any conditions while driving, the number of messages will reappear in the multifunction display when the SmartKey in the starter switch is turned to position **0** or removed from the starter switch:

► Press button **(B)** repeatedly until you have seen all occurred messages.



The vehicle status message memory will be cleared when you turn the SmartKey in the starter switch to position 1 or 2.

You will then only see high-priority messages in the multifunction display (> page 368).

Control system

Settings menu

In the Settings... menu are two functions:

- The function To reset: Press reset button for 3 seconds for resetting all settings to factory standard.
- A collection of submenus for performing individual settings for your vehicle.
- Press button or repeatedly until the Settings... menu appears in the multifunction display.

Settings...
To reset: Press
reset button
for 3 seconds

The following settings and submenus are available in the Settings... menu:

Function	Page
Resetting all settings	134
Submenus in the Settings menu	135
Instrument cluster submenu	137
Time/date submenu	137
Lighting submenu	143
Vehicle submenu	147
Convenience submenu	147

Resetting all settings

You can reset all the functions of all submenus to the factory settings.

▶ Press the reset button on the instrument cluster (> page 24) for approximately 3 seconds.

The request to press the reset button **(B)** once more to confirm appears in the multifunction display.



The functions of all submenus will be reset to the factory settings.

The message Reset to factory settings appears in the multifunction display.



For safety reasons, the following function cannot be reset while driving:

 the function Lamp circuit headlamp mode in the Lighting submenu

The following message appears in the multifunction display:

Lighting Cannot be completely reset to factory settings while driving.



Your individual settings will not be reset unless you confirm the action by pressing the reset button again.

After 5 seconds the Settings...menu reappears in the multifunction display.

Submenus in the Settings menu

▶ Press button <a> .

In the multifunction display you see the collection of the submenus.



Press button

The selection marker moves to the next submenu.

The submenus are arranged by hierarchy. Scroll up with button , and scroll down with button .

With the selection marker on the desired submenu, use the button to access the individual functions within that submenu. Once within the submenu, you can use the button to move to the next function or the button to move to the previous function within that submenu.

The settings themselves are made with button + or -.

Control system

The table below shows what settings can be changed within the various submenus.

Detailed instructions on making individual settings can be found on the following pages.

Instrument cluster	Time/Date	Lighting	Vehicle	Convenience*
(⊳ page 137)	(⊳ page 139)	(⊳ page 143)	(⊳ page 147)	(⊳ page 147)
Selecting digital speed- ometer display mode	Time synchronization with head unit*	Daytime running lamp mode (USA only)	Setting automatic locking	Activating easy-entry/exit feature*
Selecting language	Setting the time (hours)	Locator lighting		Setting parking position for exterior rear view mirror*
Selecting display (speed display or outside	Setting the time (minutes)	Night security illumination		
temperature) for status indicator	Setting the date (month)	Interior lighting delayed shut-off		
	Setting the date (day)			
	Setting the date (year)			

Instrument cluster submenu

Access the Instr. cluster submenu via the Settings... menu. Use the Instr. cluster submenu to change the instrument cluster display settings. The following functions are available:

Function	Page
Selecting speedometer display mode	137
Selecting language	137
Selecting display (speed display or outside temperature) for status indicator	138

Selecting digital speedometer display mode

- ► Move the selection marker with button → or → to the Instr.
- ► Press button or repeatedly until you see Display unit Digital speedometer in the multifunction display.

The selection marker is on the current setting.



Press button or to set the speedometer unit to km or miles.

Selecting language

- ► Move the selection marker with button + or to the Instr.
- ▶ Press button or repeatedly until you see Language in the multifunction display.

The selection marker is on the current setting.




Control system

- ▷▷ Available languages:
 - German
 - English
 - Italian
 - French
 - Spanish

Selecting display (speed display or outside temperature) for status indicator

- Move the selection marker with button or to the Instr.
- ▶ Press button or repeatedly until you see Select display in the multifunction display.

The selection marker is on the current setting.



 Press button or to select the desired setting.

The selected display is then shown continuously in the lower display.

The other display now appears in the menu of the standard display:

- Digital speedometer or
- Outside temperature

Time/Date submenu

Access the Time/Date submenu via the Settings... menu. Use the Time/Date submenu to change the instrument cluster display settings.

The following functions are available:


Function	Page
Time synchronization with head unit*	139
Setting the time (hours)	139
Setting the time (minutes)	140
Setting the date (month)	141
Setting the date (day)	141
Setting the date (year)	142

Time and date synchronization with head unit*

This function can only be seen on vehicles with COMAND* and navigation module*.

- ► Move the selection marker with button → or → to the Time/Date submenu.
- ► Press button or repeatedly until you see Synchronization with head unit in the multifunction display.

The selection marker is on the current setting.



Press button or to select the desired setting.

Setting the time (hours)

This function can be seen in vehicles with audio system, or in vehicles with COMAND* and navigation module*, if the time and date synchronization with head unit* feature was set to 0ff (▷ page 139).



Vehicles with COMAND*: For information on setting the time in COMAND, refer to the separate COMAND operating instructions.

Control system

- Move the selection marker with button to the Time/Date submenu.
- ▶ Press button or repeatedly until you see Clock, hours in the multifunction display.

The selection marker is on the hours.



- Press button or to set the correct hours displayed in the multifunction display.
- Press reset button
 to confirm the set hours.

Setting the time (minutes)

This function can be seen in vehicles with audio system, or in vehicles with COMAND* and navigation module*, if the time and date synchronization with head unit* feature was set to 0ff (▷ page 139).



Vehicles with COMAND*: For information on setting the time in COMAND, refer to the separate COMAND operating instructions.

- Move the selection marker with button to the Time/Date submenu.
- ▶ Press button or repeatedly until you see Clock, minutes in the multifunction display.

The selection marker is on the minutes.



- Press button + or to set the correct minutes displayed in the multifunction display.
- ► Press reset button **(B)** to confirm the set minutes.

Setting the date (month)

This function can be seen in vehicles with audio system, or in vehicles with COMAND* and navigation module*, if the time and date synchronization with head unit* feature was set to 0ff (▷ page 139).



Vehicles with COMAND*: For information on setting the time in COMAND, refer to the separate COMAND operating instructions.

- Move the selection marker with button → or → to the Time/Date submenu.
- ► Press button or repeatedly until you see Set date month in the multifunction display.

The selection marker is on the month.



Press button for to set the month.

Setting the date (day)

This function can be seen in vehicles with audio system, or in vehicles with COMAND* and navigation module*, if the time and date synchronization with head unit* feature was set to 0ff (▷ page 139).



Vehicles with COMAND*: For information on setting the time in COMAND, refer to the separate COMAND operating instructions.

Control system

- Move the selection marker with button to the Time/Date submenu.
- ▶ Press button or repeatedly until you see Set date day in the multifunction display.

The selection marker is on the day.



Press button or to set the day.

Setting the date (year)

This function can be seen in vehicles with audio system, or in vehicles with COMAND* and navigation module*, if the time and date synchronization with head unit* feature was set to 0ff (▷ page 139).



Vehicles with COMAND*: For information on setting the time in COMAND, refer to the separate COMAND operating instructions.

- ► Move the selection marker with button → or → to the Time/Date submenu.
- Press button or repeatedly until you see Set date year in the multifunction display.

The selection marker is on the year.



Press button or to set the year.

Lighting submenu

Access the Lighting submenu via the Settings... menu. Use the Lighting submenu to change the lamp and lighting settings on your vehicle.

The following functions are available:

Function	Page
Daytime running lamp mode (USA only)	143
Locator lighting	144
Night security illumination	145
Interior lighting delayed shut-off	146


Daytime running lamp mode (USA only)



This function is not available in countries where the daytime running lamp mode is mandatory and therefore in a constant mode.

- Press button or repeatedly until you see Lamp circuit headlamp mode in the multifunction display.

The selection marker is on the current setting.



Press button + or - to select manual operation (manual) or daytime running lamp mode (constant) activated.

With daytime running lamp mode activated and the exterior lamp switch in position or auto, the low beam headlamps are switched on when the engine is running.

In low ambient light conditions the following lamps will switch on additionally:

- Parking lamps
- Tail lamps
- License plate lamps
- Side marker lamps

For more information on the daytime running lamp mode, see "Lighting" (> page 110).

Control system



For safety reasons, resetting all the functions of all submenus to the factory settings while driving (\triangleright page 134) will not deactivate the daytime running lamp mode.

The following message appears in the multifunction display:

Lighting Cannot be completely reset to factory settings while driving.

Locator lighting

With the locator lighting feature activated and the exterior lamp switch in position AUTO, the following lamps will switch on during darkness when the vehicle is unlocked with the SmartKey:

- Parking lamps
- Tail lamps
- License plate lamps
- Side marker lamps
- Front fog lamps

The locator lighting switches off when the driver's door is opened.

If you do not open a door after unlocking the vehicle with the SmartKey, the lamps will switch off automatically after approximately 40 seconds.

- Move the selection marker with button to the Lighting submenu.
- Press button or repeatedly until you see Function Surround lighting in the multifunction display.

The selection marker is on the current setting.



- ► Press button → or → to switch the locator lighting function 0n.
- ► Turn the exterior lamp switch to position AUTO when exiting the vehicle (> page 55).

The locator lighting feature is activated.

Control system

Night security illumination (Headlamps delayed shut-off)

Use this function to set whether or not the exterior lamps illuminate during darkness after exiting the vehicle and all doors closed.

With the delayed shut-off feature activated and the exterior lamp switch in position AUTO before the engine is turned off, the following lamps will switch on when the engine is turned off and remain lit for approximately 15 seconds:

- Parking lamps
- Tail lamps
- License plate lamps
- Side marker lamps
- Front fog lamps

If after turning off the engine you do not open a door or do not close an opened door, the lamps will automatically switch off after 60 seconds.



You can reactivate this function within 10 minutes by opening a door.

- Move the selection marker with button → or → to the Lighting submenu.
- ► Press button or repeatedly until you see Headlamps delayed shut-off in the multifunction display.

The selection marker is on the current setting.



- ► Press button or or off.
- ► Turn the exterior lamp switch to position AUTO before turning off the engine (▷ page 55).

Control system

You can temporarily deactivate the delayed shut-off feature:

- Before exiting the vehicle, turn the SmartKey in the starter switch to position 0.
- ► Then turn it to position **2** and back to position **0**.

The delayed shut-off feature is deactivated. It will reactivate as soon as you reinsert the SmartKey in the starter switch.

Interior lighting delayed shut-off

Use this function to set whether or not the interior lighting remains lit during darkness for approximately 10 seconds after you have removed the SmartKey from the starter switch.

- ► Press button or repeatedly until you see Interior lighting delayed shut-off in the multifunction display.

The selection marker is on the current setting.



► Press button → or → to set the function to 0n or 0ff.

Control system

Vehicle submenu

Access the Vehicle submenu via the Settings... menu. Use the Vehicle submenu to make general vehicle settings.

The following function is available:

Function	Page
Setting automatic locking	147

For additional information on central locking, see "Automatic central locking" (> page 101).

Setting automatic locking

Use this function to activate or deactivate the automatic locking system. With the automatic locking system activated, the vehicle is centrally locked at vehicle speeds of approximately 9 mph (15 km/h).

- Move the selection marker with button → or → to the Vehicle submenu.
- ► Press button or repeatedly until you see Automatic door lock in the multifunction display.

The selection marker is on the current setting.



Press button or to set the automatic central locking to 0n or 0ff.

Convenience* submenu

Access the Convenience submenu via the Settings... menu. Use the Convenience submenu to change the settings for a number of convenience features.

The following functions are available:

Function	Page
Activating easy-entry/exit feature*	148
Setting parking position for exterior rear view mirror*	148

Control system

Activating easy-entry/exit feature *

Use this function to activate and deactivate the easy-entry/exit feature (\triangleright page 43).

Warning!



You must make sure no one can become trapped or injured by the moving steering wheel when the easy-entry/exit feature is activated.

To cancel steering wheel movement, do one of the following:

- Move steering column lever* (▷ page 43).
- Press one of the memory position buttons* or the memory button M*
 (▷ page 107).

Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could open the driver's door and unintentionally activate the easy-entry/exit feature, which could result in an accident and/or serious personal injury.

- Move the selection marker with button or to the Convenience submenu.
- ► Press button or repeatedly until you see Function Easy-entry feature in the multifunction display.

The selection marker is on the current setting.



► Press button ← or to set the function to 0n or 0ff.

Setting parking position * for exterior rear view mirror

Use this function to select whether the passenger-side exterior rear view mirror should be turned downward during parking maneuvers when reverse gear **R** is engaged.

For additional information, see "Storing exterior rear view mirror parking position (parking aid)" (> page 108).

Move the selection marker with button or to the Convenience submenu.

Control system

▶ Press button or repeatedly until you see Mirror adjustment Parking aid in the multifunction display.

The selection marker is on the current setting.



► Press button → or → to set the function to 0n or 0ff.

Trip computer menu

Use the trip computer menu to call up statistical data on your vehicle.

The following information is available:

Function	Page
Fuel consumption statistics after start	149
Fuel consumption statistics since last reset	150
Calling up range (distance to empty)	151



When you enter the trip computer menu, you will always see the fuel consumption statistics after start first.

Fuel consumption statistics after start

- ▶ Press button or repeatedly until you see the first function of the trip computer menu.
- ► Press button or repeatedly until you see After start in the multifunction display.



- ① Statistics called up: since start
- 2 Time elapsed since start
- ③ Average fuel consumption since start
- (4) Average speed since start
- (5) Distance driven since start

Control system



All statistics stored since the last engine start will be reset approximately four hours after the SmartKey in the starter switch is turned to position **0** or removed from the starter switch.

Resetting will not occur if you turn the SmartKey back to position 1 or 2 within this time period.

Fuel consumption since last reset

- Press button or repeatedly until you see the first function of the trip computer menu.
- ▶ Press button or repeatedly until you see After reset in the multifunction display.



- 1 Statistics called up: since last reset
- (2) Time elapsed since last reset
- 3 Average fuel consumption since last reset
- 4 Average speed since last reset
- (5) Distance driven since last reset

Resetting fuel consumption statistics manually

▶ Press and hold reset button **(B)** until the values of the statistics are reset to 0.

Resetting fuel consumption statistics automatically

The values of the statistics will be automatically reset to 0 when one of the following values exceeds:

• distance: 100000 miles (100000 km)

• elapsed time: 10000 hours

Control system

Calling up range (distance to empty)

- ▶ Press button or repeatedly until you see the first function of the trip computer menu.
- ▶ Press button or repeatedly until you see Range: in the multifunction display.

In the multifunction display you will see the calculated range based on the current fuel tank level.



TEL menu*

Warning!



A driver's attention to the road must always be his/her primary focus when driving. For your safety and the safety of others, we recommend that you pull over to a safe location and stop before placing or taking a telephone call. If you choose to use the telephone while driving, please use the hands-free device and only use the telephone when weather, road, and traffic conditions permit.

Some jurisdictions prohibit the driver from using a cellular telephone while driving a vehicle.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

Never operate radio transmitters equipped with a built-in or attached antenna (i.e. without being connected to an external antenna) from inside the vehicle while the engine is running. Doing so could lead to a malfunction of the vehicle's electronic system, possibly resulting in an accident and/or personal injury.

You can use the functions in the TEL menu to operate your telephone, provided it is connected to a hands-free system and switched on.

Switch on the telephone and Audio or COMAND*.

See separate operating instructions.

Press button or repeatedly until you see the TEL menu in the multifunction display.

Control system

Which messages will appear in the multifunction display depends on whether your telephone is switched on or off:

- If the telephone is switched off, the message in the multifunction display is: PHONE off.
- If the telephone is switched on:

The telephone will then search for a network. During this time the multifunction display is empty.

As soon as the telephone has found a network, Ready is indicated in the multifunction display.



This standby message indicates that your telephone is ready for use and you can operate it using the control system.

Answering a call

When your telephone is ready to receive calls, you can answer a call at any time. In the multifunction display you will see the message:



Audio system



COMAND*

Press button

You have answered the call.

The duration of the call appears in the multifunction display.

Rejecting a call

If you do not wish to receive the call, you can choose to reject it.

▶ Press button <a>♠.



The caller receives a busy signal.

Ending a call

▶ Press button <a>.

You have ended the call.

The standby message appears in the multifunction display.

Control system

Dialing a number from the phone book

If your telephone is ready to receive calls, you may select and dial a number from the phone book at any time.

- ▶ Press button or repeatedly until you see the TEL menu and the standby message in the multifunction display.
- ▶ Press button or <</p>

The control system reads the phone book which is stored in the telephone. This may take up to 30 seconds. In the multifunction display you will see the message Please wait.

When the message Please wait disappears, the phone book has been loaded.

▶ Press button or repeatedly until the desired name appears in the multifunction display.

The stored names are displayed in ascending or descending alphabetical order.



(1) Selected name from phone book




If you press and hold button or for longer than 1 second, the system scrolls rapidly through the list of names until you release the button again.

Cancel the quick search mode by pressing button .

▶ Press button <a> □.

The control system dials the selected phone number.

 If the connection is successful, the name of the party you called and the duration of the call will appear in the display.



 If no connection is made, the control system stores the dialed number in the redial memory.

or

► Cancel the call you have intended to make by pressing button <a>.

Control system

Redialing

The control system stores the most recently dialed phone numbers. This eliminates the need to search through your entire phone book.

- ► Press button or repeatedly until you see the TEL menu and the standby message in the multifunction display.



- ▶ Press button or repeatedly until the desired number or name appears in the multifunction display.
- Press button .

The control system dials the selected phone number.

If the connection is successful, the duration of the call will appear in the multifunction display, and

 the name of the party if stored in the phone book

or

• instead of it the dialed number

or

 Cancel the call you have intended to make by pressing button

Manual transmission

▼ Manual transmission

Manual transmission is standard equipment on select models and not available on all models.

For information on driving with a manual transmission, see "Manual transmission" (> page 51).

Warning!



For vehicles equipped with a manual transmission, getting out of your vehicle with the gearshift lever not engaged in first or reverse gear and parking brake engaged is dangerous.

Also, when parked on an incline, an engaged first or reverse gear alone may not prevent your vehicle from moving, possibly hitting people or objects.

Always set the parking brake in addition to engaging first or reverse gear (▷ page 59).

When parked on an incline, turn front wheels towards the road curb.

Do not park this vehicle in areas where combustible materials such as grass, hay or leaves can come into contact with the hot exhaust system, as these materials could be ignited and cause a vehicle fire.

Warning!



When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could move the gearshift lever, which could result in an accident and/or serious injury.


Warning!



On slippery road surfaces, never downshift in order to obtain braking action.

This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.

Manual transmission



Gearshift pattern for manual transmission

!

When you are shifting into the **5th** or **6th** gear, make sure that you press the gearshift lever to the right. Otherwise, you could accidentally shift into the **3rd** or **4th** gear and damage the transmission.

Downshifting gears leading to overrevving the engine can result in engine damage that is not covered by the Mercedes-Benz Limited Warranty.

Never hold the vehicle stopped on a hill by using the clutch pedal. The clutch may be damaged which is not covered by the Mercedes-Benz Limited Warranty.

Do not exceed the engine speed limits. Refer to tachometer (▷ page 121) for engine speeds.

Shifting into reverse

!

Only shift into reverse gear ${\bf R}$ when the vehicle is stationary, as the transmission could otherwise be damaged.

- Stop the vehicle completely.
- ► Fully depress the clutch pedal.
- Move the gearshift lever to the neutral position (no gear selected).
- ► Move the gearshift lever to the left until you feel a certain resistance.
- Push the gearshift lever past this resistance.
- ► Then move the gearshift lever forward into position **R**.

▼ Automatic transmission*


For more information on driving with an automatic transmission, see "Automatic transmission*" (▷ page 51).

Your vehicle's transmission adapts its gear shifting process to your individual driving style by continually adjusting the shift points up or down. These shift point adjustments are performed based on current operating and driving conditions.

If the operating conditions change, the automatic transmission reacts by adjusting its shift program.



During the brief warm-up, transmission upshifting is delayed. This allows the catalytic converter to heat up more quickly to operating temperature.



Gearshift pattern for automatic transmission

The automatic transmission selects individual gears automatically, depending on:

- the gear selector lever position **D** (▷ page 159) with gear ranges (▷ page 160)
- the selected program mode:

(**C/S**) (⊳ page 163)

or

(**M/C/S**) (SLK 55 AMG only) (▷ page 169)

- the position of the accelerator pedal (▷ page 162)
- the vehicle speed

Automatic transmission*



- Current gear range/gear selector lever position
- ② Current program mode

The current gear range/gear selector lever position and program mode (C/S) or (M/C/S) appear in the multifunction display.

Warning!



It is dangerous to shift the gear selector lever out of ${\bf P}$ or ${\bf N}$ if the engine speed is higher than idle speed. If your foot is not firmly on the brake pedal, the vehicle could accelerate quickly forward or reverse. You could lose control of the vehicle and hit someone or something. Only shift into gear when the engine is idling normally and when your right foot is firmly on the brake pedal.

Į.

Allow engine to warm up under low load use. Do not place full load on the engine until the operating temperature has been reached.

Shift into reverse gear **R** or parking position **P** only when the vehicle is stopped.

Avoid spinning of a drive wheel for an extended period when driving off on slippery road surfaces. This may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.

When the gear selector lever is in position **D**, you can influence transmission shifting by:

- · limiting the gear range
- changing gears manually

Gear selector lever position

Effect

P Park position

Gear selector lever position when the vehicle is parked. Place gear selector lever in position **P** only when vehicle is stopped. The park position is not intended to serve as a brake when the vehicle is parked. Rather, the driver should always set the parking brake in addition to placing the gear selector lever in position **P** to secure the vehicle.

Effect

The SmartKey can only be removed from the starter switch with the gear selector lever in position **P**. With the SmartKey removed, the gear selector lever is locked in position **P**.

If the vehicle's electrical system is malfunctioning, the gear selector lever could remain locked in position **P** (> page 396).

Reverse gear

Place gear selector lever in position **R** only when vehicle is stopped.

Effect

Neutral

No power is transmitted from the engine to the drive axle. When the brakes are released, the vehicle can be moved freely (pushed or towed).

To avoid damage to the transmission, never engage ${\bf N}$ while driving.

If the ESP® is deactivated or malfunctioning:
Move gear selector lever to **N** only if the vehicle is in danger of skidding, e.g. on icy roads.

D Drive

The transmission shifts automatically. All forward gears are available.

Automatic transmission*



Coasting the vehicle, or driving for any other reason with gear selector lever in **N** can result in transmission damage that is not covered by the Mercedes-Benz Limited Warranty.

Warning!



Getting out of your vehicle with the gear selector lever not fully engaged in position **P** is dangerous. Also, position **P** alone is not intended to or capable of preventing your vehicle from moving, possibly hitting people or objects.

Always set the parking brake in addition to shifting to position P (\triangleright page 52). When parked on an incline, turn the front wheels towards the road curb.

Do not park this vehicle in areas where combustible materials such as grass, hay or leaves can come into contact with the hot exhaust system, as these materials could be ignited and cause a vehicle fire.

Warning!



When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could move the gear selector lever from position **P**, which could result in an accident and/or serious personal injury.

Gear ranges

With the gear selector lever in position \mathbf{D} and driving in the automatic shift program \mathbf{C} or \mathbf{S} (\triangleright page 163), you can select a gear range for the automatic transmission to operate within:

Gear selector lever (> page 164): You can limit the gear range by pressing the gear selector lever to the left (**D-**), and reverse the gear range limit by pressing the gear selector lever to the right (**D+**).

Steering wheel gearshift control (⊳ page 165):

You can limit the gear range by pressing the respective downshift button on the steering wheel gearshift control, and reverse the gear range limit by pressing the respective upshift button on the steering wheel gearshift control.

Automatic transmission*

The selected gear range appears in the multifunction display (> page 158). If you press on the accelerator when the engine has reached its rpm limit, the transmission will upshift beyond any gear range limit selected.

Effect

- The transmission shifts through sixth gear only.
- The transmission shifts through fifth gear only.
- The transmission shifts through fourth gear only.

Effect

The transmission shifts through third gear only.

With this selection you can use the braking effect of the engine.

The transmission shifts through second gear only.

Allows the use of engine's braking power when driving:

- on steep downgrades
- in mountainous regions
- under extreme operating conditions
- The transmission operates in first gear only.

For maximum use of engine's braking effect on very steep or lengthy downgrades.

Driving tips

Accelerator position

Your driving style influences the transmission's shifting behavior:

Less throttle Earlier upshifting

More throttle Later upshifting

Kickdown

Use kickdown when you want maximum acceleration.

 Press the accelerator past the point of resistance.

The transmission shifts into a lower gear.

Ease on the accelerator when you have reached the desired speed.

The transmission shifts up again.

Stopping

When you stop briefly, e.g. at traffic lights:

- ▶ Leave the transmission in gear.
- Hold the vehicle with the brake.

When you stop longer with the engine idling and/or on a hill:

- ► Set the parking brake.
- ► Move the gear selector lever to position **P**.

Maneuvering

When you maneuver in tight areas, e.g. when pulling into a parking space:

- ► Control the vehicle speed by gradually releasing the brakes.
- Accelerate gently.
- Never abruptly step on the accelerator.

Working on the vehicle

Warning!



When working on the vehicle, set the parking brake and move gear selector lever to position **P**. Otherwise the vehicle could roll away.

Automatic shift program

The program mode selector switch is located on the lower part of the center console.



1 Program mode selector switch

C Comfort For comfort driving

S Sport For standard driving

The current gear selector lever position and the selected program mode (C/S) are indicated in the multifunction display (\triangleright page 158).



Never change the program mode when the gear selector lever is out of position **P**. This could result in a change of driving characteristics for which you may not be prepared.



The last selected program mode (**C** or **S**) is switched on when the engine is restarted.

 Press program mode selector switch 1 repeatedly until the letter of the desired program mode appears in the multifunction display.

Select **C** for comfort driving:

- The vehicle starts out in second gear (both forward and reverse) for gentler starts. This does not apply if full throttle is applied or gear range 1 is selected.
- Traction and driving stability are improved on icy roads.
- Upshifts occur earlier even when you give more gas. The engine then operates at lower rpms and the wheels are less likely to spin.

Gear selector lever one-touch gearshifting

Even with an automatic transmission, you can change the gears manually and limit or extend the gear range for automatic shifting with the gear selector lever in position **D** and driving in the automatic program mode **C** or **S**.



Allow engine to warm up under low load use. Do not place full load on the engine until the operating temperature has been reached.

Shift into reverse gear **R** or parking position **P** only when the vehicle is stopped.

Avoid spinning of a drive wheel for an extended period when driving off on slippery road surfaces. This may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.

Downshifting

Warning!



On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.

▶ Briefly press the gear selector lever to the left in the D- direction.

The transmission will shift from the current gear to the next lower gear as permitted by the shift program. This action simultaneously limits the gear range of the transmission (▷ page 160).



To avoid overrevving the engine when the gear selector lever is moved to the **D**- direction, the transmission will not shift to a lower gear if the engine's max. speed would be exceeded.

Upshifting

► Briefly press the gear selector lever to the right in the **D+** direction.

The transmission will shift from the current gear to the next higher gear as permitted by the shift program. This action simultaneously extends the gear range of the transmission.

Canceling gear range limit

Press and hold the gear selector lever in the **D+** direction until D reappears in the multifunction display.

The transmission will shift from the current gear range directly to gear range **D**.

Shifting into optimal gear range

▶ Press and hold the gear selector lever in the **D**- direction.

The transmission will automatically select the gear range suited for optimal acceleration and deceleration. This will involve shifting down one or more gears.

Steering wheel gearshift control one-touch gearshifting

The steering wheel gearshift control provides an alternative method for changing the gears manually and limiting or extending the gear range for automatic shifting with the gear selector lever in position **D** and driving in the automatic program mode **C** or **S**.



To avoid overrevving the engine when downshifting with steering wheel gearshift buttons, the transmission will not shift to a lower gear if the engine's max. speed would be exceeded.

!

Allow engine to warm up under low load use. Do not place full load on the engine until the operating temperature has been reached.

Shift into reverse gear **R** or parking position **P** only when the vehicle is stopped.

Avoid spinning of a drive wheel for an extended period when driving off on slippery road surfaces. This may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.

Steering wheel gearshift control* SLK 280, SLK 350

The steering wheel gearshift buttons are located to the left and right of the steering wheel.



- ① Button, inside: downshift
- (2) Button, outside: upshift

Automatic transmission*



You cannot shift with the steering wheel gearshift buttons when the gear selector lever is in position **P**, **N** or **R**.

The last selected program mode (**C** or **S**) is switched on when the engine is restarted.

Downshifting

Warning!



On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.

▶ Briefly press the inside ① of one of the buttons on the steering wheel.

The transmission will shift to the next lower gear as permitted by the shift program. This action simultaneously limits the gear range of the transmission (> page 160).

Upshifting

▶ Briefly press the outside ② of one of the buttons on the steering wheel.

The transmission will shift to the next higher gear as permitted by the shift program. This action simultaneously extends the gear range of the transmission.

Canceling gear range limit

Press and hold the outside ② of one of the buttons on the steering wheel until D reappears in the multifunction display.

The transmission will shift from the current gear range directly to gear range **D**.

Shifting into optimal gear range

 Press and hold the inside ① of one of the buttons on the steering wheel.

The transmission will automatically select the gear range suited for optimal acceleration and deceleration. This will involve shifting down one or more gears.

Steering wheel gearshift control SLK 55 AMG

The steering wheel gearshift buttons are located to the left and right of the steering wheel.



- 1 Left button: downshift
- (2) Right button: upshift



You cannot shift with the steering wheel gearshift buttons when the gear selector lever is in position **P**, **N** or **R**.

The last selected program mode (**C** or **S**) is switched on when the engine is restarted in the automatic program mode.

The following instructions describe operation of the steering wheel gearshift control when driving in the automatic program mode **C** or **S**.

For instructions on operating the steering wheel gearshift control and gear selector lever in the manual program mode \mathbf{M} , see "Manual shift program SLK 55 AMG" (\triangleright page 169).

Automatic transmission*

Downshifting

Warning!



On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.

► Briefly press button ① on the left side of the steering wheel.

The transmission will shift to the next lower gear as permitted by the shift program. This action simultaneously limits the gear range of the transmission (▷ page 160) when you are driving in the automatic program mode (**C** or **S**).

Upshifting

► Briefly press button ② on the right side of the steering wheel.

The transmission will shift to the next higher gear as permitted by the shift program. This action simultaneously extends the gear range of the transmission when you are driving in the automatic program mode (**C** or **S**).

Canceling gear range limit

► Press and hold button ② on the right side of the steering wheel until □ reappears in the multifunction display.

The transmission will shift from the current gear range directly to gear range **D**.

Shifting into optimal gear range

► Press and hold button ① on the left side of the steering wheel.

The transmission will automatically select the gear range suited for optimal acceleration and deceleration. This will involve shifting down one or more gears.

Manual shift program SLK 55 AMG

In addition to the automatic shift program ${\bf C}$ or ${\bf S}$, your vehicle is equipped with the manual shift program ${\bf M}$.

In the manual program mode **M**, system-controlled automatic gearshifting is switched off and you need to change the gears by manually upshifting or downshifting using the steering wheel gearshift buttons to the left and right of the steering wheel (> page 167) or the gear selector lever.



Allow engine to warm up under low load use. Do not place full load on the engine until the operating temperature has been reached.

Shift into reverse gear **R** or parking position **P** only when the vehicle is stopped.

Avoid spinning of a drive wheel for an extended period when driving off on slippery road surfaces. This may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.

The program mode selector switch is located on the lower part of the center console.



1) Program mode selector switch

M Manual For manual gear shifting

C Comfort For comfort driving

S Sport For standard driving

Automatic transmission*

The current gear selector lever position and the selected program mode (M/C/S) are indicated in the multifunction display (\triangleright page 158).



For information on automatic program modes **C** or **S**, see "Automatic shift program" (> page 163), "Gear selector lever one-touch gearshifting" (> page 164), and "Steering wheel gearshift control one-touch gearshifting" (> page 165).

Activating manual shift program

► Press program mode selector switch ① repeatedly until the M for manual program mode **M** appears in the multifunction display.

The transmission switches to the manual program mode **M**. Automatic shifting is switched off. The gear range is not limited.

You can change the gears manually when the gear selector lever is in position **D**. You can upshift or downshift through the gears in succession.



The manual program mode \mathbf{M} will not be stored. When the engine is turned off with the manual program mode \mathbf{M} selected, the transmission will go to the automatic program mode (\mathbf{C} or \mathbf{S}) when the engine is restarted.

Upshifting



In the manual program mode **M**, the transmission will not upshift, even if the engine has reached its overrevving range. Shift up to the next gear before the engine has reached its overrevving range. Make absolutely certain that the engine speed does not reach the red marking on the tachometer (> page 24). Otherwise the engine could be damaged which is not covered by the Mercedes-Benz Limited Warranty.

 Briefly press the gear selector lever to the right in the **D+** direction.

or

 ▶ Briefly press button ② on the right side of the steering wheel (▷ page 167).

The transmission shifts to the next higher gear.

If, instead of the manual program mode symbol M, the symbol appears in the multifunction display (> page 158), shift to the next higher gear. The fuel supply will otherwise be interrupted to prevent the engine from overrevving.

Downshifting

Warning!



On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.

► Briefly press the gear selector lever to the left in the **D**- direction.

or

► Briefly press button ① on the left side of the steering wheel (▷ page 167).

The transmission shifts to the next lower gear.



When you brake or stop, the transmission shifts down to a gear from which you can easily accelerate or take off.

Kickdown

Using the kickdown when driving in the manual program mode **M** is not possible.

Automatic transmission*

Deactivating manual shift program

► Press the program mode selector switch (▷ page 169) repeatedly until ℂ or S appears in the multifunction display.

or

Restart the engine.

The transmission will go to the automatic program mode (**C** or **S**).

The manual program mode \mathbf{M} is not stored.

Emergency operation (Limp Home Mode)

If vehicle acceleration worsens or the transmission no longer shifts, the transmission is most likely operating in limp home (emergency operation) mode. In this mode only second gear and reverse gear can be activated.

- ▶ Stop the vehicle.
- Move gear selector lever to P.
- ► Turn off the engine.
- Wait at least 10 seconds before restarting.
- Restart the engine.
- Move gear selector lever to position D (for second gear) or R.
- Have the transmission checked at an authorized Mercedes-Benz Center as soon as possible.

Good visibility

▼ Good visibility

For information on the windshield wipers, see (▷ page 56).

Headlamp cleaning system*

The button is located on the left side of the dashboard.



- (1) Headlamp cleaning button
- Switch on the ignition (▷ page 36).
- ▶ Press button ①.

The headlamps are cleaned with a high-pressure water jet.



The headlamps will automatically be cleaned when you have

- switched on the headlamps and
- operated the windshield wipers with windshield washer fluid
 15 times

When you switch off ignition, the counter resets.

For information on filling up the washer reservoir, see "Windshield washer system and headlamp cleaning system*" (> page 315).

Rear view mirrors

For more information on setting the rear view mirrors, see "Mirrors" (> page 45).

Interior rear view mirror, antiglare position



 Tilt the mirror to the antiglare night position by moving the lever towards the windshield.

The interior rear view mirror is dimmed.

Good visibility

Auto-dimming mirrors*

The reflection brightness of the exterior rear view mirrors and the interior rear view mirror will respond automatically to glare when

- ignition is switched on and
- incoming light from headlamps falls on the sensor in the interior rear view mirror

The rear view mirrors will not react if

- reverse gear R is engaged
- interior lighting is switched on

Warning!



The auto-dimming function does not react if incoming light is not aimed directly at sensors in the interior rear view mirror.

The interior rear view mirror and the exterior rear view mirror on the driver's side do not react, for example, if the wind screen is installed.

Glare can endanger you and others.

Warning!



In case of an accident, liquid electrolyte may escape from the mirror housing if the mirror glass breaks.

Electrolyte has an irritating effect. Do not allow the liquid to come into contact with eyes, skin, clothing, or the respiratory system. In case it does, immediately flush affected area with water, and seek medical help if necessary.

!

Electrolyte drops coming into contact with the vehicle paint finish can only be completely removed while in their liquid state and by applying plenty of water.

Warning!




Exercise care when using the passenger-side exterior rear view mirror. The mirror surface is convex (outwardly curved surface for a wider field of view). Objects in mirror are closer than they appear. Check your interior rear view mirror or glance over your shoulder before changing lanes.

Good visibility

Activating exterior rear view mirror parking position*

Follow these steps to activate the mirror parking position so that the passenger-side exterior rear view mirror will be turned downward during parking maneuvers to the stored position.

The switches are located on the lower part of the center console.



- 1 Driver-side exterior rear view mirror
- (2) Adjustment switch
- 3 Passenger-side exterior rear view mirror

- ► Switch on the ignition (> page 36).
- Store a parking position* for the passenger-side exterior rear view mirror (▷ page 108).
- ► Switch the Mirror adjustment
 Parking aid function* in the
 Convenience submenu of the control
 system to ON (▷ page 148).
- ► Press switch ③ for the passenger-side exterior rear view mirror.
- ► Shift into reverse gear **R**.

The passenger-side exterior rear view mirror turns downwards to the stored position.

The passenger-side exterior rear view mirror returns to its previously stored driving position:

- 10 seconds after you shifted out of reverse gear R
- immediately once you exceed a vehicle speed of approximately 6 mph (10 km/h)
- immediately when you press adjustment switch (2)

Good visibility

Sun visors

The sun visors protect you from sun glare while driving.



- 1) Mirror lamp*
- ② Mounting*
- (3) Mirror cover
- (4) Sun visor

Warning!



Do not use the vanity mirror while driving. Keep the mirrors in the sun visors closed while vehicle is in motion. Reflected glare can endanger you and others.

- Swing sun visors down when you experience glare.
- ➤ To use mirror and switch on mirror lamp*, lift up mirror cover (3).



If sunlight enters through a side window, disengage sun visor from mounting* (2) and pivot it to the side. You then can slide the sun visor along the pivot arm to a different position if so desired.

The mirror lamp* ① will switch off as soon as sun visor is disengaged from mounting* ②.

!

Close mirror cover ③ if open before you disengage the sun visor ④ from mounting* ② and pivot it to the side.

Good visibility

Rear window defroster

The rear window defroster uses a large amount of power. To keep the battery drain to a minimum, switch off the defroster as soon as the rear window is clear.

The defroster is automatically deactivated after approximately 6 to 17 minutes of operation depending on the outside temperature.

Warning!



Any accumulation of snow and ice should be removed from the rear window before driving. Visibility could otherwise be impaired, endangering you and others.

Switching on

➤ Press the rear window defroster switch [fff] in the control panel of the climate control (▷ page 179) or the automatic climate control* (▷ page 192).

The indicator lamp on the rear window defroster switch comes on.

!

The rear window defroster cannot be switched on when the retractable hard-top is open. The indicator lamp starts flashing if the hardtop is open.

• Close the retractable hardtop first.

The rear window defroster can be switched on again.

Switching off

► Press the rear window defroster switch again in the control panel of the climate control or the automatic climate control*.


The indicator lamp on the rear window defroster switch goes out.

Į.

If the rear window defroster switches off too soon and the indicator lamp starts flashing, this means that too many electrical consumers are operating simultaneously and there is insufficient voltage in the battery. The system responds automatically by deactivating the rear window defroster.

As soon as the battery has sufficient voltage, the rear window defroster automatically turns itself back on.

Climate control



Climate control

Item

- 1 Thumbwheel for air volume control for adjustable left side air vent
- (2) Left side air vent, adjustable
- Fixed air vent for defrosting left side window
- (4) Left center air vent, fixed
- Thumbwheel for air volume control for fixed/adjustable left center air vents
- (6) Left center air vent, adjustable
- 7 Right center air vent, adjustable
- Thumbwheel for air volume control for fixed/adjustable right center air vents
- (9) Right center air vent, fixed
- Fixed air vent for defrosting right side window
- Right side air vent, adjustable
- 12 Thumbwheel for air volume control for adjustable right side air vent

Item


(3) Climate control panel



When you turn the thumbwheels (5) and (8) upwards to the first stop, the fixed center air vents (4) and (9) and the adjustable center air vents (6) and (7) are open.

When you turn the thumbwheels completely upwards, only the adjustable center air vents (a) and (7) are open.

For draft-free ventilation, move the sliders for the center air vents (6) and (7) to the middle position.



Item

- 1) Temperature control, left side
- ② Air volume control, climate control on/off
- (3) Air distribution control
- (4) Temperature control, right side
- (> Rear window defroster (> page 177)
- 6 Front defroster
- AC cooling on/off, Residual heat/ventilation
- 8 Air recirculation

Climate control

The climate control is operational whenever the engine is running. The system cools or heats the interior depending on the selected interior temperature and the current outside temperature.

Warning!



When operating the climate control, the air that enters the passenger compartment through the air vents can be very hot or very cold (depending on the set temperature). This may cause burns or frostbite to unprotected skin in the immediate area of the air vents. Always keep sufficient distance between unprotected parts of the body and the air vents. If necessary, use the air distribution controls (>> page 179) to direct the air to air vents in the vehicle interior that are not in the immediate area of unprotected skin.

Nearly all dust particles, pollutants and odors are filtered out before outside air enters the interior through the air distribution system.

The air conditioning will not engage (no cooling) if the **A/C** mode is deactivated (▷ page 179).

Warning!



Follow the recommended settings for heating and cooling given on the following pages. Otherwise the windows could fog up, impairing visibility and endangering you and others.



Severe conditions (e.g. strong air pollution) may require replacement of the filter before its scheduled interval.

A clogged filter will reduce the air volume to the interior.

If the vehicle interior is hot, ventilate the interior before driving off. The climate control will then adjust the interior temperature to the set value much faster.

Keep the air intake grille in front of the windshield free of snow and debris.

When the retractable hardtop is closed, do not obstruct air flow by placing objects on the air flow-through exhaust slots below the rear window.

Climate control

Switching climate control system on/off

Switching on

- ► Switch on the ignition (> page 36).
- Set air volume control ② to any speed
 (▷ page 179).

The previous settings are once again in effect.

Switching off

Set air volume control ② (▷ page 179) to position 0.



When the climate control system is switched off, the outside air supply and circulation are also switched off. Only choose this setting for a short time. Otherwise the windows could fog up.

Setting the temperature

Use temperature controls ① and ④ (▷ page 179) to separately adjust the air temperature on each side of the passenger compartment. You should raise or lower the temperature setting in small increments, preferably starting at 72°F (22°C). The climate control will adjust to the set temperature as fast as possible.

Increasing

Turn temperature control ① and/or ② (▷ page 179) slightly clockwise.

The climate control system will correspondingly adjust the interior air temperature.

Decreasing

Turn temperature control

 (1) and/or (4) (▷ page 179) slightly counterclockwise.

The climate control system will correspondingly adjust the interior air temperature.

Climate control

Adjusting air distribution

Use air distribution control ③ (▷ page 179) to adjust the air distribution.

The following symbols are found on the control:

Symbol	Function
şi	Directs air through the center and side air vents
i,i	Directs air to the windows and through the center and side air vents
† _ブ	Directs air into the entire vehicle interior
1,1	Directs air to the footwells and through the center and side air vents

► Turn the air distribution control to the desired symbol (> page 179).

The climate control system will correspondingly adjust the interior air distribution.



You can also turn the control to a position between two symbols.

Opening the center air vents

- ► Turn thumbwheels ⑤ and ⑧ (▷ page 178) upward to the first stop.

 Center air vents ④, ⑥, ⑦ and ⑨ are open.
- Turn thumbwheels ⑤ and ⑧
 (▷ page 178) upward all the way.
 Only center air vents ⑥ and ⑦ are open.

Climate control

Closing the center air vents

► Turn thumbwheels ⑤ and ⑥ (▷ page 178) downward all the way.

Center air vents ④, ⑥, ⑦ and ⑨ are closed.

Opening and closing side air vents

► Turn thumbwheels ① and ②
(▷ page 178) in the required direction.
Side air vents ② and ① are open or closed.

Adjusting air volume

Ten blower speeds are available.

Use air volume control ②(▷ page 179) to adjust the air volume.

Basic settings

Heating (winter)

- ► Turn temperature controls ① and ② (▷ page 179) to the desired position.
- Turn air volume control ②
 (▷ page 179) to level 2 or higher.
 Otherwise the windows may fog over.
- ► Turn air distribution control ③
 (▷ page 179) to a position
 between → and → .
- ▶ Open the side air vents if necessary.
- ▶ Close the center air vents.

Climate control

Heating (summer)

- ➤ Turn air temperature control ① and ④ (▷ page 179) to the desired position.
- ► Turn air volume control ② (▷ page 179) to level 1 or higher.
- ► Turn air distribution control ③(▷ page 179) to position
- Open the center and side air vents.

Defrosting windshield

You can use this setting to defrost the windshield, for example if it is iced up. You can also defog the side windows.



Keep this setting selected only until the windshield or the side windows are clear again.

Activating

comes on.

The air conditioning switches automatically to the following functions:

- · cooling on to dehumidify
- maximum blowing and heating power
- air flows onto the windshield and the front side windows

Climate control

Deactivating

The previous settings are once again in effect.



The cooling remains switched on.

Windshield fogged on the outside

- ➤ Switch the windshield wipers on (> page 56).
- ► Turn air distribution control ③ to position → or → (▷ page 179).

Air recirculation mode

Switch to air recirculation mode to prevent unpleasant odors from entering the vehicle from the outside (e.g. before driving through a tunnel). This setting cuts off the intake of outside air and recirculates the air in the interior.

Warning!



Fogged windows impair visibility, endangering you and others. If the windows begin to fog on the inside, switching off the air recirculation mode immediately should clear interior window fogging. If interior window fogging persists, make sure the air conditioning (\triangleright page 187) is activated, or press button

Climate control

Activating

► Briefly press button (▷ page 179).

The indicator lamp on the button comes on.



The air recirculation mode is activated automatically at high outside temperatures.

The indicator lamp on button sis not lit when the air recirculation mode is automatically switched on.

A quantity of outside air is added after approximately 30 minutes.

Warning!



Never operate the side windows if there is the possibility of anyone being harmed by the closing procedure.

In the event that the closing procedure causes potential danger, the closing of the door windows can be immediately halted by releasing the button or by pressing the respective power window switch.

The closing of the rear side windows can be immediately halted by releasing the button.



If you press button and keep it pressed, the side windows will close.

The closing of the side windows can be immediately halted by releasing button ...

Deactivating

Press button (▷ page 179) again. The indicator lamp on the button goes out.



The air recirculation mode is deactivated automatically:

- after 5 minutes if the outside temperature is below approximately 41°F (5°C)
- after 5 minutes if the air conditioning is turned off
- after 30 minutes if the outside temperature is above approximately 41°F (5°C)



If you press button and keep it pressed, the side windows will open.

The opening of the side windows can be immediately halted by releasing button ...

Climate control

Air conditioning

The cooling function, only operational when the engine is running, cools the vehicle interior down to the selected temperature. The cooling function also dehumidifies the air in the vehicle interior, thus preventing the windows from fogging up.



Condensation may drip from underneath the vehicle. This is normal and not an indication of a malfunction.

Warning!



If you turn off the cooling function, the vehicle will not be cooled when the weather conditions are warm. The windows can fog up more quickly. Window fogging may impair visibility and endanger you and others.

Deactivating

It is possible to deactivate the air conditioning (cooling) function of the climate control system. The air in the vehicle will then no longer be cooled or dehumidified.

► Press button (> page 179).

The indicator lamp on the button goes out. The cooling function switches off after a short delay.

Activating

Moist air can fog up the windows. You can dehumidify the air with the air conditioning.

The air conditioning uses the refrigerant R134a. This refrigerant is free of CFCs which are harmful to the ozone layer.

Climate control

Maximum cooling

- ► Turn thumbwheels ⑤ and ⑧ (▷ page 178) upwards to the first stop.
 - The fixed center air vents ④ and ⑨ (▷ page 178) and the adjustable air vents ⑥ and ⑦ (▷ page 178) are open.
- For draft-free ventilation, move the sliders for the center air vents
 ⑥ and ⑦ (▷ page 178) to the middle position.
- ► Turn thumbwheels ① and ② (> page 178) for the adjustable side air vents ② and ① (> page 178) to the fully open position.
- Set air distribution control ③
 (▷ page 182) to position

The air distribution directs the air through the center and side air vents.

► Set air volume control ② (▷ page 183) to position **5**.

The ventilation operates with maximum blower speed.

➤ Turn temperature controls ① and ② (▷ page 179) completely counterclockwise to their end stops.

The lowest temperature for both sides is set.



When the vehicle's interior has cooled down enough, reduce the air volume and increase the air temperature to comfortable settings if desired.

Residual engine heat utilization

With the engine switched off, it is possible to continue to heat or ventilate the interior for up to 30 minutes. This feature makes use of the residual heat produced by the engine.

Climate control

Activating

- ► Switch off the ignition (> page 36).



How long the system will provide heating depends on

- the coolant temperature
- the temperature set by the operator

The blower will run at speed setting **1** regardless of the air distribution control setting.


Deactivating



The residual heat is automatically turned off

- when the ignition is switched on (> page 36)
- after about 30 minutes
- if the battery voltage drops

Automatic climate control*



Item

- 1 Thumbwheel for air volume control for adjustable left side air vent
- (2) Left side air vent, adjustable
- Fixed air vent for defrosting left side window
- (4) Left center air vent, fixed
- (5) Thumbwheel for air volume control for fixed/adjustable left center air vents
- (6) Left center air vent, adjustable
- Ockpit air vent
- (8) Thumbwheel for air volume control for cockpit air vent
- Right center air vent, adjustable
- Thumbwheel for air volume control for fixed/adjustable right center air vents
- Right center air vent, fixed
- 12 Fixed air vent for defrosting right side window

Item

- (13) Right side air vent, adjustable
- Thumbwheel for air volume control for adjustable right side air vent
- (5) Automatic climate control panel



When you turn the thumbwheels (5) and (10) upwards to the first stop, the fixed center air vents (4) and (11) and the adjustable center air vents (6) and (9) are open.

When you turn the thumbwheels completely upwards, only the adjustable center air vents (6) and (9) are open.

For draft-free ventilation, move the sliders for the center air vents (6) and (9) to the middle position.

Automatic climate control*



Item

- 1) Air volume control, manual
- (2) Automatic mode
- (3) Front defroster
- 4 To increase temperature on the left side
- (5) OFF Automatic climate control on/off
- 6 To increase temperature on the right side
- 8 Air distribution control, manual
- (9) **REST** Residual heat/ventilation
- (10) A/C AC cooling on/off
- 1) To lower temperature on the right side
- To lower temperature on the left side
- (3) Air recirculation
- (4) Display

The automatic climate control is operational whenever the engine is running. You can operate the automatic climate control system in either the automatic or manual mode. The system cools or heats the interior depending on the selected interior temperature and the current outside temperature.

Warning!



When operating the automatic climate control, the air that enters the passenger compartment through the air vents can be very hot or very cold (depending on the set temperature). This may cause burns or frostbite on unprotected skin in the immediate area of the air vents. Always keep sufficient distance between unprotected parts of the body and the air vents. If necessary, use the air distribution controls (\triangleright page 192) to direct the air to air vents in the vehicle interior that are not in the immediate area of unprotected skin.

Nearly all dust particles, pollutants and odors are filtered out before outside air enters the interior through the air distribution system.

The air conditioning will not engage (no cooling) if the **A/C** mode is deactivated (> page 192).

Warning!



Follow the recommended settings for heating and cooling given on the following pages. Otherwise the windows could fog up, impairing visibility and endangering you and others.



Severe conditions (e.g. strong air pollution) may require replacement of the filter before its scheduled interval.

A clossed filter will reduce the air vol-

A clogged filter will reduce the air volume to the interior.

If the vehicle interior is hot, ventilate the interior before driving off. The climate control will then adjust the interior temperature to the set value much faster.

Keep the air intake grille in front of the windshield free of snow and debris.

When the retractable hardtop is closed, do not obstruct air flow by placing objects on the air flow-through exhaust slots below the rear window.

Automatic climate control*

Deactivating the climate control system

Deactivating

▶ Press button OFF (▷ page 192). The indicator lamp on the button comes on.



When the climate control system is switched off, the outside air supply and circulation are also switched off. Only choose this setting for a short time. Otherwise the windows could fog up.

Reactivating

- ▶ Switch on the ignition (> page 36).
- ▶ Press button OFF (▷ page 192) again. The previous settings are once again in effect.

or

The indicator lamp on the button comes on. Air volume and air distribution are adjusted automatically.

Press button AUTO (⊳ page 192).

Operating the climate control system in automatic mode



When operating the climate control system in automatic mode, you will only rarely need to adjust the temperature, air volume and air distribution.

In automatic mode, cooling with dehumidify is switched on. This function can be switched off if necessary.

Activating

Press button AUTO (▷ page 192) while the engine is running.

The indicator lamp on the button comes on. The air volume and air distribution are adjusted automatically.

► Use temperature controls (4) and (6) or (1) and (12) (▷ page 192) to separately adjust the air temperature on each side of the passenger compartment.

The temperature of the vehicle interior is adjusted automatically.

Deactivating

Press button AUTO (▷ page 192) again.

The indicator lamp on the button goes out. The air volume changes to level **2** and the air distribution changes to . Automatic control of air volume and air distribution is switched off.

Setting the temperature

Use temperature controls ④ and ⑫ for the left side or ⑥ and ⑪ for the right side (▷ page 192) to separately adjust the air temperature on each side of the passenger compartment. You should raise or lower the temperature setting in small increments, preferably starting at 72°F (22°C). The climate control will adjust to the set temperature as fast as possible.

Increasing

Press temperature button(s)
④ and/or ⑥ (▷ page 192) until the desired temperature appears in the control panel display ⑭ (▷ page 192).

The automatic climate control system will correspondingly adjust the interior air temperature.

Decreasing

Press temperature button(s)
 (1) and/or (12) (▷ page 192) until the desired temperature appears in the control panel display (14) (▷ page 192).

The automatic climate control system will correspondingly adjust the interior air temperature.

Automatic climate control*

Adjusting air distribution

Use the air distribution control (8) (▷ page 192) to adjust the air distribution. The following symbols are found on the control:

Symbol	Function
゙゙゙゙゙゙゙゙゙゙゙゙	Directs air through the center, side and cockpit air vents
نب	Directs air to the windows and side air vents
† ≂i	Directs air into the entire vehicle interior
1,4	Directs air to the footwells and side air vents

Turn air distribution control (8)
 (▷ page 192) to the desired position.

The indicator lamp on the button (⊳ page 192) goes out.

The automatic air distribution is switched off. The air distribution is controlled according to the selected control setting.



You can also turn the control to a position between two symbols.

Opening the cockpit air vent and center air vents

► Turn thumbwheels ⑤ and ⑩ (▷ page 190) to the first stop and turn thumbwheel ⑧ (▷ page 190) upward all the way.

The cockpit air vent (7) and the center air vents (4), (6), (9) and (11) are open.

Turn thumbwheels ⑤ and ⑩
 (▷ page 190) upward all the way.

Only center air vents (6) and (9) are open.

Closing the cockpit air vent and center air vents

► Turn thumbwheels (5), (8) and (10) (> page 190) downward.

The cockpit air vent and the center air vents are closed.

Opening and closing side air vents

► Turn thumbwheels ① and ⑭ (▷ page 190) in the corresponding direction.

Side air vents ② and ③ are open or closed.

Adjusting air volume

Use button AUTO (> page 192) for automatic mode or air volume control () (> page 192) to adjust air volume manually.

Eleven blower speeds are available.

Turn air volume control ①
 (▷ page 192) to the desired position.

The indicator lamp on the button (> page 192) goes out.

The automatic operation of air volume switches off.

Defrosting windshield

You can use this setting to defrost the windshield, for example if it is iced up. You can also defog the side windows.



Keep this setting selected only until the windshield or the side windows are clear again.

Automatic climate control*

Activating

The air conditioning switches automatically to the following functions:

- cooling on to dehumidify
- maximum blowing and heating power
- air flows onto the windshield and the front side windows

Deactivating

▶ Press button (▷ page 192) again. The indicator lamp on the button goes out.

The previous settings are once again in effect.



The cooling remains switched on.

Windows fogged on the outside



Keep this setting selected only until the windshield is clear again.

- Switch the windshield wipers on (▷ page 56).
- ► Press button AUTO (> page 192).

 The indicator lamp on the button come on. Air distribution and air volume are adjusted automatically.

If the automatic air distribution and air volume are switched off:

► Turn air distribution control (8) to position (> or (> page 192).

Maximum cooling MAX COOL

When operating the automatic climate control system in automatic mode and there is a high need for cooling, MAX COOL is activated. This provides the fastest possible cooling of the vehicle's interior (when retractable hardtop is closed).

MAX COOL will appear in display (♠) (▷ page 192).

Air recirculation mode

Switch to air recirculation mode to prevent unpleasant odors from entering the vehicle from the outside (e.g. before driving through a tunnel). This setting cuts off the intake of outside air and recirculates the air in the interior.

Warning!



Fogged windows impair visibility, endangering you and others. If the windows begin to fog on the inside, switching off the air recirculation mode immediately should clear interior window fogging. If interior window fogging persists, make sure the air conditioning (\triangleright page 187) is activated, or press button

Activating

► Press button (▷ page 192).

The indicator lamp on the button comes on.



The air recirculation mode activates automatically at high outside temperatures.

The indicator lamp on button sis not lit when the air recirculation mode is automatically switched on.

A quantity of outside air is added after approximately 30 minutes. ▷▷

 $\triangleright \triangleright$

Warning!



Never operate the side windows if there is the possibility of anyone being harmed by the closing procedure.

In the event that the procedure causes potential danger, the closing of the door windows can be immediately halted by releasing the button or by pressing the respective power window switch.

The closing of the rear side windows can be immediately halted by releasing the button.



If you press button and keep it pressed, the side windows will close.

The closing of the windows can be immediately halted by releasing button .

Deactivating

Press button (▷ page 192) again. The indicator lamp on the button goes out.



The air recirculation mode is deactivated automatically:

- after 5 minutes if the outside temperature is below approximately 41°F (5°C)
- after 5 minutes if the air conditioning is turned off (▷ page 200)
- after 30 minutes if the outside temperature is above approximately 41°F (5°C)



If you press button and keep it pressed, the side windows will open.

The opening of the windows can be immediately halted by releasing button .

Air conditioning

The cooling function, only operational when the engine is running, cools the vehicle interior down to the selected temperature. The cooling function also dehumidifies the air in the vehicle interior, thus preventing the windows from fogging up.

The air conditioning uses the refrigerant R134a. This refrigerant is free of CFCs which are harmful to the ozone layer.

Warning!



If you turn off the cooling function, the vehicle will not be cooled when weather conditions are warm. The windows can fog up more quickly. Window fogging may impair visibility and endanger you and others.



Condensation may drip from underneath the vehicle. This is normal and not an indication of a malfunction.

Deactivating

It is possible to deactivate the air conditioning (cooling) function of the automatic climate control system. The air in the vehicle will then no longer be cooled or dehumidified.

► Press button A/C (> page 192).
The indicator lamp on the button goes out.

Activating

Moist air can fog up the windows. You can dehumidify the air with the air conditioning.

Press button A/C (▷ page 192).
The indicator lamp on the button comes on.

Automatic climate control*

Residual heat and ventilation

With the engine switched off, it is possible to continue to heat or ventilate the interior for up to 30 minutes. This feature makes use of the residual heat produced by the engine.



How long the system will provide heating depends on

- the coolant temperature
- the temperature set by the operator

The blower will run at speed setting 1 regardless of the air volume control setting.

Activating

- ▶ Switch off the ignition (> page 36).
- ► Press button REST (> page 192).

The indicator lamp on the button comes on. The display in the automatic climate control panel remains switched off.

Deactivating

► Press button REST (> page 192) again.

The indicator lamp on the button goes out.



The residual heat is automatically turned off:

- when the ignition is switched on (▷ page 36)
- after about 30 minutes
- if the battery voltage drops

▼ Audio system

Audio and telephone*, operation

These instructions are intended to help you become familiar with your Mercedes-Benz audio system. They contain useful tips and a detailed description of the user functions.

Warning!



In order to avoid distraction which could lead to an accident, the driver should enter system settings with the vehicle at a standstill and operate the system only when road and traffic conditions permit. Always pay full attention to traffic conditions first before operating system controls while driving.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your car is covering a distance of 44 feet (approximately 14 m) every second.

Operating safety

Warning!



Any alterations made to electronic components can cause malfunctions.


The radio, amplifier, CD changer*, satellite radio* and telephone* are interconnected. When one of the components is not operational or has not been removed/replaced properly, the function of other components may be impaired.

This condition might seriously impair the operating safety of your vehicle.

We recommend that you have any service work on electronic components carried out by an authorized Mercedes-Benz Center.

Audio system

Operating and display elements



Audio system

	Item	Page
1	CD changer mode selector	219
2	Single CD mode selector	222
3	Radio mode selector	
4	Mute function (radio)	212
	Pause (CD)	229
5	Volume distribution	208
6	Sound settings	207
7	Display	
8	Alphanumeric keypad	

	Item	Page
9	Speed dialing memory (telephone*) in descending order	
10	Accepting a call (telephone*)	235
11)	Telephone* mode selector	229
12	Speed dialing memory (telephone*) in ascending order	231
(13)	Terminating a call (telephone*)	235
14)	CD slot	
(15)	CD ejection	222

	Item	Page
16	Soft keys	206
17	Volume	207
18	Switching on/off	206
19	Manual tuning / seek tuning (radio)	211
	Track search, reverse (CD)	228
20	Manual tuning / seek tuning (radio)	211
	Track search, fast forward (CD)	228

Audio system

Button and soft key operation

In these instructions, the alphanumeric keypad (right side of radio panel) and the function buttons (left side of radio panel) are referred to as "buttons". The four keys below the display panel are referred to as "soft keys".



Do not press directly in the display face. Otherwise, the display will be damaged.

Operation

Switching the unit on/off

Switching on

- Turn the SmartKey in the starter switch to position 1 or 2 (▷ page 36).
- If the audio system was on as you removed the SmartKey from the starter switch, the audio system will automatically come back on as you turn the SmartKey to position 1 or 2.

or

Press button.



If the radio is switched on without the SmartKey in the starter switch, it will automatically switch off again after approximately 30 minutes.

If your vehicle is equipped with a telephone, the display may prompt you to enter your PIN (GSM network) or code (TDMA or CDMA network).

Switching off

► Remove the SmartKey from the starter switch.

or



Should excessively high temperatures occur while the audio system is being operated, the display will dim. If temperatures continue to rise, HIGH TEMP will appear in the display, after which the audio system will be switched off for a cooling-down period.

Adjusting the volume

► Turn rotary control of button.

The volume will increase or decrease depending on the direction turned.



If your vehicle equipment includes a Mercedes-Benz specified mobile telephone*, you can adjust its volume separately from the volume of the audio system while the telephone is being used.

Adjusting sound functions

The bass and treble functions are called up by pressing the button.

Settings for bass and treble are stored separately for the AM and FM wavebands, weather band, CD mode and telephone mode.

Bass

► Press JP button repeatedly until BASS appears in the display.



 Press + or - soft key to increase or decrease tone level accordingly.

or

► Press RES soft key briefly to reset bass tones to their center level.

The radio switches back to the standard radio menu 8 seconds after the last soft key is pressed.

Audio system

Adjusting treble

Press JP button repeatedly until TREBLE appears in the display.



 Press + or - soft key to increase or decrease tone level accordingly.

or

 Press RES soft key briefly to reset treble tones to their center level.

The radio switches back to the standard radio menu 8 seconds after the last soft key is pressed.

Returning sound functions to factory settings

Press JP button to call up settings menu in the display.



 Press RES soft key briefly; the respective sound function is reset to its center level.

or

 Press and hold RES soft key until RESET appears in the display.

The sound settings for bass and treble are returned to their center level and the volume is set to a predefined level.

The radio switches back to the standard radio menu 4 seconds after the last soft key is pressed.

Adjusting balance

► Press ♦ button.

BALANCE appears in the display.



▶ Press <<< or >>> soft key.

The volume is distributed between the left and right sides of the vehicle.

or

► Press RES soft key briefly.

The balance is reset to its center level.

The radio switches back to the standard radio menu 8 seconds after the last button is pressed.

Returning volume distribution to factory settings

► Press button to call up settings menu in the display.



 Press RES soft key briefly; the respective volume distribution is reset to its center (flat) level.

or

Press and hold RES soft key until RESET appears in the display.

The volume distribution settings for the balance is set to the center level.

The radio switches back to the standard radio menu 4 seconds after the last soft key is pressed.

Telephone* muting

If your vehicle equipment includes a Mercedes-Benz specified mobile telephone*, you can adjust its volume separately from the volume of the audio system while the telephone* is being used.

Radio operation

Selecting radio mode

► Press RADIO button.

Calling up wavebands

You can choose from among the FM, AM and WB wavebands.

Weather band (⊳ page 213).



FM waveband: 87.7.....107.9 MHz

AM waveband: 530.....1710 KHz

Audio system

Calling up wavebands for radios without SAT

▶ Press FM or AM soft key to switch between FM and AM.

The FM and AM wavebands are called up one after another.

or

▶ Press WB soft key.

The weather band menu is called up.

The waveband currently selected appears in the upper left-hand corner of the display.

Calling up wavebands for radios with SAT

 Press FM, AM or WB soft key repeatedly until desired waveband has been selected.

The FM, AM and WB wavebands are called up one after another.

The waveband currently selected appears in the upper left-hand corner of the display.

Selecting a station

The following options are available for selecting a station:

- Direct frequency input (> page 211)
- Manual tuning (> page 211)
- Automatic seek tuning (▷ page 211)
- Scan search (▷ page 211)
- Station memory (▷ page 212)
- Automatic station memory (Autostore)
 (▷ page 212)

The station search proceeds in the following frequency increments:

- 0.2 MHz in FM range
- 10 kHz in AM range

Direct frequency input

Select desired waveband.



- ► Press ★ button.
- ► Enter desired frequency with buttons 11 to 21.



You can only enter frequencies within the respective waveband.

If a button is not pressed within 4 seconds, the radio will return to the last station tuned.

Manual tuning

- Select desired waveband.
- ► Press or ▷► button for approx. 3 seconds.
- Press button repeatedly until desired frequency has been reached.

Step-by-step station tuning takes place in ascending or descending order. Each time the button is pressed, the radio tunes further by 0.2 MHz. During manual tuning, the radio is muted.

Automatic seek tuning

- Select desired waveband.



If no station is received after two consecutive scans of the complete frequency range, then the scan stops at the frequency from which it began.

Scan search

- Starting scan search
 - Select desired waveband.



▶ Press SC soft key.

SC will appear in the display. The radio briefly (approximately 8 seconds) tunes in all receivable stations on the waveband selected.

- Ending scan search
 - ► Press SC soft key or 🔼 or 🖂

The station last played will be selected and SC disappears from the display.

Audio system

Station memory

You can store ten AM and ten FM stations in the memory.

- · Storing stations
 - ► Tune in desired station.
 - ▶ Press and hold desired station button to until a brief signal tone is heard.

The frequency is stored on the selected station button.

- Calling up stations
 - Press desired station button to to briefly.

Autostore - automatic station memory

The Autostore memory function provides an additional memory level. The station memory for manually stored stations is not overwritten.

 Calling up Autostore memory level and storing stations



Press AS soft key briefly.

The radio switches to the Autostore memory level. AS and SEARCH appear in the display and the radio finds the ten stations with the strongest signals. These stations are stored on the station buttons to to to in order of signal strength.

- Calling up stations
 - Press desired station button to 0...
- Leaving the Autostore memory level
 - ▶ Press FM or AM soft key briefly.

Interrupting radio mode

The radio mode is interrupted by an incoming call on the telephone* (> page 235).

- Mute on
 - ▶ Press ♥ button.

The radio mode is interrupted and MUTED appears in the display.

- Mute off
 - ▶ Press ⋈ button.

The radio mode is again active.

Weather band



Press WB soft key.

The weather band station last received is tuned in.

Selecting a weather band station directly

► Select desired weather band station with buttons 11 to 7.

If a station cannot be tuned in, a search is automatically started.

Search

► Press dd or ► button to tune in the next receivable weather band station.



If no weather band station is received after three consecutive scans of the complete frequency range, then the scan stops at the channel with which it began and NO WB FOUND appears in the display.

If this happens, switch back to standard radio mode.

Scan search

- Starting scan search
 - ▶ Press SC soft key.

SC will appear in the display. The radio briefly (approximately 8 seconds) tunes in all receivable weather band stations.

- Ending scan search
 - ► Press SC soft key or 🔼 or 🖂

The weather band station last played will be selected and SC disappears from the display.

Introduction to satellite radio* (USA only)

SIRIUS satellite radio provides 100 channels of digital-quality radio, among others music, sports, news, and entertainment, free of commercials. SIRIUS satellite radio uses a fleet of high-power satellites to broadcast 24 hours per day, coast to coast, in the contiguous U.S.

This diverse, satellite-delivered programming is available for a monthly subscription fee.

For more information and service availability, call the SIRIUS Service Center (> page 218), or contact www.siriusradio.com



Additional satellite radio equipment and a subscription to a satellite radio service provider are required for the satellite radio operation described here.

Contact an authorized Mercedes-Benz Center for details and availability for your vehicle.

Note that categories and channels shown in illustrations are dependent on programming content delivered by the service provider. Programming content is subject to change. Therefore, channels and categories shown in illustrations and descriptions contained in this manual may differ from the channels and categories delivered by the service provider.



Satellite radio service may be unavailable or interrupted from time to time for a variety of reasons, such as environmental or topographic conditions and other things beyond the service provider's or our control. Service might also not be available in certain places (e.g., in tunnels, parking garages, or within or next to buildings) or near other technologies.

Program categories

The channels are categorized. Categories allow you to tune to stations broadcasting a certain type of program (category mode) (> page 216).

Calling up the SAT main menu

► Press SAT soft key.

SAT is displayed in the upper left-hand corner of the display.

Prior to activation of the satellite radio service (▷ page 215).

After activation of satellite radio service (▷ page 215).

Prior to activation of the satellite radio service



The telephone number of the SIRIUS Service Center (888-539-7474) is displayed.

▶ Press ESN soft key.

The twelve-digit electronic serial number (ESN) of the SAT tuner* installed in your vehicle is displayed.

This information is required to call the SIRIUS Service Center for an activation request.



Credit card information may also be required for your application.

The activation process takes approximately 5 to 10 minutes after calling the SIRIUS Service Center.

After activation of the satellite radio service

The satellite radio main menu appears. The radio station selected last is audible, provided it can be received.



The system will tune to a default station if no station had been selected previously.



The first channel 001 is called up and the PTY system changes to All categories.

If no station can be received, ACQUIRING appears in the display.

If the Satellite radio service is not activated, ACQUIRING will also appear in the radio display and NO SAT will appear in the multifunction display.

Audio system

Selecting a station

The following options are available:

- Selecting a station using the selected category (> page 217).
- Tuning via station presets (> page 216).
- Tuning via scan search (> page 217).
- Tuning via manual channel input (▷ page 216).
- Tuning via the program category list (> page 216).

Tuning via station presets

Ten satellite radio station presets are available.

You can access the presets via number keys.

Accessing via number keys

► Enter number of preset you wish to select, e.g. ■1.

The radio plays the station stored under this number and the PTY function changes to the category corresponding to the station.

Tuning via manual channel input



Example: tuning in channel 16

▶ Press \star .

Input line appears in the main radio menu.

Use number keys to enter desired channel within 8 seconds, e.g. 1 6.6.

The system tunes to channel 16.

The station you have selected begins to play.



You can only enter available channel numbers.

Tuning via the program category list

The category list contains all currently receivable categories of programs. It is arranged alphabetically.

- Selecting a category
 - ▶ Press PTY soft key.



The current PTY category of the station is displayed.

► Press <<< or >>> soft key.

This switches between the individual categories.

When changing the category, the channel selected last in the new category becomes audible.

The system will automatically switch to a station of the selected category if the currently selected station is not of the selected category. Otherwise, the currently selected station remains tuned.

 Tuning a station within the selected category

The channels identified for the currently selected category are arranged numerically. Only one entry is visible at a time.

► Press do or by button briefly.

The next station within the category is started.

or

Press and hold
or by button for approx.
3 seconds until desired station has been reached.

Tuning via scan search

Scan search is characterized as follows:

- Scan search plays a channel for approx. 8 seconds and then skips to the next channel within the current category.
- Scan search can be terminated manually.
- ▶ Press SC soft key.

The search starts. SC appears in the display.

▶ Press SC soft key again.

The search stops.

Audio system

Obtaining additional text information

Additional text information (artist, title) related to the current channel can be displayed.

- Press INF soft key.
 The title being played is displayed.
- Press INF soft key again.

The name of the artist performing the title being played is displayed.



If a button is not pressed within 4 seconds, the radio will return to the standard display.

Storing stations

- ► Tune in desired station.
- Press and hold desired station button to until a brief signal tone is heard.

The frequency is stored on the selected station button.

The radio saves the current station at the memory preset selected. The memory preset selected appears in the status line, e.g. S3.



There are ten presets available.

An existing entry is overwritten in the memory list when a new entry is given.

Calling up the ESN information menu

- Press INF soft key.
- ▶ Press ESN soft key.

The twelve-digit electronic serial number (ESN) of the SAT tuner* installed in your vehicle is displayed.

▶ Press RET soft key to exit the menu.

CD mode

Safety precautions

Warning!



The single CD player and the CD changer* are Class 1 laser products. There is a danger of invisible laser radiation if the housing is opened or damaged.

Do not open the housing. The single CD player and the CD changer* do not contain any parts that can be serviced by the user. For safety reasons, have any service work which may be necessary performed only by qualified personnel.

Warning!



In order to avoid distraction which could lead to an accident, the driver should insert CDs with the vehicle at a standstill and operate the audio system only if permitted by road, weather and traffic conditions.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your car covers a distance of 44 feet (approximately 14 m) every second.

General notes

The system may not be able to play audio CDs with copy protection.

Playing copied CDs may cause malfunctions during playback.



The audio system plays both CD-Rs and CD-RWs with audio data.

!

If you affix stickers to the CDs, they can become warped due to the heat that develops in the CD drive or CD changer.

In certain situations, the CDs can then no longer be ejected and cause damage to the drive. Such damage is not covered by the Mercedes-Benz Limited Warranty.



Your CD drive or CD changer has been designed to play CDs which correspond to the EN 60908 standard. You can therefore only use CDs with a maximum thickness of 1.3 mm.

If you insert thicker data carriers, e.g. ones that have data on both sides (one side with DVD data, the other side with audio data), they cannot be ejected and will damage the drive.

Audio system

Do not use CDs with an 8 cm diameter, not even with a CD adapter. Attempting to play CDs with an 8 cm diameter or playing such CDs with an adapter may cause damage to the CD drive. Such damage is not covered by the Mercedes-Benz Limited Warranty.

Should excessively high or low temperatures occur while in CD changer mode*, CD TEMP will appear in the display, and the CD will be muted until the temperature has reached an acceptable level for the system to continue operation.

The single CD player and the CD changer* play audio CDs.

Tips on handling CDs

- Handle CDs carefully to prevent interference during playback.
- Avoid scratches, fingerprints and dust on the CDs.
- Do not write on CDs or apply any labels or other material to them.
- Clean CDs from time to time with a commercially available cleaning cloth. Never wipe the CD in a circular motion; instead, wipe it in a straight line starting in the center and moving outward. Do not use solvents, anti-static sprays, etc. for cleaning.
- Replace the CD in its case after use.
- Protect CDs from heat and direct sunlight.

MP3

The CD changer* can play audio CDs as well as CDs with MP3 files.

Information on MP3 data carriers



CD media, CD burning software and CD writers are available in great variety. Due to this variety, it cannot be guaranteed that the CD changer will be able to play every user-written CD.

The burning process can lead to data errors and aging of the medium may result in data loss. Therefore, the CD changer may be restricted in its ability to play MP3 data carriers; it may play them with reduced sound quality, or it may not be able to play them at all.

Problems may be encountered during playback of user-written CDs with a storage capacity of more than 700 MB. These CDs do not meet valid standards as of this printing.

Compatible MP3 data carriers

The CD changer can read the following data carriers in MP3 mode:

- CD-DA
- CD-R
- CD-RW

Compatible file systems and compression methods

Use Romeo or Joliet. Depending on file format used, up to 128 characters are possible.

The following compression methods are compatible:

- MP3
- WMA
- WAV

Compatible bit and sampling rates

Fixed and variable bit rates of up to 320 kBit/s are possible.

The following table lists possible sampling rates:

MPEG1	44.1 KHz, 48 KHz,
Audio Layer3	32 KHZ
MPEG2	22.5 KHz, 24 KHz,
Audio Layer3	16 KHz
MPEG2.5	11.025 KHz,
Audio Layer3	12 KHz, 8 KHz
WMA	32 KHz, 44.1 KHz, 48 KHz



Only use MP3 tracks with a bit rate of 128 kBit/s or higher and with the specified sampling rates.

The use of rates other than those specified may lead to noticeably inferior sound quality.

Information on copyright

The music tracks that you create for use in MP3 mode or that you play in MP3 mode are subject to copyright laws under applicable international and national regulations.

In many countries, the reproduction of copyrighted materials is not permitted, even if only for personal use, without the express prior consent of the copyright holder.

Please check the current copyright laws for your country and comply with them.

These restrictions do not apply, for example, to your own compositions and recordings, or for recordings for which authorization has been obtained from the copyright holder.

Audio system

MP3 playback

You can play an MP3 CD on the CD changer* as you would any standard audio CD. All of the functions described for the CD changer also apply for the playback of MP3 CDs. Keep in mind that the single CD player in the audio system unit is not able to read MP3 CDs.

The first 99 tracks on the CD, including tracks in subdirectories, are recognized and played. Any additional tracks will not be played.



Due to the branched data structure, playback of the first track may be delayed slightly.

Operating the single CD player in the audio system unit

Loading a CD

The single CD player in the audio system unit has capacity for one CD. The CD slot for loading the drive is located underneath the soft keys.

- Make sure the system is switched on.
- Insert CD into CD slot. The label side of the CD must face upwards.

The system automatically pulls the CD into the CD slot. The audio CD begins to play.



If a CD is already loaded, it must be ejected before inserting a new CD. Inserting a second CD in the slot with another CD still loaded will cause damage to the CD drive not covered by the Mercedes-Benz Limited Warranty.



If a CD has been inserted incorrectly or cannot be read, WRONG CDO will appear in the display.

Ejecting a CD

- ► Make sure the system is switched on.
- ▶ Press button.

The system ejects the CD. Remove CDO will appear in the display.

Remove CD from slot.

With the CD removed, NO CD will appear in the display.




If you do not take the CD out of the CD slot within approx. 15 seconds, the system automatically pulls the CD back in and plays it.

If a CD is pulled back in, press button, the CD will then be ejected.

Operational readiness of CD changer*

If a CD changer has been installed in the vehicle, it can be operated from the front control panel of the audio system.

The CD changer is located in the glove box.



- (1) CD loading slot
- 2 Magazine slot button

A magazine is integrated into the CD changer as a fixed element. It holds a maximum of six CDs.

The CD changer features six magazine slot buttons ② for controlling the loading procedure.

A light-emitting diode in the buttons shows the status of the corresponding magazine slot.

CD loading slot ① is above buttons ② and is used to load CDs.

LEDs	
no LED is lit	Magazine slot is empty.
green LED flashes	CD can be loaded.
red LED is lit	Magazine slot is in use.
red LED flashes	CD is being ejected.

Loading the CD magazine




If a CD has been inserted incorrectly or cannot be read, ${\tt WRONG\ CD0}$ will appear in the display.

Loading one or more CDs interrupts the CD playback.

Loading single CDs

▶ Open the glove box.



- 1 CD loading slot
- 2 Magazine slot button



Audio system

⇒⇒ Briefly press button ② for the empty magazine slot that you would like to use.

The light-emitting diode in the magazine slot button flashes in green.

INSERT CD appears in the display along with the slot number.

The flashing light indicates that the CD changer is ready to receive a CD.

- Insert an audio CD into CD loading slot ① within 5 seconds, label side up. The CD is pulled in and played.
- Close the glove box.

Loading several CDs

- Open the glove box.
- Press button ② of an empty magazine slot for more than 2 seconds.

The light-emitting diodes in all the magazine slot buttons light up several times in green, and ALL LOAD appears in the display.

Wait until the light-emitting diode for the first magazine slot flashes in green.

The flashing light indicates that the CD changer is ready to receive a CD.

 Insert an audio CD into CD loading slot ① within 5 seconds, label side up.

The CD is pulled in and the light-emitting diode in the magazine slot button lights up in red. The magazine slot is loaded.

The light-emitting diode in the next available magazine slot button flashes in green. The CD changer is ready to receive the next CD.

 Repeat the previous step until all six magazine slots are loaded.

Once all magazine slots are loaded, the CD in the sixth magazine slot is played.



If, for example, you only want to load magazine slots 1 - 4 instead of all six, simply do not insert a fifth CD into the CD loading slot. The CD changer will first try to load a CD but will then cancel the procedure, after which the radio will play the fourth CD.

Close the glove box.

Ejecting CDs



The CD playback is interrupted while one or more CDs are being ejected.

Ejecting single CDs

- ▶ Open the glove box.
- Briefly press desired magazine slot button.

The light-emitting diode in the magazine slot button flashes in red. The corresponding CD is ejected. EJECTING CD appears in the display along with the magazine slot number.

 Remove CD from CD loading slot within 15 seconds.

If after removing a single CD no other CDs remain loaded in the magazine, MAG. EMPTY appears in the display.



If you do not take the CD from the CD loading slot within 15 seconds, the CD changer will automatically pull the CD back in. The system will then play the CD.

If you are listening to a CD while ejecting another CD from the changer:

The Audio system stops playing the CD while another CD is being ejected. Once the CD has been ejected, the Audio system will continue playing where it left off.

Close the glove box.

Ejecting all loaded CDs

- ▶ Open the glove box.
- ▶ Press the button of a loaded magazine slot for more than 2 seconds.

The light-emitting diodes in all magazine slot buttons light up several times in red, and ALL EJECT appears in the display.

The CD changer ejects the CDs one after another.

The light-emitting diode for the magazine slot being emptied flashes in red.

► Take corresponding CD from CD loading slot within 15 seconds.

The ejection procedure is finished once you have removed all CDs from the CD loading slot or if the CD changer cancels the procedure.

With all CDs removed from the magazine, MAG. EMPTY appears in the display.



 $\triangleright \triangleright$



If you do not take the CD from the CD loading slot within 15 seconds, the CD changer will automatically pull the CD back in. The system will then play the CD.

With all CDs ejected, press the RADIO button to switch back to the radio mode.

Close the glove box.

Playing CDs

Single CD player in the audio unit

► Press CD button.

CDO will appear in the upper left-hand corner of the display.

The CD will resume playback at the point where it was switched off.

CD changer*

Press cpc button.

CD and the selected magazine slot number appear in the upper left-hand corner of the display.

If you have not removed a CD since the last time the CD audio source was activated, the last CD listened to will begin to play at the point where it was switched off.

After the last track on a CD has finished, the next CD is automatically played.

Playing tracks

You have the following options:


- Audio system with CD changer*: selecting CDs
- Direct track entry
- Track skip forward/reverse
- Fast forward/reverse
- Scan
- Random tracks
- Repeat track

Selecting CDs in the audio unit with CD changer*



 You can select from among the inserted CDs with buttons





The magazine slot number of the selected CD appears next to CD in the display, and the number of the currently played track appears next to TRACK.



If there is no CD in the selected magazine slot, NO CD appears in the display with the corresponding slot number.

Direct track entry



You can make a direct selection from among the tracks on a CD.

- ► Press ★ button.
- Enter track number using buttons to ...

The number of the track being played appears next to TRACK in the display.

You can only enter available track numbers.

Skipping tracks forward/backward

- Skipping tracks forward
 - ► Press ▶ button briefly.

 The next track will be played.
- Skipping tracks backward
 - ► Press dutton briefly.

If the track has been playing for more than 10 seconds, the unit skips back to the beginning of the track currently playing. If less than 10 seconds have been played, the unit skips back to the beginning of the previous track.

Pressing the or by button repeatedly will result in multiple tracks being skipped.

Audio system

Fast forward/reverse

- Fast forward
 - ▶ Press and hold ▶▶ button until desired point has been reached.
- Reverse
 - ▶ Press and hold desired point has been reached.



The track number and the relative time of the track is shown in the display during the search.

Scan

- Starting scan
 - ▶ Press SC soft key.

SC will appear in the display.

Each track on the current CD will be played for approx. 8 seconds in ascending order.

- Ending scan
 - ► Press SC soft key or 🔼 or 🔀

Random play

The random function (RDM) plays the tracks of the current CD in random order.



When you start the RDM function, the RPT function is automatically switched off.

- Switching on random
 - Press RDM soft key.
 RDM appears in the display.

A randomly selected track is played.

- Switching off random
 - ► Press RDM soft key again.

Repeat

The track being played is repeated until the repeat function is switched off.



When you start the RPT function, the RDM function is automatically switched off.

- Switching on repeat
 - Press RPT soft key.
 RPT appears in the display.
- Switching off repeat
 - ▶ Press RPT soft key again.

Pause function

The CD changer mode is interrupted by an incoming call on the telephone* (▷ page 235).

Switching on pause function



▶ Press button.

The CD changer mode is interrupted and PAUSE appears in the display.

- Switching off pause function
 - ▶ Press 🛱 button.

The CD changer mode is active again.

Track and time display



▶ Press T soft key.

The number of the track being played and the elapsed playing time appear in the display.

▶ Press T soft key again.

The total number of tracks and the total playing time of the CD appear in the display.

► Press T soft key.

The standard CD playback menu appears in the display.

GSM network phones

Using your Mercedes-Benz specified mobile telephone*, a number of functions and operating steps can be performed and displayed in the audio system display.

Warning!



A driver's attention to the road must always be his/her primary focus when driving. For your safety and the safety of others, we recommend that you pull over to a safe location and stop before placing or taking a telephone call. If you choose to use the telephone ¹ while driving, please use the hands-free device and only use the telephone when weather, road, and traffic conditions permit.

Some jurisdictions prohibit the driver from using a cellular telephone while driving a vehicle.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

Further operating instructions not covered here can be found in the operating instructions for the multifunction steering wheel and the cellular telephone*.

If your audio system is set up for telephone operation, the symbol will appear in the display.

When you insert your Mercedes-Benz specified mobile telephone* into the telephone cradle, you will be prompted to enter your PIN for 30 seconds (▷ page 231). This display disappears when you press any button.

When your mobile telephone* is inserted into the telephone cradle, you will see the reception strength in the upper right-hand corner of the display.

Switching on the telephone

Switching on the telephone

▶ Press TEL button.

If the telephone was previously switched off, PROCESSING appears in the display and you will then be prompted to enter your PIN.

Switching off the telephone

Press TEL button for approx.3 seconds.

PROCESSING appears in the display until the telephone is off. Afterward, PHONE OFF appears in the display.

Observe all legal requirements.

PIN entry



- ► Enter PIN number using buttons to ...
- ▶ If necessary, correct number entered with the CLR soft key. Press soft key briefly to delete the last digit entered; press soft key and hold to delete the complete number.
- ► Press 0K soft key after entering correct PIN.
- ► READY or ROAMING will appear in the display.



If the PIN is entered incorrectly three times, NEED PUK will appear in the display. Enter PUK via your telephone. Please refer to the separate telephone operating instructions for more information.

Adjusting the volume

The volume will increase or decrease depending on the direction turned.



The volume can be adjusted separately for telephone mode and audio mode.

Adjusting sound

► Adjust sound during a telephone call. Sound adjustment (▷ page 207).

Placing a call

Entering a telephone number and starting the dialing process



► Enter desired telephone number using buttons ■1 to ■2.

The number can have up to 32 digits, but only twelve of these are visible in the display.

 $\triangleright \triangleright$

Audio system

- ▷▷► If necessary, correct number entered with the CLR soft key. Press soft key briefly to delete the last digit entered; press soft key and hold to delete the complete number.
 - ► After correct telephone number has been entered, press button.



If the telephone number has been saved together with a name in the telephone book, the name will appear in the display.

Phone book

The numbers stored in the phone book of the telephone can be called up either by name or number.

In addition, incoming calls are stored in the phone book.



This is only possible, however, when the call information transmitted includes the number of the person calling. If the telephone number is not transmitted, NO NUMBER will be stored in the phone book.

 Searching and calling up telephone book entries by name

You can access your mobile telephone's phone book using the audio system. You can access both the main entries and the sub-entries of your phone book.



- ► Press MEM soft key or press button or .

The stored entries are selected according to the alphabetical order of the initial letters (e.g. for S-Schneider, press button 7 four times).

or

▶ Press and hold button or ▼.

The system jumps from one initial letter to the next in ascending or descending order.

Press and hold button or until desired initial letter has been reached.

or

Audio system

Press button or repeatedly until desired entry has been reached.

The stored entries are selected in alphabetical order with the sub-entries



Several sub-entries can be stored for each main entry (name). These entries are marked by a corresponding abbreviation that appears in the upper left-hand corner of the display. The following abbreviations for sub-entries are possible:

CEL = Mobile phone

HOM = Home

WOR = Work

FAX = Fax

PAG = Pager

TEL = Main

▶ When you have selected a number, press button.

The call will be made.

- Viewing the telephone number of a telephone book entry
 - ► Search for desired entry.
 - ► Press NUM soft key.

The telephone number of the phone book entry appears in the display.

· Returning calls received



- ► Press MEM soft key or press button or .
- Press RCV soft key (received calls). The number of received calls and then the call last received appear briefly in the display.
- ➤ Select desired telephone number with button or .

The letter R and the number of the memory position appear in the upper left-hand corner of the display. The numbers are stored in the order of the calls received.

When you have selected a number, press button.

The call will be made.

Audio system

· Speed dial

If you have stored telephone numbers as speed dial numbers in your telephone, you can also enter these with buttons to contact the sequence on the radio head unit.

- ► Press desired button to briefly.
- Press button.The call will be made.
- Turbo dial

If you have stored telephone numbers as turbo dial numbers in your telephone, you can also enter these with buttons to contact the contact to contact the contact

▶ Press desired button 1 to 0 until the call is made.

Redial

If the number you have dialed is busy, you can again place calls to the last ten telephone numbers dialed using the redial function.



If you have activated the automatic redial function on your telephone, the number of the person being called is automatically redialed after a short waiting period if there is a busy signal. Refer to the separate operating instructions for the mobile telephone.

Manual redial



- Press button.
 - The telephone number last dialed will appear in the display.
- ► Select desired telephone number with button or .
 - The letter L and the number of the memory position appears in the left-hand corner of the display. The numbers are stored in the order of the calls received.
- When you have selected a number, press button.

The call will be made.

Audio system

Accepting an incoming call

If the telephone is active in the background (reception symbol is visible in the display), the audio source is muted when an incoming call is received. A ringing tone can be heard and the caller's telephone number, or the name under which the telephone number has been saved in the phone book, appears in the display. If the caller's number is not transmitted with the call, CALL will appear in the display.

▶ Press button.

The call is accepted.

Muting a call

It is possible to mute a call; the caller is then no longer able to hear you.

- Mute on
 - ► Press MUT soft key.
 - ► MIC MUTE will appear in the display.
- Mute off
 - ► Press MUT soft key again.

Terminating a call

Press button.

The current call is terminated and the muted audio source becomes active again.

Talking with two callers at the same time

If you wish to receive or place another call during an already active call, you can accept or place the second call and switch between the callers or combine them into one call. Note that the feature described here is dependent on availability from your mobile phone service provider.

- Placing/accepting a second call
 - Place new call by entering telephone number manually.
 - Press button.

You are connected to the second caller; the first caller is kept on hold.

or

Press button to accept a second call.



Audio system

 $\triangleright \triangleright$



You will be notified of the second call acoustically, but you will not see this in the display.

You are connected with the second caller; the first caller is kept on hold.

- Switching between calls
 - Press and buttons.
 This switches between the calls.
 The non-active call is kept on hold.
- Terminating a call
 - Press button.

The current call is terminated. You are again connected with the caller previously placed on hold.

- Combining two calls
 - ▶ Press and buttons.
 The calls are combined into one call.
- Terminating a combined call
 - ▶ Press button.

The connection to both callers is terminated.

TDMA or CDMA network phones

Warning!



A driver's attention to the road must always be his/her primary focus when driving. For your safety and the safety of others, we recommend that you pull over to a safe location and stop before placing or taking a telephone call. If you choose to use the telephone ¹ while driving, please use the hands-free device and only use the telephone when weather, road, and traffic conditions permit.

Some jurisdictions prohibit the driver from using a cellular telephone while driving a vehicle.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

Observe all legal requirements.

Audio system

Using your Mercedes-Benz specified mobile telephone*, a number of functions and operating steps can be performed and displayed in the audio system display.

Further operating instructions not covered here can be found in the operating instructions for the multifunction steering wheel and the mobile telephone*.

If your audio system is set up for telephone operation, the symbol will appear in the display.

When you insert your Mercedes-Benz specified mobile telephone* into the telephone cradle, you will be prompted to enter your PIN for 30 seconds (▷ page 237). This display disappears when you press any button.

When your mobile telephone* is inserted into the telephone cradle, you will see the reception strength in the upper right-hand corner of the display.

Switching on the telephone

Switching on the telephone

► Press **TEL** button.

If you have programmed an unlock code for the telephone, you must now enter the code.



- If necessary, correct number entered with the CLR soft key. Press soft key briefly to delete the last digit entered; press soft key and hold to delete the complete number.

► Press 0K soft key after entering correct code.

The telephone is unlocked. If you have entered an incorrect code, you must enter the correct code.

Switching off the telephone

Press TEL button for approx.3 seconds.

PROCESSING appears in the display until the telephone is off. Afterward, PHONE OFF appears in the display.

Adjusting the volume

► Turn rotary control of button during a telephone call.

The volume will increase or decrease depending on the direction turned.



The volume can be adjusted separately for telephone mode and audio mode.


Audio system

Adjusting sound

Adjust sound during a telephone call. Sound adjustment (▷ page 207).

Placing a call

Entering a telephone number and starting the dialing process



► Enter desired telephone number using buttons 11 to 20.

The number can have up to 32 digits, but only twelve of these are visible in the display.

- ► If necessary, correct number entered with the CLR soft key. Press soft key briefly to delete the last digit entered; press soft key and hold to delete the complete number.
- ► After correct telephone number has been entered, press button.



If the telephone number has been saved together with a name in the phone book, the name will appear in the display.

Phone book

The numbers stored in the phone book of the mobile telephone can be called up either by name or number.

In addition, incoming calls are stored in the phone book.



This is only possible, however, when the call information transmitted includes the number of the person calling. If the telephone number is not transmitted, NO NUMBER will be stored in the phone book.

• Searching and calling up phone book entries by name

You can access your mobile telephone's phone book with the audio system. You can access both the main entries and the sub-entries of your phone book.



- ► Press MEM soft key or press button or .
- Press desired numerical key to ...

The stored entries are selected according to the alphabetical order of the initial letters (e.g. for S-Schneider, press button four times).

or

▶ Press and hold button or ▼.

The system jumps from one initial letter to the next in ascending or descending order.

Press and hold button or until desired initial letter has been reached.

▶ Press button or repeatedly until desired entry has been reached.

The stored entries are selected in alphabetical order with the sub-entries.



Several sub-entries can be stored for each main entry (name). These entries are marked by a corresponding abbreviation that appears in the upper left-hand corner of the display. The following abbreviations for sub-entries are possible:

CEL = Mobile phone

HOM = Home

WOR = Work

FAX = Fax

PAG = Pager

TEL = Main

► When you have selected a number, press button.

The call will be made.

- Viewing the telephone number of a phone book entry
 - ► Search for desired entry.
 - ► Press NUM soft key.

The telephone number of the phone book entry appears in the display.

Returning calls received



or

Audio system

- ▶ Press MEM soft key or press button or .
- Press RCV soft key (received calls).
 The number of received calls and then the call last received appear briefly in the display.
- ► Select desired telephone number with button or .

The letter R and the number of the memory position appear in the upper left-hand corner of the display. The numbers are stored in the order of the calls received.

When you have selected a number, press button.

The call will be made.

Speed dial

If you have stored telephone numbers as speed dial numbers in your telephone, you can also enter these with buttons to contact the sequence.

- ► Press desired button to briefly.
- Press button.The call will be made.
- Turbo dial

If you have stored telephone numbers as turbo dial numbers in your telephone, you can also enter these with buttons to contact the contact on the radio unit.

▶ Press desired button 1 to 0 until the call is made.

Redial

If the number you have dialed is busy, you can again place calls to the last ten telephone numbers dialed using the redial function.



If you have activated the automatic redial function on your mobile telephone, the number of the person being called is automatically redialed after a short waiting period if there is a busy signal. Refer to the separate operating instructions for the mobile telephone.

Manual redial



Press button.

The telephone number last dialed will appear in the display.

► Select desired telephone number with button or .

The letter L and the number of the memory position appears in the left-hand corner of the display. The numbers are stored in the order of the calls received.

When you have selected a number, press button.

The call will be made.

Accepting an incoming call

If the telephone is active in the background (reception symbol is visible in the display), the audio source is muted when an incoming call is received. A ringing tone can be heard and the caller's telephone number, or the name under which the telephone number has been saved in the telephone book, appears in the display. If the caller's number is not relayed, CALL will appear in the display.

Press button.The call is accepted.

Muting a call

It is possible to mute a call; the caller is then no longer able to hear you.

- Mute on
 - ► Press MUT soft key.
 - ► MIC MUTE will appear in the display.
- Mute off
 - ► Press MUT soft key again.

Terminating a call

Press button.

The current call is terminated and the muted audio source becomes active again.

Audio system

Accepting a second incoming call

If you receive another call during an already active call, you can accept the second call and switch between the two.

- Accepting a second call
 - ► Place new call by entering telephone number manually.



You will be notified of the second call acoustically, but you will not see this in the display.

You are connected to the second caller; the first caller is kept on hold.

- Switching between calls
 - ► Press button.

This switches between the calls. The non-active call is kept on hold.

- Terminating a call
 - ▶ Press button.

The current call is terminated. The connection to the caller previously kept on hold is also interrupted; however, reconnection is indicated by an acoustic signal.

Placing a second call

If you wish to place another call during an already active call, you can place the second call and switch between the callers or combine them into one call. Note that this feature is dependent on availability from your mobile phone service provider.

- · Placing a second call
 - ► Place a new call by entering telephone number manually.
 - Press button.

You are connected to the second caller; the first caller is kept on hold.

- Terminating a call
 - Press button.

The current call is terminated. The connection to the caller previously kept on hold is also interrupted; however, reconnection is indicated by an acoustic signal.

- Combining two calls
 - ▶ Press button.

The calls are combined into one call.

- Terminating a combined call
 - Press button.

The connection to both callers is terminated.

Emergency calls "911"

The following describes how to dial a "911" emergency call using the audio system head unit when a Mercedes-Benz specified mobile phone* is inserted in the phone cradle. Unless otherwise specified, the descriptions refer to the audio system head unit.

Consult the separate telephone operating instructions that came with your mobile phone* for information on how to place a "911" emergency call on the mobile phone*.

Warning!



The "911" emergency call system is a public service. Using it without due cause is a criminal offense.

The following conditions must be met for a "911" emergency call:

- Telephone must be switched on.
- The corresponding mobile communications network must be available.



Emergency calls may not be possible with all telephone networks or if certain network services and/or telephone functions are active. Check with your local service providers.

If you cannot make an emergency call, you will have to initiate rescue measures yourself.

Audio system

GSM network phones

Placing a "911" emergency call using audio head unit with the phone locked

► Press **TEL** button to switch to telephone operation.

PIN? appears in the audio display.

- ► Enter 911 using the number keypad on the audio head unit.
- Press 0K soft key or button for dialing to begin.

DIALING appears in the audio display while the telephone establishes the connection.

► Wait until the emergency call center answers, then describe the emergency.

Placing a "911" emergency call using audio head unit with the phone unlocked

- ► Press **TEL** button to switch to telephone operation.
- ► Enter 911 using the number keypad on the audio head unit.
- Press button for dialing to begin.
 DIALING appears in the audio display while the telephone establishes the connection.
- ➤ Wait until the emergency call center answers, then describe the emergency.



If no SIM card is in the mobile phone, NO SERVICE appears in the audio display. In that case, you only can make an emergency call on the mobile phone itself, without the use of the head unit.

TDMA/CDMA network phones

Placing a "911" emergency call using audio head unit with the phone locked

- ► Press **TEL** button to switch to telephone operation.
 - CODE? appears in the audio display.
- Enter 911 using the number keypad on the audio head unit.
- ▶ Press 0K soft key or button for dialing to begin.
 - DIALING appears in the audio display while the telephone establishes the connection.
- Wait until the emergency call center answers, then describe the emergency.

Placing a "911" emergency call using audio head unit with the phone unlocked

- ► Press **TEL** button to switch to telephone operation.
- ► Enter 911 using the number keypad on the audio head unit.
- Press button for dialing to begin.
 DIALING appears in the audio display while the telephone establishes the connection.
- ► Wait until the emergency call center answers, then describe the emergency.

Power windows

Opening and closing the windows

The windows are opened and closed eletrically. Switches for operating the driver and passenger door windows are located on the driver's door. A switch for operating the passenger door window is located on the passenger door.

The door windows can also be operated using the retractable hardtop switch (▷ page 248). The rear side windows can only be operated using the retractable hardtop switch (▷ page 248) or the SmartKey* (▷ page 249).



- 1) Left window
- 2 Right window

Warning!



When closing the windows, make sure there is no danger of anyone being harmed by the closing procedure.

The closing of the door windows can be immediately halted by releasing the switch or, if the switch was pressed past the resistance point and released, by pressing the respective switch.

The door windows are equipped with the express-close and automatic reversal function. If a door window encounters an obstruction that blocks its path in a circumstance where you pressed the switch past the resistance point and released it to close the window, the automatic reversal function will stop the window and open it slightly.

If a door window encounters an obstruction that blocks its path in a circumstance where you are closing the window by pressing and holding the switch, by pressing and holding button on the SmartKey*, by pushing and holding the retractable hardtop switch, or by pressing and holding the button on the climate control panel or automatic climate control* panel, the automatic reversal function will not operate.

When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment can cause an accident and/or serious personal injury.



You can also open or close the windows using the SmartKey* (▷ page 249) or the retractable hardtop switch (▷ page 248).

You can close and open the windows using the air recirculation switch in the control panel of the climate control (> page 185) or the automatic climate control* (> page 199).



With the SmartKey in starter switch position **0** or removed from the starter switch, the door windows can be operated:

- until you open a door
- · for at least 5 minutes
- ► Switch on the ignition (> page 36).

Opening the door windows

► Press and hold switch ① or ② at the symbol to the resistance point.

The corresponding window will move downwards until you release the switch.

Closing the door windows

► Press and hold switch ① or ② at the symbol △ to the resistance point.

The corresponding window will move upwards until you release the switch.

Warning!



If you press and hold the switch when closing the window, and upward movement of the window is blocked by some obstruction including but not limited to arms, hands, fingers, etc., the automatic reversal will not operate.

Fully opening the door windows (Express-open)

► Press switch ① or ② at the symbol □ past the resistance point and release.

The corresponding window opens completely.

Fully closing the door windows (Express-close)

► Press switch ① or ② at the symbol △ past the resistance point and release.

The corresponding window closes completely.

Warning!



Driver's door only:

If the switch is pressed again past the resistance point and released within 5 seconds, the automatic reversal will not operate.



 $\triangleright \triangleright$



If the upward movement of the window is blocked during the closing procedure, the window will stop and open slightly.

Remove the obstruction, press the respective switch at the symbol again past the resistance point and release.

If the window still does not close when there is no obstruction, press and hold the respective switch at the symbol . The window will then close without the obstruction sensor function.

Stopping windows during Express-operation

► Briefly press the respective switch at the symbol

or
again.

Opening and closing the windows with the retractable hardtop switch

All windows can be opened or closed with the retractable hardtop switch.

The retractable hardtop switch is located on the lower part of the center console.



Retractable hardtop switch

- (1) Opening all side windows
- 2 Closing all side windows

Warning!



Never operate the windows if there is the possibility of anyone being harmed by the opening or closing procedure.

In case the procedure causes potential danger, the procedure can be immediately halted by releasing the retractable hardtop switch.

If a door window encounters an obstruction that blocks its path in a circumstance where you are closing the windows using the retractable hardtop switch, the automatic reversal function will not operate.

Switch on the ignition (▷ page 36).

Opening

► Push the retractable hardtop switch in quick succession twice in direction of arrow ①.

All side windows open.



You can operate the rear side windows only by using the retractable hardtop switch.

Closing

- ► Push the retractable hardtop switch in quick succession twice in direction of arrow ②.
- Keep the retractable hardtop switch pushed the second time until all windows are closed.

The windows in the driver's and passenger door will close first, followed by the rear side windows.



If the retractable hardtop is open, only the windows in the driver's and passenger door will close. The rear side windows remain open.

Opening and closing the windows with the SmartKey*

The retractable hardtop (▷ page 252) will also be opened or closed when the power windows are operated with the SmartKey.



► Aim transmitter eye at the outside driver's or passenger door handle.

The SmartKey must be in close proximity to the respective outside door handle.

Opening (Summer opening feature)

Press and hold button ...

The windows and retractable hardtop begin to open after approximately 1 second.

In the multifunction display you will see the message Retractable roof in operation.

► Release button on the SmartKey to interrupt procedure.

Closing (Convenience closing feature)

▶ Press and hold lock button .

The windows and retractable hardtop begin to close after approximately 1 second.

In the multifunction display you will see the message Retractable roof in operation.

 Release button on the SmartKey to interrupt procedure.

Warning!



When closing the side windows and retractable hardtop, make sure that there is no danger of anyone being harmed by the closing procedure.

If potential danger exists, proceed as follows:

Pelease button to stop the closing procedure. To open, press and hold button To . To continue the closing procedure after making sure that there is no danger of anyone being harmed by the closing procedure, press and hold button To .

Warning!



If the retractable hardtop does not completely open or close, the roof hydraulics will lose pressure and the retractable hardtop is lowered

- after approximately 7 minutes when the ignition is switched on.
- after approximately 15 seconds when the ignition is switched off.

Shortly before the hardtop is lowered, a warning will sound. In the multifunction display you will see and the message Retractable roof being opened.

Properly lock the retractable hardtop (▷ page 255) before continuing to drive.

Synchronizing power windows

The power windows must be synchronized

- after the battery has been disconnected or discharged.
- if the power windows cannot be fully opened (Express-open) or closed (Express-close).

Each power window must be synchronized.

- Close all doors.
- ▶ Switch on the ignition (▷ page 36).
- ► Press and hold both switches ①
 and ② at the symbol △ until the
 windows are completely closed.
- ► Hold on to switches ① and ② for approximately 1 second.

The power windows are synchronized.

Retractable hardtop

Opening and closing the retractable hardtop

For safety reasons, the retractable hardtop can only be opened and closed when the vehicle is standing still.

Warning!



Before operating the switch for the retractable hardtop, make sure no persons are injured by the moving parts (retractable hardtop, roof frame, and trunk lid).

Hands must never be placed near the roof frame, upper windshield area, retractable hardtop, shelf behind roll bars, or trunk lid while the retractable hardtop is being raised or lowered. Serious personal injury may occur.

If potential danger exists, release the retractable hardtop switch. This immediately interrupts the raising or lowering procedure. You can then operate the retractable hardtop switch to raise or lower the retractable hardtop away from the danger zone.

Warning!



When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause an accident and/or serious personal injury.

!

Never sit or place heavy objects on the rear shelf. Doing so could cause damage to the retractable hardtop and the rear shelf.

!

When opening and closing the retractable hardtop, make sure

- there is sufficient clearance for the retractable hardtop to move up and the trunk lid to move back
- the cargo compartment cover is extended and closed
- the trunk is only loaded to the height of the cargo compartment cover
- the luggage/cargo does not push the closed cargo compartment cover up
- the trunk lid is closed
- no roof luggage carrier is installed
- the outside temperature is above +5°F (-15°C)

Otherwise the roof and other parts of the vehicle could be damaged.

Cargo compartment cover

The cargo compartment cover is located in the trunk.



Cargo compartment cover

Closing

Pull the cargo compartment cover at the handle in direction of the arrow until it engages on both sides at the trunk sill.

Opening

- ► Press the release handle on the cargo compartment cover.
- ► Guide the cargo compartment cover forward to its end stop.

!

To prevent damage to the retractable hardtop or luggage/cargo when lowering the roof:

- Load trunk only to the height of the cargo compartment cover.
- Do not permit luggage/cargo to push up the closed cargo compartment cover.
- Do not place anything on top or in front of the cargo compartment cover.
- Do not place anything on the shelf behind the roll bar.

Retractable hardtop

Warning!



To prevent possible accidents, drive the vehicle only with the retractable hardtop either completely closed and locked, or fully lowered into its storage compartment.



For safety reasons, the retractable hardtop cannot be opened or closed while driving.

Make sure the retractable hardtop and the rear window are dry before you open it. Otherwise water may enter the interior and/or trunk.

Retractable hardtop



Before operating the retractable hardtop via the retractable hardtop switch, do the following first:

- Engage the parking brake (> page 59).
- Close the cargo compartment cover.
- Close the trunk lid.
- Switch on ignition (> page 36).

The switch for opening/closing the retractable hardtop is on the lower part of the center console.



Retractable hardtop switch

- 1) Opening
- ② Closing

For operating the power windows with the retractable hardtop switch (> page 248).

Opening

► Push and hold the retractable hardtop switch in direction of arrow ① until the retractable hardtop is completely lowered into the trunk.

Closing

 Push and hold the retractable hardtop switch in direction of arrow ② until the retractable hardtop is completely closed and locked.

Locking the retractable hardtop after raising/lowering

Warning!



Be sure to keep the hardtop switch pushed until the hardtop is fully opened or closed. The hydraulic pump will then shut off.

To prevent possible accidents, drive the vehicle only with the hardtop either completely closed and locked, or fully lowered into its storage compartment.

Warning!



If the retractable hardtop does not completely open or close, the roof hydraulics will lose pressure and the retractable hardtop is lowered

- after approximately 7 minutes when the ignition is switched on.
- after approximately 15 seconds when the ignition is switched off.

Shortly before the hardtop is lowered, a warning will sound. In the multifunction display you will see and the message Retractable roof being opened.

 Properly lock the retractable hardtop before continuing to drive (▷ page 256).

Warning!



The hardtop is not fully closed and locked or not fully opened and locked if:

- the message Retractable roof in operation is shown in the multifunction display
- a warning sounds for 10 seconds when driving and a message in the multifunction display appears (> page 381).

If the retractable hardtop is not properly locked, lock it as described below.

Retractable hardtop

Unlocked status noticed when stopped

- ► Switch on the ignition (> page 36).
- ► To lock the retractable hardtop in its fully closed position, push the retractable hardtop switch forward until the retractable hardtop is fully closed.

or:

► To lock the retractable hardtop in its fully opened position, push the retractable hardtop switch rearward until the retractable hardtop is fully open.

Unlocked status noticed while driving

Warning!



Stop the vehicle and lock the retractable hardtop before continuing to drive. You could otherwise endanger yourself and others.

► Stop the vehicle and leave the ignition switched on.

► To lock the retractable hardtop in its fully closed position, push the retractable hardtop switch forward until the retractable hardtop is fully closed.

or:

► To lock the retractable hardtop in its fully opened position, push the retractable hardtop switch rearward until the retractable hardtop is fully open.

Opening and closing the retractable hardtop with the SmartKey*

The power windows (▷ page 246) will also be opened or closed when you operate the retractable hardtop with the SmartKey.

Warning!



Before operating the retractable hardtop, make sure no persons can be injured by the moving parts (retractable roof, roof frame, and trunk lid) due to negligence.

Hands must never be placed near the roof frame, upper windshield area, hardtop, shelf behind roll bars, or trunk lid while the retractable hardtop is being raised or lowered. Serious personal injury may occur.

If potential danger exists, release the respective button on the SmartKey. This immediately interrupts the raising or lowering procedure. You can then operate or to raise or lower the hardtop away from the danger zone.



Aim transmitter eye at the outside driver's or passenger door handle.

The SmartKey must be in close proximity to the respective outside door handle.

Opening (Summer opening feature)

► Press and hold unlock button until the retractable hardtop is completely open.

The retractable hardtop and windows begin to open after approximately 1 second. In the multifunction display you will see the message Retractable roof in operation.

► Release button on the SmartKey to interrupt procedure.

Closing (Convenience closing feature)

- ► Press and hold lock button until the retractable hardtop is fully closed.
 - The retractable hardtop and windows begin to close after approximately 1 second. In the multifunction display you will see the message Retractable roof in operation.
- ► Release button on the SmartKey to interrupt procedure.

Warning!



When closing the side windows and retractable hardtop, make sure that there is no danger of anyone being harmed by the closing procedure.

If potential danger exists, proceed as follows:

Procedure. To open, press and hold button To continue the closing procedure after making sure that there is no danger of anyone being harmed by the closing procedure, press and hold button To continue the closing procedure, press and hold button To continue to stop the closing procedure.

Warning!



If the retractable hardtop does not completely open or close, the roof hydraulics will lose pressure and the retractable hardtop is lowered

- after approximately 7 minutes when the ignition is switched on.
- after approximately 15 seconds when the ignition is switched off.

Shortly before the hardtop is lowered, a warning will sound. In the multifunction display you will see and the message Retractable roof being opened.


 Properly lock the retractable hardtop before continuing to drive (▷ page 256).

Wind screen


Warning!



The wind screen can restrict the driver's vision to the rear of the vehicle. To prevent a possible accident when visibility is limited (e.g. in darkness), the upper part of the wind screen should be folded back.



- (1) Wind screen
- ② Snap fastener (with handle cap)
- 3 Supporting strap
- (4) Fastening pin
- ⑤ Gap



6 Handle cap

Installing

Remove wind screen (1) from its storage bag and unfold.

The storage bag is located on the wall behind the seat backrests.

► Attach supporting straps ③ to fastening pins ④.



Make sure the lower wind screen edging is inserted through the gap ⑤ between the storage compartment and the rear panel.

- Close snap fasteners ② by pushing in handle cap ⑥.
- ► Pull wind screen ① on molding over roll bars.

Pull the wind screen edging, not on the netting itself.

Removing

- ▶ Pull off wind screen (1) from roll bars.
- ► Open snap fasteners ② by pulling out handle cap ⑥.
- ► Loosen supporting straps ③ from fastening pins ④.
- Fold wind screen ① and put it back into storage bag.

Driving systems

The driving system of your vehicle is described on the following pages:

 Cruise control, with which the vehicle can maintain a preset speed.

The BAS, ABS and ESP® driving systems are described in the "Safety and Security" section (▷ page 82).

Cruise control

The cruise control automatically maintains the speed you set for your vehicle.

Use of cruise control is recommended for driving at a constant speed for extended periods of time.

You can set or resume cruise control at any speed over 20 mph (30 km/h).

The cruise control function is operated by means of the cruise control lever.

The cruise control lever is the uppermost lever on the left-hand side of the steering column (▷ page 22).

Warning!




The cruise control is a convenience system designed to assist the driver during vehicle operation. The driver is and must remain at all times responsible for the vehicle speed and for safe brake operation.

Only use the cruise control if the road, traffic, and weather conditions make it advisable to travel at a steady speed.

- The use of cruise control can be dangerous on winding roads or in heavy traffic because conditions do not allow safe driving at a steady speed.
- The use of cruise control can be dangerous on slippery roads. Rapid changes in tire traction can result in wheel spin and loss of control.
- Deactivate the cruise control when driving in fog.

The "Resume" function should only be operated if the driver is fully aware of the previously set speed and wishes to resume this particular preset speed.

Driving systems



- ① Set current or higher speed
- ② Set current or lower speed
- (3) Cancel cruise control
- (4) Resume to last set speed

Warning!



Cruise control brakes automatically so that the set speed is not exceeded. The brake pedal is depressed automatically to do this.

Keep in mind that cruise control is a convenience system designed to assist the driver during vehicle operation. The driver is and must always remain responsible for the vehicle's speed and for safe braking operation.

Keep driver's foot area clear at all times, including the area under the brake pedal. Objects stored in this area may impair pedal movement which could interfere with the braking ability of the cruise control system.

Do not place your foot under the brake pedal - your foot could become caught.

Setting current speed

- ► Accelerate or decelerate to the desired speed.
- ► Briefly lift ① or depress ② the cruise control lever (▷ page 261).

The current speed is set.

Remove your foot from the accelerator pedal.

The cruise control is activated.

The selected speed appears in the multifunction display.

Driving systems



On uphill or downhill grades, the cruise control may not be able to maintain the set speed. Once the grade eases, the set speed will be resumed.

On downhill grades, the cruise control maintains the set speed with braking from the vehicle's braking system. In addition, on longer downhill grades the automatic transmission* will automatically downshift.



Vehicles with manual transmission:

If you depress the clutch pedal when shifting into another gear, the engine speed may increase.

- Drive with sufficient engine speed.
- Shift gears in a timely manner.
- If possible, do not shift down more than one gear.

Canceling cruise control

There are several ways to cancel the cruise control:

► Step on the brake pedal.

The cruise control is canceled. The last speed set is stored for later use.

or

▶ Briefly push the cruise control lever in direction of arrow ③ (▷ page 261).

The cruise control is canceled. The last speed set is stored for later use.



The last stored speed is canceled when you turn off the engine.

Driving systems



The cruise control switches off automatically, if

- you step on the brake pedal.
- you pull up the parking brake lever firmly.
- the vehicle speed is below 20 mph (30 km/h).
- ESP® is in operation or switched off with the ESP® switch (▷ page 84).
- Vehicles with manual transmission: you depress the clutch pedal for longer than 6 seconds during shifting into another gear.
- Vehicles with automatic transmission*: you move the gear selector lever to position N while driving.



Vehicles with automatic transmission*: Moving gear selector lever to position **N** while driving also cancels cruise control. However, the gear selector lever should not be moved to position **N** while driving except to coast when the vehicle is in danger of skidding (e.g. on icy roads).



Depressing the accelerator pedal does not deactivate the cruise control. After brief acceleration (e.g. for passing), the cruise control will resume the last speed set.

Setting a higher speed

- ▶ Lift the cruise control lever in direction of arrow ① (▷ page 261) and hold it up until the desired speed is reached.
- Release the cruise control lever.
 The new speed is set.

Setting a lower speed

- Depress the cruise control lever in direction of arrow ② (▷ page 261) and hold it down until the desired speed is reached.
- Release the cruise control lever.The new speed is set.



When you use the cruise control lever to decelerate, the brake system will automatically brake the vehicle if the engine's braking power does not brake the vehicle sufficiently.

Driving systems

Fine adjustment in 1 mph (Canada: 1 km/h) increments

Faster

▶ Briefly tip the cruise control lever in direction of arrow (1) (▷ page 261).

Slower

► Briefly tip the cruise control lever in direction of arrow ② (▷ page 261).

Setting to last stored speed ("Resume" function)

Warning!



The speed stored in memory should only be set again if prevailing road conditions permit. Possible acceleration or deceleration differences arising from returning to the preset speed could cause an accident and/or serious injury to you and others.

- ▶ Briefly pull the cruise control lever in direction of arrow ④ (▷ page 261).
 - The cruise control resumes the last set speed.
- ► Remove your foot from the accelerator pedal.

The last set speed appears in the multifunction display.

Loading

▼ Loading

Roof rack



This vehicle is not designed to carry items on its roof. Roof rails and any roof-mounted devices, unless expressly approved by Mercedes-Benz for use on this vehicle model, must not be used as they will damage the vehicle and retractable hardtop.

At time of printing, Mercedes-Benz does not offer any roof racks or any other roof-mounted devices for use on this vehicle.



This vehicle is not designed to carry any items on its trunk lid or accommodate any type of trunk lid rack or device. Using such devices may damage the vehicle and retractable hardtop mechanism.

Storage compartments

Warning!



To help avoid personal injury during a collision or sudden maneuver, exercise care when storing objects in the vehicle. Put luggage or cargo in the trunk if possible. Do not place anything on shelf behind the roll bars.

Parcel nets cannot secure hard or heavy objects.

Keep compartment lids closed. This will help to prevent stored objects from being thrown around and injuring vehicle occupants during an accident.



The glove box and the storage compartment under the armrest are centrally locked and unlocked.

Glove box



- 1 Glove box lid release
- 2 Glove box
- ► Pull glove box lid release ① to open the glove box.


The glove box lid opens downward.

Push glove box lid ① up until it engages to close the glove box.



The CD changer* is located in the glove box.

Storage compartment and telephone* compartment under armrest



- 1 Armrest
- ② Recess for opening storage and telephone* compartment

Storage compartment

- Reach into recess ② on the left or right side and lift armrest ① in direction of arrow to open the storage compartment.
- ► Lower armrest ① until it engages to close storage compartment.

Telephone * compartment

► Reach into recess ② on the left or right side, press in and fold up armrest to the right or left side to open it.

The compartment for the telephone* is opened.

► Fold armrest back until it engages to close the telephone* compartment.

Storage compartment between the seat backrests



- 1) Storage compartment lid release
- (2) Storage compartment
- ► Press storage compartment lid release (1) to open.

The storage compartment lid opens downward.

 Push storage compartment lid up until it engages to close it.

Parcel net in passenger footwell

A small convenience parcel net is located in the passenger footwell and behind the driver's seat. It is for small and light items, such as road maps, mail, etc.

Warning!



Do not place heavy or fragile objects, or objects having sharp edges, in the parcel net.

In an accident, during hard braking or sudden maneuvers, they could be thrown around inside the vehicle, and cause injury to vehicle occupants.

Useful features

Shelf behind roll bars

Warning!



The shelf behind the roll bars should not be used to carry objects. This will prevent such objects from being thrown around and injuring vehicle occupants during an accident or sudden maneuver.

The trunk is the preferred place to carry objects.

Cup holder

Warning!



In order to help prevent spilling liquids on vehicle occupants and/or vehicle equipment, only use containers that fit into the cup holder. Use lids on open containers and do not fill containers to a height where the contents, especially hot liquids, could spill during braking, vehicle maneuvers, or in an accident. Liquids spilled on vehicle occupants may cause serious personal injury. Liquids spilled on vehicle equipment may cause damage not covered by the Mercedes-Benz Limited Warranty.

When not in use, keep the cup holder closed. An open cup holder may cause injury to you or others when contacted during braking, vehicle maneuvers, or in an accident.

Keep in mind that objects placed in the cup holder may come loose during hard braking, vehicle maneuvers, or in an accident and be thrown around in the vehicle interior. Objects thrown around in the vehicle interior may cause an accident and/or serious personal injury.



- 1 Cover plate
- ► Press briefly on cover plate ① to open the cup holder.
 - The cup holder opens automatically.
- ► Press cover plate ① until the cup holder engages to close it.

Ashtray



- (1) Cover plate
- Press cover plate (1) briefly in the direction of the arrow.

The ashtray opens automatically.

 To close the ashtray again, press cover plate (1) until the ashtray engages.

Removing ashtray insert

Warning!



Remove front ashtray only with vehicle standing still. Set the parking brake to secure vehicle from movement. Move gear selector lever to position **N** (manual transmission: into second gear). With gear selector lever in position **N** (manual transmission: into second gear), turn off the engine.

- ► Secure vehicle from movement by setting the parking brake.
- Move the selector lever to position N (manual transmission: second gear).
 Now you have more room to take out the ashtray insert.
- ▶ Open the ashtray.
- Reach into both recesses on the left and right side of the retainer and pull out the ashtray insert.

Installing ashtray insert

- ► Place the ashtray insert into the retainer.
- ► Push the ashtray insert down into the retainer until it engages.

Useful features

Cigarette lighter

Warning!



Never touch the heating element or sides of the cigarette lighter; they are extremely hot. Hold the knob only.

When leaving the vehicle, always remove the SmartKey from the starter switch, take it with you, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause an accident and/or serious personal injury.

► Switch on the ignition (> page 36).




- 1 Cigarette lighter
- Push in cigarette lighter ①.
 Cigarette lighter ① will pop out automatically when hot.
- ► Reinsert cigarette lighter ① in its socket after use.

!

The lighter socket can be used to accommodate 12V DC electrical accessories (up to a maximum of 85 W) designed for use with the standard "cigarette lighter" plug type. Keep in mind, however, that connecting accessories to the lighter socket (for example extensive connecting and disconnecting, or using plugs that do not fit properly) can damage the lighter socket. With the socket damaged, the lighter may no longer be able to be placed in the heating (pushed-in) position, or the lighter may pop out too early with the lighter not hot enough.

To help avoid damaging the cigarette lighter socket, we recommend connecting 12V DC electrical assessories designed for use with the standard "cigarette lighter" plug type to the 12V power outlets (▷ page 271) in your vehicle whenever possible.

Power outlet



A power outlet ① is located in the passenger footwell on the side panel of the center console.


- ► Switch on the ignition (> page 36).
- ► Flip up cover of power outlet ① and insert electrical plug (cigarette lighter type).



The power outlet can be used to accommodate 12V DC electrical assessories (e.g. air pump, auxiliary lamps) up to a maximum of 180 W.


Floormat (driver's side only)

Removing



- ► Pull floormat off of retainer pins ② in direction of arrow ①.
- ► Remove the floormat.

Installing



- ► Lay down the floormat.
- ► Press the floormat eyelets ④ onto retainer pins ⑤ in direction of arrow ③.

Warning!



Whenever you are using floormats, make sure there is enough clearance and the floormats are securely fastened.

Floormats should always be securely fastened using eyelets 4 and retainer pins 5.

Before driving off, check that the floormats are securely in place and adjust them if necessary. A loose floormat could slip and hinder proper functioning of the pedals.



For easier removing and installing the floormat, slide the driver's seat fully backwards (\triangleright page 38).

Telephone*

Warning!



Never operate radio transmitters equipped with a built-in or attached antenna (i.e. without being connected to an external antenna) from inside the vehicle while the engine is running. Doing so could lead to a malfunction of the vehicle's electronic system, possibly resulting in an accident and/or serious personal injury.

Radio transmitters, such as a portable telephone or a citizens band unit, should only be used inside the vehicle if they are connected to an antenna that is installed on the outside of the vehicle.

The external antenna must be approved by Mercedes-Benz. Please contact an authorized Mercedes-Benz Center for information on the installation of an approved external antenna. Refer to the radio transmitter operating instructions regarding use of an external antenna.

Warning!



Please do not forget that your primary responsibility is to drive the vehicle. A driver's attention to the road must always be his/her primary focus when driving. For your safety and the safety of others, we recommend that you pull over to a safe location and stop the vehicle before placing or taking a telephone call.

If you choose to use the telephone ¹ while driving, please use the hands-free device and only use the telephone when road, weather and traffic conditions permit. Some jurisdictions prohibit the driver from using a cellular telephone while driving a vehicle.

Observe all legal requirements.

Only operate the COMAND (Cockpit Management and Data System)* or audio system if road, weather, and traffic conditions permit.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

You can take and place telephone calls using the buttons and on the multifunction steering wheel. Use the control system for performing other telephone functions (▷ page 151).

See separate operating manual for instructions on how to use the telephone.

Tele Aid



The initial activation of the Tele Aid system may only be performed by completing the subscriber agreement and placing an acquaintance call using the button. Failure to complete either of these steps will result in a system that is not activated.

If you have any questions regarding activation, please call the Response Center at 1-800-756-9018 (in the USA) or 1-888-923-8367 (in Canada).

Shortly after the completion of your Tele Aid acquaintance call, you will receive a user ID and password. By visiting www.mbusa.com and selecting "Tele Aid" (USA only), you will have access to account information, remote door unlock and more.

The Tele Aid system

(**Tele**matic **A**larm **I**dentification on **D**emand)

The Tele Aid system consists of three types of response:

- Automatic and manual emergency
- Roadside Assistance
- Information

The Tele Aid system is operational providing that the vehicle's battery is charged, properly connected, not damaged and cellular and GPS coverage is available.

The speaker volume of a Tele Aid call can be adjusted when using the volume control on the multifunction steering wheel. To raise, press button and to lower, press button or use the volume knob on your audio system or COMAND* head unit.

Useful features

➤ To activate, press the SOS button, the Roadside Assistance button or the Information button depending on the type of response required.



The SOS button is located in the overhead control panel.

The Roadside Assistance button and the Information button are located below the center armrest cover.

!

The Tele Aid system utilizes the cellular network for communication and the GPS (Global Positioning System) satellites for vehicle location. If either of these signals are unavailable, the Tele Aid system may not function and if this occurs, assistance must be summoned by other means.



When a Tele Aid call has been initiated. the audio system or COMAND* system audio is muted and the selected mode (radio, tape or CD) pauses. The optional cellular phone* (if installed) and inserted in cradle switches off. If you must use this phone, we recommend that you use it only with the vehicle at a standstill in a safe location. Remove the phone from the cradle and place the call. The COMAND* navigation system (if engaged) will continue to run. The display in the instrument cluster is available for use, and spoken commands are only available by pressing the RPT button on the COMAND* unit. A pop-up window will appear in the COMAND* display to indicate that a Tele Aid call is in progress. After the Tele Aid call has ended, the optional cellular phone switches on again. A PIN entry might be necessary.

System self-check

Initially, after switching on ignition, malfunctions are detected and indicated (the indicator lamps in the SOS button, the Roadside Assistance button , and the Information button stay on longer than 10 seconds or do not come on). The message Malfunction. Drive to workshop appears for approximately 10 seconds in the multifunction display.

Warning!



If the indicator lamps in the SOS button, in the Roadside Assistance button, and/or in the Information button do not come on during the system self-check or if any of these indicators remain illuminated constantly in red and/or the message Malfunction. Drive to workshop is displayed in the multifunction display after the system self-check, a malfunction in the system has been detected.

If a malfunction is indicated as outlined above, the system may not operate as expected. Have the system checked at the nearest Mercedes-Benz Center as soon as possible.

Emergency calls

An emergency call is initiated automatically following an accident in which the emergency tensioning devices (ETDs) or air bags deploy.

An emergency call can also be initiated manually by opening the cover next to the interior rear view mirror labeled SOS, then briefly pressing the button located under the cover. See (> page 276) for instructions on initiating an emergency call manually.

Once the emergency call is in progress, the indicator lamp in the SOS button will begin to flash. The message Connecting call appears in the multifunction display and the audio system is muted. When the connection is established, the message Call connected appears in the multifunction display. All information relevant to the emergency, such as the location of the vehicle (determined by the GPS satellite location system), vehicle model, identification number and color are generated.

A voice connection between the Response Center and the occupants of the vehicle will be established automatically soon after the emergency call has been initiated. The Response Center will attempt to determine more precisely the nature of the emergency provided they can speak to an occupant of the vehicle.

The Tele Aid system is available if:

- it has been activated and is operational. Activation requires a subscription for monitoring services, connection and cellular air time.
- the relevant cellular phone network and GPS signals are available and pass the information on to the Response Center.



Location of the vehicle on a map is only possible if the vehicle is able to receive signals from the GPS satellite network and pass the information on to the Response Center.

Warning!



If the indicator lamp in the SOS button is flashing continuously and there was no voice connection to the Response Center established, then the Tele Aid system could not initiate an emergency call (e.g. the relevant cellular phone network is not available). The message Call failed appears in the multifunction display for approximately 10 seconds.

Should this occur, assistance must be summoned by other means.

Initiating an emergency call manually



- 1 Cover
- 2 SOS button
- Briefly press on cover ①.The cover opens.

- Press SOS button ② briefly.
 The indicator lamp in SOS button ② flashes until the emergency call is concluded.
- Wait for a voice connection to the Response Center.
- ► Close cover ① after the emergency call is concluded.

Warning!



If you feel at any way in jeopardy when in the vehicle (e.g. smoke or fire in the vehicle, vehicle in a dangerous road location), please do not wait for voice contact after you have pressed the emergency button. Carefully leave the vehicle and move to a safe location. The Response Center will automatically contact local emergency officials with the vehicle's approximate location if they receive an automatic SOS signal and cannot make voice contact with the vehicle occupants.

Roadside Assistance button **S**



Located below the center armrest cover is the Roadside Assistance button

- Open center armrest cover (⊳ page 266).
- ▶ Press and hold the button (for longer than 2 seconds).

A call to a Mercedes-Benz Roadside Assistance dispatcher will be initiated. The button will flash while the call is in progress. The message Connecting call will appear in the multifunction display and the audio system is muted.

When the connection is established, the message Call connected appears in the multifunction display. The Tele Aid system will transmit data generating the vehicle identification number, model, color and location (subject to availability of cellular and GPS signals).

A voice connection between the Roadside Assistance dispatcher and the occupants of the vehicle will be established.

 Describe the nature of the need for assistance.

The Mercedes-Benz Roadside Assistance dispatcher will either dispatch a qualified Mercedes-Benz technician or arrange to tow your vehicle to the nearest Mercedes-Benz Center, For services such as labor and/or towing, charges may apply. Refer to the Roadside Assistance manual for more information.

The following is only available in the USA:

Sign and Drive services: Services such as jump start, a few gallons of fuel or the replacement of a flat tire with the vehicle spare tire are obtainable.



The indicator lamp in the Roadside Assistance button remains illuminated in red for approx. 10 seconds during the system self-check after switching on ignition (together with the SOS button and the Information button •—).

See "System self-check" (⊳ page 274) when the indicator lamp does not come on in red or stays on longer than approximately 10 seconds.

If the indicator lamp in the Roadside Assistance button is flashing continuously and there was no voice connection to the Response Center established, then the Tele Aid system could not initiate a Roadside Assistance call (e.g. the relevant cellular phone network was not available). The message Call failed appears in the multifunction display.

Useful features

Roadside Assistance calls can be terminated using the button on the multifunction steering wheel or the respective button for ending a telephone call on the audio system or COMAND* head unit.

Information button

Located below the center armrest cover is the Information button •—•.

- Open center armrest cover (▷ page 266).
- Press and hold the button (for longer than 2 seconds).

A call to the Customer Assistance Center will be initiated. The button will flash while the call is in progress. The message Connecting call will appear in the multifunction display and the audio system is muted. When the connection is established, the message Call connected appears in the multifunction display. The Tele Aid system will transmit data generating the vehicle identification number, model, color and location (subject to availability of cellular and GPS signals).

A voice connection between the Customer Assistance Center representative and the occupants of the vehicle will be established. Information regarding the operation of your vehicle, the nearest Mercedes-Benz Center or Mercedes-Benz USA products and services is available to you.

For more details concerning the Tele Aid system, please visit www.mbusa.com and use your ID and password (sent to you separately) to learn more (USA only).



The indicator lamp in the Information button remains illuminated in red for approx. 10 seconds during the system self-check after switching on ignition (together with the SOS button and the Roadside Assistance button ...).

See "System self-check" (> page 274) when the indicator lamp does not come on in red or stays on longer than approximately 10 seconds.

If the indicator lamp in the Information button is flashing continuously and there was no voice connection to the Response Center established, then the Tele Aid system could not initiate an Information call (e.g. the relevant cellular phone network is not available). The message Call failed appears in the multifunction display.

Information calls can be terminated using the button on the multifunction steering wheel or the respective button for ending a telephone call on the audio system or COMAND* head unit.

!

If the indicator lamps do not start flashing after pressing one of the buttons or remain illuminated (in red) at any time, the Tele Aid system has detected a malfunction or the service is not currently active, and may not initiate a call. Visit your Mercedes-Benz Center and have the system checked or contact the Response Center at 1-800-756-9018 (in the USA) or 1-888-923-8367 (in Canada) as soon as possible.

Call priority

If other service calls such as a Roadside Assistance call or Information call are active, an Emergency call is still possible. In this case, the Emergency call will take priority and override all other active calls.



The indicator lamp in the respective button flashes until the call is concluded. Calls can only be terminated by a Response Center or Customer Assistance Center representative, except Roadside Assistance and Information calls, which can also be terminated by pressing the

button on the multifunction steering wheel or the respective button for ending a telephone call on the audio system or COMAND* head unit.

!

If the indicator lamp continues to flash or the system does not reset, contact the Response Center at 1-800-756-9018 (in the USA) or 1-888-923-8367 (in Canada), or Mercedes-Benz Customer Assistance at 1-800-FOR-MERCedes (1-800-367-6372) in the USA or Customer Service at 1-800-387-0100 in Canada.

Remote door unlock

In case you have locked your vehicle unintentionally (e.g. SmartKey inside vehicle), and the reserve SmartKey is not handy:

- ► Contact the Mercedes-Benz Response Center at 1-800-756-9018 (in the USA) or 1-888-923-8367 (in Canada).
 - You will be asked to provide your password which you provided when you completed the subscriber agreement.
- Then return to your vehicle and pull the trunk recessed handle for a minimum of 20 seconds until the SOS button is flashing.

The message Connecting call appears in the multifunction display.

As an alternative, you may unlock the vehicle via Internet using the ID and password sent to you shortly after the completion of your acquaintance call. The Response Center will then unlock your vehicle with the remote door unlocking feature.



The remote door unlock feature is available if the relevant cellular phone network is available.

The SOS button will flash and the message Connecting call will appear in the multifunction display to indicate receipt of the door unlock command.

Once the vehicle is unlocked, a Response Center specialist may attempt to establish voice contact with the vehicle occupants.

If the trunk recessed handle was pulled for more than 20 seconds before door unlock authorization was received by the Response Center, you must wait 15 minutes before pulling the trunk handle again.

Stolen Vehicle Recovery services

In the event your vehicle was stolen:

- Report the incident to the police.
 The police will issue a numbered incident report.
- ▶ Pass this number on to the Mercedes-Benz Response Center along with your password issued to you when you subscribed to the service.

The Response Center will then attempt to covertly contact the vehicle's Tele Aid system. Once the vehicle is located, the Response Center will contact the local law enforcement and you. The vehicle's location will only be provided to law enforcement.




When the anti-theft alarm or the tow-away alarm stays on for more than 30 seconds, a call is initiated automatically to the Response Center. See anti-theft alarm system (▷ page 87) and tow-away alarm (▷ page 88).

Garage door opener*

The integrated remote control is capable of operating up to three separately controlled devices. It provides a convenient way to replace up to three hand-held remote controls used to operate devices such as garage door openers, gate openers, or other devices compatible with HomeLink® or some other systems.

Before the integrated remote control can be used, it must be programmed to the garage door opener, gate operator or other device you wish to operate. See the following instructions for programming information.



Overhead control panel with integrated remote control

- (1) Indicator lamp
- 2 3 4 Signal transmitter button

Needed for programming (not part of vehicle equipment):

- (5) Hand-held remote control of garage door opener, gate operator or other device
- 6 Hand-held remote control button

Warning!



Before programming the integrated remote control to a garage door opener or gate operator, make sure people and objects are out of the way of the device to prevent potential harm or damage. When programming a garage door opener, the door moves up or down. When programming a gate operator, the gate opens or closes.

Do not use the integrated remote control with any garage door opener that lacks safety stop and reverse features as required by U.S. federal safety standards (this includes any garage door opener model manufactured before April 1, 1982).

A garage door that cannot detect an object - signaling the door to stop and reverse - does not meet current U.S. federal safety standards.

 $\triangleright \triangleright$

Useful features

When programming a garage door opener, it is advised to park outside the garage.

Do not run the engine while programming the integrated remote control. Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide, and inhaling it can cause unconsciousness and possible death.

Programming the integrated remote control

Step 1:

► Switch on the ignition (> page 36).

Step 2:

If you have previously programmed an signal transmitter button and wish to retain its programming, proceed to step 3.

If you are programming the integrated remote control for the first time, press and hold the two outer signal transmitter buttons ② and ④ and release them only when the indicator lamp ① begins to flash after approximately 20 seconds (do not hold the button for longer than 30 seconds). This procedure erases any previous settings for all three channels and initializes the memory.

If you later wish to program a second and/or third hand-held transmitter to the remaining two signal transmitter buttons, do not repeat this step and begin directly with step 3.

Step 3:

► Hold the end of the hand-held remote control ⑤ of the device you wish to train approximately 2 to 5 in (5 to 12 cm) away from the signal transmitter button (②, ③ or ④) to be programmed, while keeping the indicator lamp ⑥ in view.

Step 4:

▶ Using both hands, simultaneously press the hand-held remote control button ⑥ and the desired signal transmitter button (②, ③ or ④). Do not release the buttons until step 5 is completed.

The indicator lamp ① will flash, first slowly and then rapidly.



The indicator lamp ① flashes immediately the first time the signal transmitter button is programmed. If this button has already been programmed, the indicator lamp will only start flashing after 20 seconds.

Step 5:

► After the indicator lamp ① changes from a slow to a rapidly flashing light, release the hand-held remote control button and the signal transmitter button.

Step 6:

▶ Press and hold the just-trained signal transmitter button (②, ③ or ④) and observe the indicator lamp ①.

If the indicator lamp ① stays on constantly, programming is complete and your device should activate when the respective signal transmitter button (②, ③ or ④) is pressed and released.



If the indicator lamp ① flashes rapidly for about 2 seconds and then turns to a constant light, continue with programming steps 8 through 12 as your garage door opener may be equipped with the "rolling code" feature.

Step 7:

► To program the remaining two signal transmitter buttons, repeat the steps above starting with step 3.

Rolling code programming

To train a garage door opener (or other rolling code devices) with the rolling code feature, follow these instructions after completing the "Programming" portion (steps 1 through 6) of this text. (A second person may make the following training procedures quicker and easier.)

Step 8:

► Locate "training" button on the garage door opener motor head unit.

Exact location and color of the button may vary by garage door opener brand. Depending on manufacturer, the "training" button may also be referred to as "learn" or "smart" button. If there is difficulty locating the transmitting button, refer to the garage door opener operator's manual.



Useful features

⊳⊳Step 9:

► Press the "training" button on the garage door opener motor head unit.

The "training light" is activated.

You have 30 seconds to initiate the following step.

Step 10:

► Return to the vehicle and firmly press, hold for 2 seconds and release the programmed signal transmitter button (②, ③ or ④).

Step 11:

▶ Press, hold for 2 seconds and release same signal transmitter button a second time to complete the training process.



Some garage door openers (or other rolling code equipped devices) may require you to press, hold for 2 seconds and release the same signal transmitter button a third time to complete the training process.

Step 12:

► Confirm the garage door operation by pressing the programmed signal transmitter button ((2), (3) or (4)).

Step 13:

► To program the remaining two signal transmitter buttons, repeat the steps above starting with step 3.

Gate operator/Canadian programming

Canadian radio-frequency laws require transmitter signals to "time-out" (or quit) after several seconds of transmission which may not be long enough for the integrated signal transmitter to pick up the signal during programming. Similar to this Canadian law, some U.S. gate operators are designed to "time-out" in the same manner.

If you live in Canada or if you are having difficulties programming a gate operator (regardless of where you live) by using the programming procedures, replace step 4 with the following:

Step 4:

- ▶ Press and hold the signal transmitter button (②, ③ or ④). Do not release this button until it has been successfully trained.
- while still holding down the signal transmitter button (②, ③ or ④), "cycle" your hand-held remote control button ⑥ as follows: Press and hold button ⑥ for 2 seconds, then release it for 2 seconds, and again press and hold it for 2 seconds. Repeat this sequence on the hand-held remote control until the frequency signal has been learned. Upon successful training, the indicator lamp ① will flash slowly and then rapidly after several seconds.
- Proceed with programming step 5 and step 6 to complete.



Upon completion of programming the integrated remote control, make sure you retain the hand-held remote control that came with the garage door opener, gate operator or other device. You may need it for use in other vehicles, for future programming of an integrated remote control, or simply for continued use as a hand-held remote control to operate the respective device in other situations.

Reprogramming a single signal transmitter button

To program a device using a signal transmitter button previously trained, follow these steps:

- ► Switch on the ignition (> page 36).
- ▶ Press and hold the desired signal transmitter button (②, ③ or ④). Do not release the button.
- ► The indicator lamp ① will begin to flash after 20 seconds. Without releasing the signal transmitter button, proceed with programming starting with step 3.

Useful features

Operation of integrated remote control

- ► Switch on the ignition (> page 36).
- Select and press the appropriate integrated signal transmitter button (2),
 (3) or (4)) to activate the remote controlled device.

The integrated remote control transmitter continues to send the signal as long as the button is pressed – up to 20 seconds.

Erasing the integrated remote control memory

- ► Switch on the ignition (> page 36).
- ➤ Simultaneously press and hold down the outer signal transmitter buttons ② and ④, for approximately 20 seconds, until the indicator lamp ① flashes rapidly. Do not hold for longer than 30 seconds.

The codes of all three channels are erased.



If you sell your vehicle, erase the codes of all three channels.

Programming tips

If you are having difficulty programming the integrated remote control, here are some helpful tips:

- Check the frequency of the hand-held remote control (5) (typically located on the reverse side of the remote). The integrated remote control is compatible with radio-frequency devices operating between 288-399 MHz.
- Put a new battery in the hand-held remote control (5). This will increase the likelihood of the hand-held remote control sending a faster and more accurate signal to the integrated remote control.

- While performing step 3, hold the hand-held remote control (a) at different lengths and angles from the signal transmitter button (2), (3) or (4) you are programming. Attempt varying angles at the distance of 2 to 5 inches (5 to 12 cm) away or the same angle at varying distances.
- If another hand-held remote control is available for the same device, try the programming steps again using that other hand-held remote control. Make sure new batteries are in the hand-held remote control before beginning the procedure.
- Straighten the antenna wire from the garage door opener assembly. This may help improve transmitting and/or receiving signals.



Certain types of garage door openers are incompatible with the integrated remote control. If you should experience further difficulties with programming the integrated remote control, contact an authorized Mercedes-Benz Center, or call Mercedes-Benz Customer Assistance Center (in the USA only) at 1-800-FOR-MERCedes, or Customer Service (in Canada) at 1-800-387-0100.



USA only:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Controls in detail

Useful features



Canada only:

This device complies with RSS-210 of Industry Canada. Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

Any unauthorized modification to this device could void the user's authority to operate the equipment.

Heated steering wheel* (SLK 280, SLK 350, Canada only)

The steering wheel heating warms up the leather area of the steering wheel.

The lever is on the lower left-hand side of the steering wheel.



- 1 Switching on
- (2) Indicator lamp
- 3 Switching off

Switching on

- Switch on the ignition (▷ page 36).
- Turn switch at tip of lever in direction of arrow (1) and release it.

The steering wheel is heated. Indicator lamp ② comes on.



The steering wheel heating is temporarily suspended while indicator lamp (2) remains on when

- the temperature of the vehicle interior is above 86°F (30°C)
- the temperature of the steering wheel is above 95°F (35°C)

When these conditions do not apply anymore, steering wheel heating continues.

Useful features

Switching off

► Turn switch at tip of lever in direction of arrow ③ and release it.

The steering wheel heating is switched off. Indicator lamp ② goes out.



Indicator lamp ② flashes or switches off in case of

- power surge or undervoltage
- steering wheel heating malfunction



The steering wheel heating switches off automatically when you remove the SmartKey from the starter switch.

The first 1000 miles (1500 km)

Driving instructions

At the gas station

Engine compartment

Tires and wheels

Winter driving

Maintenance

Vehicle care



The first 1000 miles (1500 km)

In the "Operation" section you will find detailed information on operating, maintaining and caring for your vehicle.

The more cautiously you treat your vehicle during the break-in period, the more satisfied you will be with its performance later on.

- Drive your vehicle during the first 1000 miles (1500 km) at varying but moderate vehicle and engine speeds.
- During this period, avoid heavy loads (full throttle driving) and excessive engine speeds (no more than ²/₃ of maximum rpm in each gear).
- Do not attempt to slow the vehicle down by shifting to a lower gear using the gear selector lever*.
- Shift gears in a timely manner.
- · Avoid accelerating by kickdown.
- Select positions 3, 2, or 1 only when driving at moderate speeds (for hill driving).
- Select C as the preferred shift program (> page 163) for the first 1000 miles (1500 km).

After 1000 miles (1500 km), you may gradually increase vehicle and engine speeds to the permissible maximum.



Additional instructions for SLK 55 AMG:

- During the first 1000 miles (1500 km), do not exceed a speed of 85 mph (140 km/h).
- During this period, avoid engine speeds above 4500 rpm in each gear.

All of the above instructions, as may apply to your vehicle type, also apply when driving the first 1000 miles (1500 km) after the engine or the rear differential has been replaced.



Always obey applicable speed limits.

▼ Driving instructions

Drive sensibly - save fuel

Fuel consumption, to a great extent, depends on driving habits and operating conditions.

To save fuel you should:

- Keep tires at the recommended inflation pressures.
- Remove unnecessary loads.
- Allow engine to warm up under low load use.
- Avoid frequent acceleration and deceleration.
- Have all maintenance work performed at the intervals specified in the Maintenance Booklet and as required by the maintenance service indicator. Contact an authorized Mercedes-Benz Center.

Fuel consumption is also increased by driving in cold weather, in stop-and-go traffic, on short trips and in hilly area.

Drinking and driving

Warning!



Drinking and driving and/or taking drugs and driving are very dangerous combinations. Even a small amount of alcohol or drugs can affect your reflexes, perceptions and judgment.

The possibility of a serious or even fatal accident are greatly increased when you drink or take drugs and drive.

Do not drink or take drugs and drive or allow anyone to drive who has been drinking or taking drugs.

Pedals

Warning!



Keep driver's foot area clear at all times. Objects stored in this area may impair pedal movement.

Power assistance

Warning!



With the engine not running, there is no power assistance for the brake and steering systems. In this case, it is important to keep in mind that a considerably higher degree of effort is necessary to brake and steer the vehicle.

Driving instructions

Brakes

Warning!



After driving in heavy rain for some time without applying the brakes or through water deep enough to wet brake components or salty road conditions, the first braking action may be somewhat reduced and increased pedal pressure may be necessary to obtain expected braking effect. Maintain a safe distance from vehicles in front.

Resting your foot on the brake pedal will cause excessive and premature wear of the brake pads.

It can also result in the brakes overheating, thereby significantly reducing their effectiveness. It may not be possible to stop the vehicle in sufficient time to avoid an accident.

To help prevent brake disc corrosion after driving on wet road surfaces (particularly salted roads), it is advisable to brake the vehicle with considerable force prior to parking. The heat generated serves to dry the brakes.

If your brake system is normally only subjected to moderate loads, you should occasionally test the effectiveness of the brakes by applying above-normal braking pressure at higher speeds. This will also enhance the grip of the brake pads.



Be very careful not to endanger other road users when you apply the brakes.

Refer to the description of the Brake Assist System (BAS) (▷ page 83).

If the parking brake is released and the brake warning lamp in the instrument cluster stays on, the brake fluid level in the reservoir is too low.

Brake pad wear or a leak in the system may be the reason for low brake fluid in the reservoir.

Have the brake system inspected immediately. Contact an authorized Mercedes-Benz Center.

All checks and service work on the brake system should be carried out by qualified technicians only. Contact an authorized Mercedes-Benz Center.

Install only brake pads and brake fluid recommended by Mercedes-Benz.

Warning!



If other than recommended brake pads are installed, or other than recommended brake fluid is used, the braking properties of the vehicle can be degraded to an extent that safe braking is substantially impaired. This could result in an accident.



When driving down long and steep grades, relieve the load on the brakes by shifting into a lower gear to use the engine's braking power. This helps prevent overheating of the brakes and reduces brake pad wear.

After hard braking, it is advisable to drive on for some time, rather than immediately park, so that the air stream will cool down the brakes faster.

High-performance brake system (SLK 55 AMG only)

The high-performance brake system is designed to operate under the extremely high operating demands required to accommodate the performance capabilities of the vehicle. The brakes may produce a squeaking-type noise depending on the

- · vehicle speed
- · brake force applied
- ambient conditions, e.g. temperature and humidity

As with any brake system, the wear of individual brake system components such as brake pads or discs strongly depends on your driving style and the conditions under which you operate the vehicle. Thus, a driving style calling for high demand braking will cause your vehicle's brakes to wear more quickly.

Warning!



New vehicle brake pads and discs, and replacement brake pads and discs may take several hundred miles of driving until they provide optimum braking efficiency. Until that time, you may need to use increased brake pedal pressure while braking. Please be aware of this and adjust your driving and braking accordingly during this break-in period.

Excessive high demand braking will cause correspondingly high brake wear. Please be attentive to the brake warning lamp in the instrument cluster and brake condition messages in the multifunction display. Especially for high performance driving, it is important to maintain the brake system and have it checked regularly.

Driving off

Apply the brakes to test them briefly after driving off. Perform this procedure only when the road is clear of other traffic.

Warm up the engine smoothly. Do not place full load on the engine until the operating temperature has been reached.

When starting off on a slippery surface, do not allow a drive wheel to spin for an extended period with the ESP® switched off. Doing so may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.

!

Simultaneously depressing the accelerator pedal and applying the brake reduces engine performance and causes premature brake and drivetrain wear.

Parking

Warning!



Do not park this vehicle in areas where combustible materials such as grass, hay or leaves can come into contact with the hot exhaust system, as these materials could be ignited and cause a vehicle fire.

To reduce the risk of personal injury as a result of vehicle movement, <u>before</u> turning off the engine and leaving the vehicle always:

- Keep right foot on brake pedal.
- Pull the parking brake lever up as many notches as possible.
- Move the selector lever to position P (manual transmission: first or reverse gear).
- Slowly release brake pedal.

- When parked on an incline, turn front wheels towards the road curb.
- Turn the SmartKey in the starter switch to position 0 and remove the SmartKey from the starter switch.
- Take the SmartKey and lock vehicle when leaving.

!

Set the parking brake whenever parking or leaving the vehicle. In addition, place gear selector lever* in position **P** (manual transmission: move gearshift lever to first or reverse gear).

In addition, when parking on hills, turn front wheel towards the road curb.

Tires

Warning!



If you feel a sudden significant vibration or ride disturbance, or you suspect that possible damage to your vehicle has occurred, you should turn on the hazard warning flashers, carefully slow down, and drive with caution to an area which is a safe distance from the road.

Inspect the tires and the vehicle undercarriage for possible damage. If the vehicle or tires appear unsafe, have the vehicle towed to the nearest Mercedes-Benz Center or tire dealer for repairs.

Treadwear indicators (TWI) are required by law. These indicators are located in six places on the tread circumference and become visible at a tread depth of approximately ¹/₁₆ in (1.6 mm), at which point the tire is considered worn and should be replaced.

The treadwear indicator appears as a solid band across the tread.

Warning!



Although the applicable federal motor vehicle safety laws consider a tire to be worn when the treadwear indicators (TWI) become visible at approximately $^1/_{16}$ in (1.6 mm), we recommend that you do not allow your tires to wear down to that level. As tread depth approaches $^1/_8$ in (3.0 mm), the adhesion properties on a wet road are sharply reduced.

Depending upon the weather and/or road surface (conditions), the tire traction varies widely.

Specified tire inflation pressures must be maintained. This applies particularly if the tires are subject to high loads (e.g. high speeds, heavy loads, high ambient temperatures).

Warning!



Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle. You may lose control of the vehicle. Continued driving with a flat tire or driving at high speed with a flat tire will cause excessive heat build-up and possibly a fire.

Hydroplaning

Depending on the depth of the water layer on the road, hydroplaning may occur, even at low speeds and with new tires. Reduce vehicle speed, avoid track grooves in the road and apply brakes cautiously in the rain.

Driving instructions

Tire traction

The safe speed on a wet, snow-covered or icy road is always lower than on a dry road.

You should pay particular attention to the condition of the road whenever the outside temperatures are close to the freezing point.

Warning!



If ice has formed on the road, tire traction will be substantially reduced. Under such weather conditions, drive, steer and brake with extreme caution.

Mercedes-Benz recommends winter tires (\triangleright page 348) with a minimum tread depth of approximately $^1/_6$ in (4 mm) on all four wheels for the winter season to ensure normal balanced handling characteristics. On packed snow, they can reduce your stopping distance as compared with summer tires.

Stopping distance, however, is still considerably greater than when the road is not covered with snow or ice. Exercise appropriate caution.



Avoid spinning of a drive wheel. This may cause serious damage to the drivetrain which is not covered by the Mercedes-Benz Limited Warranty.

Tire speed rating

Regardless of the tire speed rating, local speed limits should be obeyed. Use prudent driving speeds appropriate to prevailing conditions.

Warning!



Even when permitted by law, never operate a vehicle at speeds greater than the maximum speed rating of the tires.

Exceeding the maximum speed for which tires are rated can lead to sudden tire failure, causing loss of vehicle control and possibly resulting in an accident and/or personal injury and possible death, for you and for others.

SLK 280, SLK 350 SLK 280 with Sport Package* SLK 350 with Sport Package*

Your vehicle is factory equipped with "W"-rated tires, which have a tire speed rating of 168 mph (270 km/h).

An electronic speed limiter prevents your vehicle from exceeding a speed of 155 mph (250 km/h).

SLK 55 AMG

Your vehicle is factory equipped with "Y"-rated tires, which have a tire speed rating of 186 mph (300 km/h).

An electronic speed limiter prevents your vehicle from exceeding a speed of 155 mph (250 km/h).

SLK 55 AMG with Performance Package*

Your vehicle is factory equipped with "Y"-rated tires, which have a tire speed rating of 186 mph (300 km/h).

An electronic speed limiter prevents your vehicle from exceeding a speed of 174 mph (280 km/h).



For information on speed rating for winter tires, see "Winter tires" (> page 348).

For additional general information on tire speed markings on tire sidewall, see "Tire speed rating" (▷ page 334).

Winter driving instructions

The most important rule for slippery or icy roads is to drive sensibly and to avoid abrupt acceleration, braking and steering maneuvers. Do not use the cruise control system under such conditions.

When the vehicle is in danger of skidding, move gear selector lever* to position **N** or declutch in case of manual transmission. Try to keep the vehicle under control by corrective steering action.



For information on driving with snow chains, see "Snow chains" (> page 349).

Warning!



On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of control loss.

Driving instructions

Road salts and chemicals can adversely affect braking efficiency. Increased pedal force may become necessary to produce the normal brake effect.

Depressing the brake pedal periodically when traveling at length on salt-strewn roads can bring road-salt-impaired braking efficiency back to normal.

If the vehicle is parked after being driven on salt-treated roads, the braking efficiency should be tested as soon as possible after driving is resumed.

Warning!



Make sure not to endanger any other road users when carrying out these braking maneuvers.

Warning!



If the vehicle becomes stuck in snow, make sure snow is kept clear of the exhaust pipe and from around the vehicle with the engine running. Otherwise, deadly carbon monoxide (CO) gases may enter the vehicle interior, resulting in unconsciousness and death.

To assure sufficient fresh air ventilation, open a window slightly on the side of the vehicle not facing the wind.

Warning!



The outside temperature indicator is not designed to serve as an ice-warning device and is therefore unsuitable for that purpose. Indicated temperatures just above the freezing point do not guarantee that the road surface is free of ice.

For more information, see "Winter driving" (▷ page 348).

Standing water



Do not drive through flooded areas or water of unknown depth. Before driving through water, determine its depth. Never accelerate before driving into water. The bow wave could force water into the engine and auxiliary equipment, thus damaging them.

If you must drive through standing water, drive slowly to prevent water from entering the passenger compartment or the engine compartment. Water in these areas could cause damage to electrical components or wiring of the engine or transmission, or could result in water being ingested by the engine through the air intake, causing severe internal engine damage. Any such damage is not covered by the Mercedes-Benz Limited Warranty.

Passenger compartment

Warning!



Always fasten items being carried as securely as possible.

In an accident, during hard braking or sudden maneuvers, loose items will be thrown around inside the vehicle, and cause injury to vehicle occupants unless the items are securely fastened in the vehicle.

The trunk is the preferred place to carry objects.

Driving abroad

Abroad, there is an extensive Mercedes-Benz service network at your disposal. If you plan to drive into areas which are not listed in the index of your Mercedes-Benz Center directory, you should request pertinent information from an authorized Mercedes-Benz Center.

Control and operation of radio transmitter

COMAND*, radio, and telephone*

Warning!



Please do not forget that your primary responsibility is to drive the vehicle safely. Only operate the COMAND*, radio or telephone ¹ if road, traffic and weather conditions permit.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of 44 feet (approximately 14 m) every second.

¹ Observe all legal requirements.

Telephones and two-way radios

Warning!



Never operate radio transmitters equipped with a built-in or attached antenna (i.e. without being connected to an external antenna) from inside the vehicle while the engine is running. Doing so could lead to a malfunction of the vehicle's electronic system, possibly resulting in an accident and/or personal injury.

Radio transmitters, such as a portable telephone or a citizens band unit should only be used inside the vehicle if they are connected to an antenna that is installed on the outside of the vehicle.

Refer to the radio transmitter operation instructions regarding use of an external antenna.

Driving instructions

Catalytic converter

Your Mercedes-Benz is equipped with monolithic-type catalytic converters, an important element in conjunction with the oxygen sensors to achieve substantial control of the pollutants in the exhaust emissions. Keep your vehicle in proper operating condition by following our recommended maintenance instructions as outlined in your Maintenance Booklet.



To prevent damage to the catalytic converters, use only premium unleaded gasoline in this vehicle.

Any noticeable irregularities in engine operation should be repaired promptly. Otherwise, excessive unburned fuel may reach the catalytic converter, causing it to overheat and potentially start a fire.

Warning!



As with any vehicle, do not idle, park or operate this vehicle in areas where combustible materials such as grass, hay or leaves can come into contact with the hot exhaust system, as these materials could be ignited and cause a vehicle fire.

Emission control

Certain engine systems serve to keep the toxic components of the exhaust gases within permissible limits required by law.

These systems, of course, will function properly only when maintained strictly according to factory specifications. Any adjustments on the engine should therefore only be carried out by qualified Mercedes-Benz Center authorized technicians.

Engine adjustments should not be altered in any way. Moreover, the specified service jobs must be carried out regularly according to Mercedes-Benz servicing requirements. For details refer to the Maintenance Booklet.

Warning!



Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide (CO), and inhaling it can cause unconsciousness and possible death.

Do not run the engine in confined areas (such as a garage) which are not properly ventilated. If you think that exhaust gas fumes are entering the vehicle while driving, have the cause determined and corrected immediately. If you must drive under these conditions, drive only with at least one window fully open at all times.

Coolant temperature

During severe operating conditions, e.g. stop-and-go city traffic, the coolant temperature may rise to approx. 248°F (120°C).

The engine should not be operated with the coolant temperature over 248°F (120°C). Doing so may cause serious engine damage which is not covered by the Mercedes-Benz Limited Warranty.



Excessive coolant temperature triggers a warning message in the multifunction display (> page 376).

Warning!



- Driving when your engine is badly overheated can cause some fluids, which may have leaked into the engine compartment, to catch fire. You could be seriously burned.
- Steam from an overheated engine can cause serious burns and can occur just by opening the hood. Stay away from the engine if you see or hear steam coming from it.

Turn off the engine, get out of the vehicle and do not stand near the vehicle until the engine has cooled down.

At the gas station

Refueling

Warning!



Gasoline is highly flammable and poisonous. It burns violently and can cause serious injury. Whenever you are around gasoline, avoid inhaling fumes and skin contact, extinguish all smoking materials. Never allow sparks, flame or smoking materials near gasoline!

Failure to remove the fuel cap slowly could result in personal injury.

The fuel filler flap is located on the right-hand side of the vehicle towards the rear.

Locking and unlocking the vehicle with the remote control automatically locks and unlocks the fuel filler flap.





- 1) To open fuel filler flap
- ② To insert fuel filler cap
- 3 Supplemental tire inflation pressure information



Only use premium unleaded gasoline with a minimum Posted Octane Rating of 91 (average of 96 RON / 86 MON).

Information on gasoline quality can normally be found on the fuel pump.

For more information on gasoline, see "Premium unleaded gasoline" (> page 452) or the Factory Approved Service Products pamphlet.

At the gas station

- Remove the SmartKey from the starter switch.
- Open fuel filler flap by pushing at point indicated by arrow ①.

The fuel filler flap springs open.

- ➤ Turn fuel filler cap counterclockwise and hold on to it until possible pressure is released.
- ➤ Take off fuel filler cap and set it in direction of arrow ② in the recess on the inside of fuel filler flap.

To prevent fuel vapors from escaping into open air, fully insert filler nozzle unit.

 Only fill your tank until the filler nozzle unit cuts out – do not top up or overfill.

Warning!



Overfilling of the fuel tank may create pressure in the system which could cause a gas discharge. This could cause the gas to spray back out when removing the fuel pump nozzle, which could cause personal injury.

- ► Replace the fuel filler cap by turning it clockwise until it audibly engages.
- Close the fuel filler flap.



Leaving the engine running and the fuel cap open can cause the yellow fuel tank reserve warning lamp to flash and the malfunction indicator lamp (USA only) or the malfunction indicator lamp (Canada only) to illuminate.

For more information, see "Practical hints" (> page 364).

Check regularly and before a long trip



Engine compartment (SLK 350, example)

- (1) Windshield washer system and headlamp cleaning system* reservoir
- (2) Brake fluid reservoir
- 3 Coolant expansion tank



For opening the hood, see "Hood" (⊳ page 307).

At the gas station

Windshield washer system and headlamp cleaning system*

For information on refilling the reservoir, see "Windshield washer system and head-lamp cleaning system*" (> page 315).

Brake fluid



If you find that the brake fluid in the brake fluid reservoir has fallen to the minimum mark or below, have the brake system checked for brake pad thickness and leaks immediately. Notify an authorized Mercedes-Benz Center immediately. Do not add brake fluid as this will not solve the problem.

For more information, see "Practical hints" (▷ page 363).

For information on brake fluid, see "Fuels, coolants, lubricants, etc." (▷ page 449).

Coolant

For normal replenishing, use water (potable water quality).

For more information on coolant, see "Coolant" (▷ page 313) and "Fuels, coolants, lubricants, etc." (▷ page 449).

Engine oil level

For information on engine oil, see "Engine oil" (\triangleright page 308).

Vehicle lighting

Check function and cleanliness.

For more information on vehicle lighting, see "Replacing bulbs" (▷ page 400).

For information on switching on the exterior lighting, see "Exterior lamp switch" (> page 110).

Tire inflation pressure

For information on tire inflation pressure, see "Important notes on tire inflation pressure" (▷ page 328).

▼ Engine compartment

Hood

Warning!



Do not pull the release lever while the vehicle is in motion. Otherwise the hood could be forced open by passing air flow.

Opening

The hood release is located on the driver side under the instrument panel.



(1) Hood lock release lever

tion of arrow.

The hood is unlocked.



To avoid damage to the windshield wipers or hood, never open the hood if the wiper arms are folded forward away from the windshield.



- (2) Lever for opening the hood
- Push lever (2) on the hood upward to release hood.

Pull hood lock release lever (1) in direc- With the hood released, lift the hood by lifting it at the front edge.

> The hood will be automatically held open at shoulder height by gas-filled struts.

Warning!



To help prevent personal injury, stay clear of moving parts when the hood is open and the engine is running. Make sure the hood is properly closed before driving. When closing the hood, use extreme caution not to catch hands or fingers.

The radiator fan may continue to run for approximately 30 seconds or even restart after the engine has been turned off. Stay clear of fan blades.

 $\triangleright \triangleright$

 $\triangleright \triangleright$

Warning!



If you see flames or smoke coming from the engine compartment, or if the coolant temperature display in the multifunction display indicates that the engine is overheated, do not open the hood. Move away from vehicle and do not open the hood until the engine has cooled down. If necessary, call the fire department.

Warning!



The engine is equipped with a transistorized ignition system. Because of the high voltage it is dangerous to touch any components (ignition coils, spark plug sockets, diagnostic socket) of the ignition system

- with the engine running
- while starting the engine
- if ignition is "on" and the engine is turned manually

Closing

Warning!



Be careful that you do not close the hood on anyone.

- Let the hood drop from a height of approximately 1 ft (30 cm).
 - The hood will lock audibly.
- Check to make sure the hood is fully closed.

If you can raise the hood at a point above the headlamps, then it is not properly closed. Open it again and let it drop with somewhat greater force.

Engine oil

The amount of oil your engine needs will depend on a number of factors, including driving style. Higher oil consumption can occur when

- the vehicle is new
- the vehicle is driven frequently at higher engine speeds

Engine oil consumption checks should only be made after the vehicle break-in period.



Do not use any special lubricant additives, as these may damage the drive assemblies. Using special additives not approved by Mercedes-Benz may cause damage not covered by the Mercedes-Benz Limited Warranty. More information on this subject is available at any authorized Mercedes-Benz Center.

Checking engine oil level with the control system (SLK 55 AMG only)

When checking the oil level

- the vehicle must be parked on level ground.
- with the engine at operating temperature, the vehicle must have been stationary for at least 5 minutes with the engine turned off.
- with the engine not at operating temperature, the vehicle must have been stationary for at least 30 minutes with the engine turned off.

To check the engine oil level via the multifunction display, do the following:

► Switch on the ignition (▷ page 36).
The standard display appears in the multifunction display (▷ page 128).

► Press button or on the multifunction steering wheel repeatedly until the following message appears in the multifunction display (▷ page 124):

Engine oil level
Measuring now
Measurement
correct only if
veh. level

One of the following messages will subsequently appear in the multifunction display:

- Engine oil level ok
- Add 1.0 qt. (Canada: 1.0 liter) to reach max. oil level

- Add 1.5 qts. (Canada: 1.5 liters) to reach max. oil level
- Add 2.0 qts. (Canada: 2.0 liters)
 to reach max. oil level



If you want to interrupt the checking procedure, press button on the multifunction steering wheel (> page 124).

► If necessary, add engine oil.

For adding engine oil, see "Adding engine oil" (▷ page 312).

For more information on engine oil, see "Fuels, coolants, lubricants, etc." (> page 449).

Engine compartment

Other display messages

If the ignition is not switched on, the following message will appear:

Turn on ignition to see engine oil level

Switch on the ignition (▷ page 36).

If you see the message:

Observe waiting time

- If engine is at operating temperature, wait 5 minutes before repeating check procedure.
- If engine is not at operating temperature yet, you must wait 30 minutes before checking oil.

If you see the message:

Engine oil level Not when engine on

- ➤ Turn off the engine.
- If the engine is at operating temperature, wait 5 minutes before checking oil.
- If the engine is not at operating temperature yet, you must wait 30 minutes before checking oil.



If you want to interrupt the checking procedure, press button on the multifunction steering wheel (> page 124).

If there is excess engine oil with the engine at normal operating temperature, the following message will appear:

Engine oil level Reduce oil level

 Have excess oil siphoned or drained off. Contact an authorized
 Mercedes-Benz Center.




Excess oil must be siphoned or drained off. It could cause damage to the engine and catalytic converter not covered by the Mercedes-Benz Limited Warranty.

For more information on messages in the display concerning engine oil, see the "Practical hints" section (> page 368).

Checking engine oil level with the oil dipstick (SLK 280, SLK 350 only)

When checking the oil level

- the vehicle must be parked on level ground.
- with the engine at operating temperature, the vehicle must have been stationary for at least 5 minutes with the engine turned off.
- with the engine not at operating temperature, the vehicle must have been stationary for at least 30 minutes with the engine turned off.



- 1 Oil dipstick
- 2 Upper (max) mark
- (3) Lower (min) mark

To check the engine oil level with the oil dipstick, do the following:

- ▶ Open the hood (> page 307).
- ▶ Pull out oil dipstick ①.
- ▶ Wipe oil dipstick (1) clean.
- ► Fully insert oil dipstick ① into the dipstick guide tube.

 Pull out oil dipstick ① again after approximately 3 seconds to obtain accurate reading.

The oil level is correct when it is between the lower (min) mark ③ and upper (max) mark ② of oil dipstick ①.



The filling quantity between the upper and lower marks on the oil dipstick is approximately 2.1 US qt. (2.0 l).

If necessary, add engine oil.

For adding engine oil, see "Adding engine oil" (▷ page 312).

For more information on engine oil, see "Fuels, coolants, lubricants, etc." (> page 449).

For more information on messages in the multifunction display concerning engine oil, see the "Practical hints" section (> page 368).

Engine compartment

Adding engine oil

Only use approved engine oils and oil filters required for vehicles with Maintenance System (U.S. vehicles) or FSS PLUS (Canada vehicles). For a listing of approved engine oils and oil filters, refer to the Factory Approved Service Products pamphlet in your vehicle literature portfolio, or contact an authorized Mercedes-Benz Center.

Using engine oils and oil filters of specification other than those expressly required for the Maintenance System (U.S. vehicles) or FSS PLUS (Canada vehicles), or changing of oil and oil filter at change intervals longer than those called for by the Maintenance System (U.S. vehicles) or FSS PLUS (Canada vehicles) will result in engine damage not covered by the Mercedes-Benz Limited Warranty.



SLK 350 (example)

1 Filler cap



SLK 55 AMG

1 Filler cap

- ► Unscrew filler cap ① from filler neck.
- Add engine oil as required.

Be careful not to overfill with oil.

Be careful not to spill any oil when adding. Avoid environmental damage caused by oil entering the ground or water.

!

Excess oil must be siphoned or drained off. It could cause damage to the engine and catalytic converter not covered by the Mercedes-Benz Limited Warranty.

► Screw filler cap (1) back on filler neck.

For more information on engine oil, see "Technical data" (▷ page 449) and (▷ page 451).

Transmission fluid level*

Vehicles with automatic transmission*: The transmission fluid level does not need to be checked. If you notice transmission fluid loss or gear shifting malfunctions, have an authorized Mercedes-Benz Center check the transmission.

Coolant level

The engine coolant is a mixture of water and anticorrosion/antifreeze. To check the coolant level, the vehicle must be parked on level ground and the engine must be cool.

Warning!



In order to avoid any possibly serious burns:

- Use extreme caution when opening the hood if there are any signs of steam or coolant leaking from the cooling system, or if the coolant temperature gauge indicates that the coolant is overheated.
- Do not remove pressure cap on coolant reservoir if coolant temperature is above 158°F (70°C). Allow engine to cool down before removing cap. The coolant reservoir contains hot fluid and is under pressure.

- Using a rag, slowly open the cap approximately ½ turn to relieve excess pressure. If opened immediately, scalding hot fluid and steam will be blown out under pressure.
- Do not spill antifreeze on hot engine parts. Antifreeze contains ethylene glycol which may burn if it comes into contact with hot engine parts.

Engine compartment

The coolant expansion tank is located on the passenger side of the engine compartment.



SLK 350 (example)

- (1) Coolant expansion tank
- ② Cap
- (3) Marking bar in the expansion tank

- Using a rag, turn cap ② slowly approximately one half turn counterclockwise to release any excess pressure.
- Continue turning cap ② counterclockwise and remove it.

The coolant level is correct if the level

- for cold coolant: reaches marking bar ③ in expansion tank ①
- for warm coolant: is approximately 0.6 in (1.5 cm) higher
- Add coolant as required.
- Replace and tighten cap ②.

For more information on coolant, see "Coolants" (> page 453).

Battery

Your vehicle's battery is located in the engine compartment.

The battery should always be sufficiently charged in order to achieve its rated service life. Refer to the Maintenance Booklet for battery maintenance intervals.

If you use your vehicle mostly for short-distance trips, you will need to have the battery charge checked more frequently.

When replacing the battery, always use batteries approved by Mercedes-Benz.

If you do not intend to operate your vehicle for an extended period of time, consult an authorized Mercedes-Benz Center about steps you need to observe.



Observe all safety instructions and precautions when handling automotive batteries.



Risk of explosion



Keep flames or sparks away from battery. Do not smoke.



Battery acid is caustic. Do not allow it to come into contact with skin, eyes or clothing.

In case it does, immediately flush affected area with clean water and seek medical help if necessary.



Wear eye protection.



Keep children away.



Follow the instructions in this Operator's Manual.

Batteries contain materials that can harm the environment if disposed of improperly. Recycling of batteries is the preferred method of disposal. Many states require sellers of batteries to accept old batteries for recycling.

Windshield washer system and headlamp cleaning system*

The windshield washer reservoir is located on the passenger side of the engine compartment.



SLK 350 (example)

1) Washer fluid reservoir cap

Fluid for the windshield washer system and the headlamp cleaning system* is supplied from the windshield washer reservoir. It has a capacity of approx. 7.4 US qt (7 I).

Engine compartment

During all seasons, add MB Windshield Washer Concentrate "S" to water. Premix the windshield washer fluid in a suitable container.

Warning!



Washer solvent/antifreeze is highly flammable. Do not spill washer solvent/antifreeze on hot engine parts, because it may ignite and burn. You could be seriously burned.

- Pull cap upward using latch until it opens.
- ► Refill the reservoir with MB Windshield Washer Concentrate and water (or commercially available premixed windshield washer solvent/antifreeze, depending on ambient temperatures).

Always use washer solvent/antifreeze where temperatures may fall below freezing point. Failure to do so could result in damage to the washer system/reservoir.

▶ Push cap down until it engages.

!

Only use washer fluid which is suitable for plastic lenses. Improper washer fluid can damage the plastic lenses of the headlamps.

For more information, see "Windshield washer system and headlamp cleaning system*" (> page 456).

▼ Tires and wheels

See an authorized Mercedes-Benz Center for information on tested and recommended rims and tires for summer and winter operation. They can also offer advice concerning tire service and purchase.

Warning!



Replace rims or tires with the same designation, manufacturer and type as shown on the original part. See an authorized Mercedes-Benz Center for further information. If incorrectly sized rims and tires are mounted:

- The wheel brakes or suspension components can be damaged.
- The operating clearance of the wheels and the tires may no longer be correct.

Warning!



Worn, old tires can cause accidents. If the tire tread is badly worn, or if the tires have sustained damage, replace them.

When replacing rims, only use genuine Mercedes-Benz wheel bolts specified for the particular rim type. Failure to do so can result in the bolts loosening and may lead to an accident.

Retreaded tires are not tested or recommended by Mercedes-Benz, since previous damage cannot always be recognized on retreads. Mercedes-Benz therefore cannot assure the operating safety of the vehicle when such tires are used.

Important guidelines

- Only use sets of tires and rims of the same type and make.
- Tires must be of the correct size for the rim.
- Break in new tires for approximately 60 miles (100 km) at moderate speeds.
- Regularly check the tires and rims for damage. Dented or bent rims can cause tire inflation pressure loss or damage the tire beads.
- If vehicle is heavily loaded, check tire inflation pressure and correct as required.
- Do not allow your tires to wear down too far. Adhesion properties on wet roads are sharply reduced at tread depths under ¹/₈ in (3 mm).
- When replacing individual tires, you should mount new tires on the front wheels first (on vehicles with same-sized wheels all around).

Tire care and maintenance

Warning!



Regularly check the tires for damage. Damaged tires can cause tire inflation pressure loss. As a result, you could lose control of your vehicle.

Worn, old tires can cause accidents. If the tire tread is badly worn, or if the tires have sustained damage, replace them.

Regularly check your tire inflation pressure at least once a month. For more information on checking tire inflation pressure, see "Recommended tire inflation pressure" (> page 327).

Tire inspection

Every time you check your tire inflation pressure, you should also inspect your tires for the following:

- excessive treadwear (▷ page 319)
- cord or fabric showing through the tire's rubber
- bumps, bulges, cuts, cracks or splits in the tread or side of the tire

Replace the tire if you find any of the above conditions.

Make sure you also inspect the spare tire periodically for condition and inflation. Spare tires will age and become worn over time even if never used, and thus should be inspected and replaced when necessary.

Life of tire

The service life of a tire is dependent upon varying factors including but not limited to:

- Driving style
- Tire inflation pressure
- Distance driven

Warning!



Tires and spare tire should be replaced after six years, regardless of the remaining tread.

Tread depth

Do not allow your tires to wear down too far. Adhesion properties on wet roads are sharply reduced at tread depths under $\frac{1}{8}$ in (3 mm).

Treadwear indicators (TWI) are required by law. These indicators are located in six places on the tread circumference and become visible at a tread depth of approximately $^1/_{16}$ in (1.6 mm), at which point the tire is considered worn and should be replaced.

Recommended minimum tire tread depth:

- Summer tires ¹/₈ in (3 mm)
- Winter tires ¹/₆ in (4 mm)


Warning!



Although the applicable federal motor safety laws consider a tire to be worn when the treadwear indicators (TWI) become visible at approximately $^1/_{16}$ in (1.6 mm), we recommend that you do not allow your tires

to wear down to that level. As tread depth approaches $^{1}/_{8}$ in (3 mm), the adhesion properties on a wet road are sharply reduced.

Depending upon the weather and/or road surface (conditions), the tire traction varies widely.



1 TWI (Tread Wear Indicator)

The treadwear indicator appears as a solid band across the tread.

Storing tires



Keep unmounted tires in a cool, dry place with as little exposure to light as possible. Protect tires from contact with oil, grease and gasoline.

Cleaning tires



Never use a round nozzle to power wash tires. The intense jet of water can result in damage to the tire.

Always replace a damaged tire.

Direction of rotation

Unidirectional tires offer added advantages, such as better hydroplaning performance. To benefit, however, you must make sure the tires rotate in the direction specified.

An arrow on the sidewall indicates the intended direction of rotation (spinning) of the tire.




Spare wheels may be mounted against the direction of rotation (spinning) even with a unidirectional tire for temporary use only until the regular drive wheel has been repaired or replaced. Always observe and follow applicable temporary use restrictions and speed limitations indicated on the spare wheel.

Loading the vehicle

Two labels on your vehicle show how much weight it may properly carry.

• The Tire and Loading Information placard (Example A) or the Vehicle Tire Information placard (Example B) can be found on the driver's door B-pillar. This placard tells you important information about the number of people that can be in the vehicle and the total weight that can be carried in the vehicle. It also contains information on the proper size and recommended tire inflation pressures for the original equipment tires on your vehicle.

• The Certification label, also found on the driver's door B-pillar tells you about the gross weight capacity of your vehicle, called the Gross Vehicle Weight Rating (GVWR). The GVWR includes the weight of the vehicle, all occupants, fuel and cargo. The Certification label also tells you about the front and rear axle weight capacity, called the Gross Axle Weight Rating (GAWR). The GAWR is the total allowable weight that can be carried by a single axle (front or rear). Never exceed the GVWR or GAWR for either the front axle or rear axle.



1 Driver's door B-pillar

Following is a discussion on how to work with the information contained on the two placards with regards to loading your vehicle.

Tire and Loading Information

Warning!




Do not overload the tires by exceeding the specified load limit or vehicle capacity weight as indicated on the placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.

Your vehicle is equipped with either the Tire and Loading Information placard (Example A) or the Vehicle Tire Information placard (Example B).



Data shown on placard examples are for illustration purposes only. Load limit data are specific to each vehicle and may vary from data shown in the illustrations below. Refer to placard on vehicle for actual data specific to your vehicle.

Placard (Example A)



① Load limit information on the Tire and Loading Information placard

The placard showing the load limit information is located on the driver's door B-pillar. If your vehicle is equipped with the Tire and

Tires and wheels

Loading Information placard (Example A), locate the statement "The combined weight of occupants and cargo should never exceed XXX kilograms or XXX lbs." on this placard. The combined weight of all occupants, cargo / luggage and trailer tongue load (if applicable) should never exceed the weight referenced in that statement.

Placard (Example B)



1 Load limit information on the Vehicle Tire Information placard


The placard showing the load limit information is located on the driver's door B-pillar. If your vehicle is equipped with the Vehicle Tire Information placard (Example B), locate the heading "Vehicle Capacity Weight" on this placard. The combined weight of all occupants, cargo/luggage and trailer tongue (if applicable) should never exceed the weight listed next to vehicle capacity weight.

Seating capacity

The seating capacity gives you important information on the number of occupants that can be in the vehicle. Your vehicle is equipped with either placard Example A or placard Example B located on the driver's door B-pillar (▷ page 321).




Data shown on placard examples are for illustration purposes only. Seating data are specific to each vehicle and may vary from data shown in the illustrations below. Refer to placard on vehicle for actual data specific to your vehicle.



Placard (Example A)

(1) Seating capacity



Placard (Example B)

1 Seating capacity

Steps for determining correct load limit

The following steps have been developed as required of all manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

Step 1 (Vehicles equipped with placard Example A)

 Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's placard.

Step 1 (Vehicles equipped with placard Example B)

► Locate the heading "Vehicle Capacity Weight" on your vehicle's placard.

Step 2

► Determine the combined weight of the driver and passengers that will be riding in your vehicle.

Step 3

 Subtract the combined weight of the driver and passengers from XXX kilograms or XXX lbs.

Step 4

▶ The resulting figure equals the available amount of cargo and luggage load capacity. For example, if the "XXX" amount equals 1400 lbs and there will be five 150 lbs passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs (1400-750 (5 x150) = 650 lbs).

Step 5

▶ Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in step 4. ▷▷

Operation

Tires and wheels

⊳>Step 6 (if applicable)

▶ If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle (▷ page 326).

The following table shows examples on how to calculate total and cargo load capacities with varying seating configurations and number and size of occupants. The following examples use a load limit of 1500 lbs. **This is for illustration purposes only**. Make sure you are using the actual load limit for your vehicle stated on the vehicle's placard (▷ page 321).

Example	Combined weight limit of occu- pants and cargo from placard	Number of occupants (driver and passengers)	Seating configura- tion	Occupants weight	Combined weight of all occupants	Available cargo/luggage and trailer tongue weight (total load limit or vehicle capacity weight from placard minus combined weight of all occupants)
1	1500 lbs	2	2	Occupant 1: 150 lbs Occupant 2: 180 lbs	330 lbs	1500 lbs - 330 lbs = 1170 lbs
2	1500 lbs	1	1	Occupant 1: 200 lbs	200 lbs	1500 lbs - 200 lbs = 1300 lbs
3	1500 lbs	1	1	Occupant 1: 150 lbs	150 lbs	1500 lbs - 150 lbs = 1350 lbs

The higher the weight of all occupants, the less cargo and luggage load capacity is available.

For more information, see "Trailer tongue load" (▷ page 326).

Certification label

Even after careful determination of the combined weight of all occupants, cargo and the trailer tongue load (if applicable) (> page 326) as to not exceed the permissible load limit, you must make sure that your vehicle never exceeds the Gross Vehicle Weight Rating (GVWR) and the Gross Axle Weight Rating (GAWR) for either the front or rear axle. You can obtain the GVWR and GAWR from the Certification label. The Certification Label can be found on the driver's door B-pillar (> page 321).

Gross Vehicle Weight Rating (GVWR): The total weight of the vehicle, all occupants, all cargo, and the trailer tongue load (▷ page 326) must never exceed the GVWR.

Gross Axle Weight Rating (GAWR): The total allowable weight that can be carried by a single axle (front or rear).

To assure that your vehicle does not exceed the maximum permissible weight limits (GVWR and GAWR for front and rear axle), have the loaded vehicle (including driver, passengers and all cargo and, if applicable, trailer fully loaded) weighed on a suitable commercial scale.

Trailer tongue load

The tongue load of any trailer is an important weight to measure because it affects the load you can carry in your vehicle. If a trailer is towed, the tongue load must be added to the weight of all occupants riding and any cargo you are carrying in the vehicle. The tongue load typically is ten percent of the trailer weight and everything loaded in it.

Your Mercedes-Benz has been designed primarily to carry passengers and their cargo. Mercedes-Benz does not recommend trailer towing with your vehicle.

Recommended tire inflation pressure

Warning!



Follow recommended tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and / or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Your vehicle is equipped with either the Tire and Loading Information placard (Example A) or the Vehicle Tire Information placard (Example B) located on the driver's door B-pillar (▷ page 321).

The tire inflation pressure should be checked regularly and should only be adjusted on cold tires. The tires can be considered cold if the vehicle has been parked for at least three hours or driven less than one mile (1.6 km).

Follow recommended cold tire inflation pressures listed on placard.


Keeping the tires properly inflated provides the best handling, tread life and riding comfort.

In addition to the tire placard on the driver's door B-pillar, also consult the fuel filler flap for any additional information pertaining to special driving situations. For more information, see "Important notes on tire inflation pressure" (> page 328).



Data shown on placard examples are for illustration purposes only. Tire data are specific to each vehicle and may vary from data shown in the illustrations below. Refer to placard on vehicle for actual data specific to your vehicle.


Placard (Example A)



 Tire and Loading Information placard with recommended cold tire inflation pressures

Placard (Example A) lists the recommended cold tire inflation pressures for maximum loaded vehicle weight. The tire inflation pressures listed apply to the tires installed as original equipment.

Placard (Example B)



 Vehicle Tire Information placard with recommended cold tire inflation pressures

Placard (Example B) lists the recommended cold tire inflation pressures for maximum loaded vehicle weight. The tire inflation pressures listed apply to the tires installed as original equipment.



Placard (Example B) may list recommended cold tire inflation pressures for different vehicle loads.

Important notes on tire inflation pressure

Warning!



If the tire inflation pressure repeatedly drops:

- Check the tires for punctures from foreign objects.
- Check to see whether air is leaking from the valves or from around the rim.

Tire temperature and tire inflation pressure are also increased while driving, depending on the driving speed and the tire load.

If you will be driving your vehicle at high speeds of 100 mph (160 km/h) or higher, where it is legal and conditions allow, consult the placard on the inside of the fuel filler flap on how to adjust the cold tire inflation pressure. If you do not adjust the tire inflation pressure, excessive heat can build up and result in sudden tire failure.

Be sure to readjust the tire inflation pressure for normal driving speeds. You should wait until the tires are cold before adjusting the tire inflation pressure.

Some vehicles may have supplemental tire pressure information for vehicle loads less than the maximum loaded vehicle condition. If such information is provided, it can be found on the placard located on the inside of the fuel filler flap.

Tire inflation pressure changes by approximately 1.5 psi (0.1 bar) per 18°F (10°C) of air temperature change. Keep this in mind when checking tire inflation pressure where the temperature is different from the outside temperature.

Checking tire inflation pressure

Regularly check your tire inflation pressure at least once a month.

Check and adjust the tire inflation pressure when the tires are cold. The tires can be considered cold if the vehicle has been parked for at least 3 hours or driven less than 1 mile (1.6 km).

If you check the tire inflation pressure when the tires are warm (the vehicle has been driven for several miles or sitting less than 3 hours), the reading will be approximately 4 psi (0.3 bar) higher than the cold reading. This is normal. Do not let air out to match the specified cold tire inflation pressure. Otherwise, the tire will be underinflated.

Checking tire inflation pressure manually

Follow the steps below to achieve correct tire inflation pressure:

- ► Remove the cap from the valve on one tire.
- ► Firmly press a tire gauge onto the valve.
- ▶ Read tire inflation pressure on tire gauge and check against the recommended tire inflation pressure on the placard on the driver's door B-pillar (▷ page 327). If necessary, add air to achieve the recommended tire inflation pressure.



If you have overfilled the tire, release tire inflation pressure by pushing the metal stem of the valve with e.g. a tip of a pen. Then recheck the tire inflation pressure with the tire gauge.

- ▶ Install the valve cap.
- Repeat this procedure for each tire.

Run Flat Indicator*

While the vehicle is being driven, the Run Flat Indicator monitors the set tire inflation pressures by evaluating each wheel's rotational speed. This allows the system to detect a significant loss of pressure in a tire. If a wheel's rotational speed changes due to falling tire inflation pressure, you will see a corresponding warning message in the multifunction display.

The Run Flat Indicator may function in a restricted manner or with a delay if:

- snow chains are mounted to the vehicle
- winter road conditions prevail
- you are driving on a loose surface (e.g. sand or gravel)
- you are driving in a very sporty manner (involving rapid acceleration or high speeds in curves)

Warning!



When the multifunction display shows the message Low pressure mode Check tires max. Speed 50 mph, one or more of your tires is significantly under-inflated. You should stop and check your tires as soon as possible, and inflate them to the proper tire inflation pressure as indicated on the vehicle's tire information placard. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Each tire, including the spare, should be checked monthly when cold and set to the recommended tire inflation pressure as specified in the vehicle placard and owner's manual.



The recommended tire inflation pressures for your vehicle can be found on the tire placard located on the driver's door B-pillar (▷ page 321). The tire inflation pressures are not listed in the owner's manual.

Warning!



The Run Flat Indicator does not indicate a warning for wrongly selected tire inflation pressures. Always adjust tire inflation pressure according to the placard on the driver's door B-pillar or fuel filler flap.

The Run Flat Indicator does not replace regular checks of the tire inflation pressures since a gradual pressure loss in all four tires cannot be detected by the Run Flat Indicator.

The Run Flat Indicator is not able to issue a warning due to a sudden dramatic loss of tire inflation pressure (e.g. tire blowout caused by a foreign object). In this case bring the vehicle to a halt by carefully applying the brakes and avoiding abrupt steering maneuvers.

Warning!



Follow recommend tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and / or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Do not overload the tires by exceeding the specified load limit or vehicle capacity weight as indicated on the placard on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout.

Reactivating the Run Flat Indicator

The tire inflation pressure monitor must be reactivated in the following situations:

- If you have changed the tire inflation pressure
- If you have replaced the wheels or tires
- If you have installed new wheels or tires
- Using the tire placard on the driver's door B-pillar or, if available, the inside of the fuel filler flap, make sure the tire inflation pressure of all four tires is correct.

Warning!



The Run Flat Indicator can only warn you in a reliable manner if you have set the correct tire inflation pressures for each tire.

If an incorrect tire inflation pressure was set, the system will monitor the pressure according to the incorrect value.

- Switch on the ignition (▷ page 36).
 The standard display menu appears in
- ► Press button or repeatedly until the following message appears in the multifunction display:

the multifunction display (> page 128).

Run Flat Indicator active
Reactivation poss.: +

Press button :

The following message will appear in the multifunction display:

Tire pres. now OK?

If you wish to confirm activation:

► Press button —.

The following message will appear in the multifunction display:

Run Flat Indicator reactivated

After a certain "learning phase", the Run Flat Indicator checks the set pressure values for all four tires.

If you wish to cancel activation:

Press button _____.

or

Wait until the message Tire pres. now OK? disappears.

Potential problems associated with underinflated and overinflated tires

Underinflated tire inflation pressure

Underinflated tires can:

- cause excessive and uneven tire wear
- adversely affect fuel economy
- lead to tire failure from being overheated
- adversely affect handling characteristics

Warning!



Follow recommended tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and / or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Overinflated tire inflation pressure

Overinflated tires can:

- adversely affect handling characteristics
- · cause uneven tire wear
- be more prone to damage from road hazards
- adversely affect ride comfort
- increase stopping distance

Warning!



Follow recommended tire inflation pressures.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

MOExtended system*

The MOExtended system allows you to continue driving your vehicle even if there is a total loss of pressure in one or more tires.

You may only use the MOExtended system in conjunction with the Run Flat Indicator*.



The maximum distance in emergency mode depends on the vehicle's load. It is 30 miles (50 km) if the vehicle is partially loaded and 18 miles (30 km) if the vehicle is fully loaded.

The point at which the maximum driving distance begins in emergency mode is when the warning message appears in the multifunction display indicating that there is a loss of tire inflation pressure.

Do not exceed the maximum speed of 50 mph (80 km/h).

Warning!



In emergency mode, your vehicle's driving characteristics are diminished in such situations as:

- driving around curves
- · while braking
- while accelerating rapidly

Therefore, your driving style must be adapted accordingly. Avoid abrupt steering and driving maneuvers, as well as driving over obstacles (road curbs, potholes, or off-road areas). This is especially important if the vehicle is heavily loaded.

The emergency driving distance that can be achieved greatly depends on the demands placed on the vehicle. Depending on speed, load, driving maneuvers, road conditions, outside temperature, etc., the distance can be significantly shorter or, if the vehicle is driven cautiously, somewhat longer.

Do not continue driving in emergency mode if

- you notice knocking sounds
- the vehicle starts to shake
- smoke develops and you smell rubber
- ESP[®] is intervening continuously
- you notice tears on the tire sidewalls

After driving in emergency mode, you must have the rims inspected by an authorized Mercedes-Benz Center to check if they are suitable for further use. The failed tire must be replaced in any case.




When replacing individual or all tires on the vehicle, make sure only tires marked with "MO*Extended*" are mounted in the size specified for your vehicle (> page 439).

Tire labeling

Besides tire name (sales designation) and manufacturer name, a number of markings can be found on a tire.

Following are some explanations for the markings on your vehicle's tires:



- ① Uniform Quality Grading Standards (▷ page 341)
- ② DOT, Tire Identification Number (TIN)(▷ page 339)
- (3) Maximum tire load (▷ page 340)
- (4) Maximum tire inflation pressure(▷ page 341)
- (5) Manufacturer
- (6) Tire ply material (▷ page 343)
- ⑦ Tire size designation, load and speed rating (▷ page 334)
- (8) Load identification (▷ page 338)
- (9) Tire name



For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

For more information, see "Rims and tires" (▷ page 439).

Tire size designation, load and speed rating



- 1) Tire width
- 2 Aspect ratio in %
- (3) Radial tire code
- (4) Rim diameter
- (5) Tire load rating
- 6 Tire speed rating



For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

General:

Depending on the design standards used, the tire size molded into the sidewall may have no letter or a letter preceding the tire size designation.

No letter preceding the size designation (as illustrated above): Passenger car tire based on European design standards.

Letter "P" preceding the size designation: Passenger car tire based on U.S. design standards.

Letter "LT" preceding the size designation: Light Truck tire based on U.S. design standards.

Letter "T" preceding the size designation: Temporary spare tires which are high pressure compact spares designed for temporary emergency use only.

Tire width

The tire width ① (▷ page 334) indicates the nominal tire width in mm.

Aspect ratio

The aspect ratio ② (> page 334) is the dimensional relationship between tire section height and section width and is expressed in percentage. The aspect ratio is arrived at by dividing section height by section width.

Tire code

The tire code ③ (> page 334) indicates the tire construction type. The "R" stands for radial tire type. Letter "D" means diagonal or bias ply construction; letter "B" means belted-bias ply construction.

At the tire manufacturer's option, any tire with a speed capability above 149 mph (240 km/h) can include a "ZR" in the size designation (for example: 245/40 ZR 18). For additional information, see "Tire speed rating" (> page 336).

Rim diameter

The rim diameter ④ (▷ page 334) is the diameter of the bead seat, not the diameter of the rim edge. Rim diameter is indicated in inches (in).

Tire load rating

The tire load rating (5) (> page 334) is a numerical code associated with the maximum load a tire can support.

For example, a load rating of 91 corresponds to a maximum load of 1356 lbs (615 kg) the tire is designed to support. See also "Maximum tire load" (▷ page 340) where the maximum load associated with the load index is indicated in kilograms and lbs.

Operation

Tires and wheels

Warning!



The tire load rating must always be at least half of the GAWR (▷ page 344) of your vehicle. Otherwise, tire failure may be the result which may cause an accident and/or serious personal injury to you or others.

Always replace rims and tires with the same designation, manufacturer and type as shown on the original part.

Warning!



Do not overload the tires by exceeding the specified load limit or vehicle capacity weight as indicated on the placard located on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.

For additional information on tire load rating, see "Load identification" (> page 338).



Tire load rating 5 (\triangleright page 334) and Tire speed rating 6 (\triangleright page 334) are also referred to as "service description".

Tire speed rating

The tire speed rating (a) (▷ page 334) indicates the approved maximum speed for the tire.

Warning!



Even when permitted by law, never operate a vehicle at speeds greater than the maximum speed rating of the tires.

Exceeding the maximum speed for which tires are rated can lead to sudden tire failure, causing loss of vehicle control and possibly resulting in an accident and/or personal injury and possible death, for you and for others.



Tire load rating 5 (\triangleright page 334) and Tire speed rating 6 (\triangleright page 334) are also referred to as "service description".

Summer tires

Index	Speed rating				
Q	up to 100 mph (160 km/h)				
R	up to 106 mph (170 km/h)				
S	up to 112 mph (180 km/h)				
T	up to 118 mph (190 km/h)				
Н	up to 130 mph (210 km/h)				
V	up to 149 mph (240 km/h)				
W	up to 168 mph (270 km/h)				
Υ	up to 186 mph (300 km/h)				
(Y)	above 186 mph (300 km/h)				
ZR	above 149 mph (240 km/h)				

At the tire manufacturer's option, any tire with a speed capability above
149 mph (240 km/h) can include a
"ZR" in the size designation (for example: 245/40 ZR18). To determine the maximum speed capability of the tire, the service description for the tire must be referred to.

The service description is comprised of the tire load rating 5 (\nearrow page 334) and the tire speed rating 6 (\nearrow page 334).

If your tire includes "ZR" in the size designation and no service description ⑤ and ⑥ (▷ page 334) is given, the tire manufacturer must be consulted for the maximum speed capability.

If a service description ⑤ and ⑥ (▷ page 334) is given, the speed capability is limited by the speed symbol in the service description.

Example: 245/40 ZR18 97Y.

In this example, "97Y" is the service description. The letter "Y" designates

description. The letter "Y" designates the speed rating and the speed capability of the tire is limited to 186 mph (300 km/h).

Any tire with a speed capability above 186 mph (300 km/h) must include a "ZR" in the size designation AND the service description must be placed in parenthesis. Example: 275/40 ZR 18 (99Y). The "(Y)" speed rating in parenthesis designates the maximum speed capability of the tire as being above 186 mph (300 km/h). Consult the tire manufacturer for the actual maximum permissible speed of the tire.

Operation

Tires and wheels

All-season and winter tires

Index		Speed rating					
Q	M+S ¹	up to 100 mph (160 km/h)					
T	M+S ¹	up to 118 mph (190 km/h)					
Н	M+S ¹	up to 130 mph (210 km/h)					
٧	M+S ¹	up to 149 mph (240 km/h)					

¹ or M+S 🛕 for winter tires.



Not all M+S rated tires provide special winter performance. Make sure the tires you use show M+S and the mountain/snowflake Amarking on the tire sidewall. These tires meet specific snow traction performance requirements of the Rubber Manufacturers Association (RMA) and the Rubber Association of Canada (RAC) and have been designed specifically for use in snow conditions.

Load identification



(1) Load identification



For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

In addition to tire load rating, special load information may be molded into the tire sidewall following the letter designating the tire speed rating ① (> page 338).

No specification given: absence of any text (like in above example) indicates a standard load (SL) tire.

XL or Extra Load: designates an extra load (or reinforced) tire.

Light Load: designates a light load tire.


C, D, E: designates load range associated with the maximum load a tire can carry at a specified pressure.

DOT, Tire Identification Number (TIN)

U.S. tire regulations require each new tire manufacturer or tire retreader to mold a TIN into or onto a sidewall of each tire produced.

The TIN is a unique identifier which facilitates efforts by tire manufactures to notify purchasers in recall situations or other safety matters concerning tires and gives purchasers the means to easily identify such tires.

The TIN is comprised of "Manufacturer's identification mark", "Tire size", "Tire type code", and "Date of manufacture".



- 1) DOT
- (2) Manufacturer's identification mark
- (3) Tire size
- (4) Tire type code (at the option of the tire manufacturer)
- (5) Date of manufacture



For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

DOT (Department of Transportation)

A tire branding symbol ① (▷ page 339) which denotes the tire meets requirements of the U.S. Department of Transportation.

Manufacturer's identification mark

The manufacturer's identification mark ② (> page 339) denotes the tire manufacturer.

New tires have a mark with two symbols.

Retreaded tires have a mark with four symbols. For more information on retreaded tires, see (> page 317).

Tire size

The code ③ (▷ page 339) indicates the tire size.

Tire type code

The code (4) (> page 339) may, at the option of the manufacturer, be used as a descriptive code for identifying significant characteristics of the tire.

Date of manufacture

The date of manufacture ⑤ (▷ page 339) identifies the week and year of manufacture.

The first two figures identify the week, starting with "01" to represent the first full week of the calendar year. The second two figures represent the year.

For example, "3202" represents the 32nd week of 2002.

Maximum tire load



(1) Maximum tire load rating



For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

The maximum tire load is the maximum weight the tires are designed to support.

Warning!



Do not overload the tires by exceeding the specified load limit or vehicle capacity weight as indicated on the placard located on the driver's door B-pillar. Overloading the tires can overheat them, possibly causing a blowout. Overloading the tires can also result in handling or steering problems, or brake failure.

For more information on tire load rating $(\triangleright page 335)$.

For information on calculating total and cargo load capacities (▷ page 323).

Maximum tire inflation pressure



① Maximum permissible tire inflation pressure



For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

This is the maximum permissible tire inflation pressure for the tire.

Always follow the recommended tire inflation pressure (▷ page 327) for proper tire inflation.

Warning!



Never exceed the max. tire inflation pressure. Follow recommended tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and / or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

Uniform Tire Quality Grading Standards (U.S. vehicles)

Tire manufacturers are required to grade tires based on three performance factors: treadwear, traction and temperature resistance.



- (1) Treadwear
- (2) Traction
- 3 Temperature resistance



For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

Quality grades can be found, where applicable, on the tire sidewall between tread shoulder and maximum section width. For example:

Treadwear	Traction	Temperature
200	AA	Α

All passenger car tires must conform to federal safety requirements in addition to these grades.

Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and one-half (1 $^{1}/_{2}$) times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

Traction

The traction grades, from highest to lowest, are AA, A, B, and C. Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

Warning!



The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

Temperature

The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Warning!



The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause excessive heat build-up and possible tire failure.

Tire ply material



- 1) Plies in sidewall
- (2) Plies under tread



For illustration purposes only. Actual data on tires are specific to each vehicle and may vary from data shown in above illustration.

This marking tells you about the type of cord and number of plies in the sidewall and under the tread

Tire and loading terminology

Accessory weight

The combined weight (in excess of those standard items which may be replaced) of automatic transmission, power steering, power brakes, power windows, power seats, radio, and heater, to the extent that these items are available as factory-installed equipment (whether installed or not).

Air pressure

The amount of air inside the tire pressing outward on each square inch of the tire. Air pressure is expressed in pounds per square inch (psi), or kilopascal (kPa), or bars.

Aspect ratio

Dimensional relationship between tire section height and section width expressed in percentage.

Bar

Another metric unit for air pressure. There are 14.5038 pounds per square inch (psi) to 1 bar; there are 100 kilopascals (kPa) to 1 bar.

Bead

The tire bead contains steel wires wrapped by steel cords that hold the tire onto the rim.

Cold tire inflation pressure

Tire inflation pressure when your vehicle has been sitting for at least three hours or driven no more than one mile (1.6 km).

Curb weight

The weight of a motor vehicle with standard equipment including the maximum capacity of fuel, oil, and coolant, and, if so equipped, air conditioning and additional optional equipment, but without passengers and cargo.

DOT (Department of Transportation)

A tire branding symbol which denotes the tire meets requirements of the U.S. Department of Transportation.

GAWR (Gross Axle Weight Rating)

The GAWR is the maximum permissible axle weight. The gross vehicle weight on each axle must never exceed the GAWR for the front and rear axle indicated on the certification label located on the driver's door B-pillar.

GVW (Gross Vehicle Weight)

The GVW comprises the weight of the vehicle including fuel, tools, spare wheel, installed accessories, passengers and cargo and, if applicable, trailer tongue load. The GWV must never exceed the GWVR indicated on the certification label located on the driver's door B-pillar.

GVWR (Gross Vehicle Weight Rating)

This is the maximum permissible vehicle weight of the fully loaded vehicle (weight of the vehicle including all options, passengers, fuel, and cargo and, if applicable, trailer tongue load). It is indicated on certification label located on the driver's door B-pillar.

Kilopascal (kPa)

The metric unit for air pressure. There are 6.9 kPa to 1 psi; another metric unit for air pressure is bars. There are 100 kilopascals (kPa) to 1 bar.

Maximum load rating

The maximum load in kilograms and pounds that can be carried by the tire.

Maximum loaded vehicle weight

The sum of curb weight, accessory weight, vehicle capacity weight and production options weight.

Maximum tire inflation pressure

This number is the greatest amount of air pressure that should ever be put in the tire under normal driving conditions.

Normal occupant weight

The number of occupants the vehicle is designed to seat, multiplied by 68 kilograms (150 lbs).

Occupant distribution

The distribution of occupants in a vehicle at their designated seating positions.

Production options weight

The combined weight of those installed regular production options weighing over 5 lbs (2.3 kilograms) in excess of those standard items which they replace, not previously considered in curb weight or accessory weight, including heavy duty brakes, ride levelers, roof rack, heavy duty battery, and special trim.

PSI (Pounds per square inch)

A standard unit of measure for air pressure -> bar, kilopascal (kPa).

Recommended tire inflation pressure

Recommended tire inflation pressure listed on placard located on driver's door B-pillar for normal driving conditions. Provides best handling, tread life and riding comfort.

Rim

A metal support for a tire or a tire and tube assembly upon which the tire beads are seated.

Sidewall

The portion of a tire between the tread and the bead.

TIN (Tire Identification Number)

Unique identifier which facilitates efforts by tire manufacturers to notify purchasers in recall situations or other safety matters concerning tires and gives purchases the means to easily identify such tires. The TIN is comprised of "Manufacturer's identification mark", "Tire size", "Tire type code", and "Date of manufacture".

Tire load rating

Numerical code associated with the maximum load a tire can support.

Tire ply composition and material used

This indicates the number of plies or the number of layers of rubber-coated fabric in the tire tread and sidewall. Tire manufacturers also must indicate the ply materials in the tire and sidewall, which include steel, nylon, polyester, and others.

Tire speed rating

Part of tire designation; indicates the speed range for which a tire is approved.

Traction

Force exerted by the vehicle on the road via the tires. The amount of grip provided.

Tread

The portion of a tire that comes into contact with the road.

Treadwear indicators

Narrow bands, sometimes called "wear bars" that show across the tread of a tire when only $^1/_{16}$ in (1.6 mm) of tread remains.

Uniform Tire Quality Grading Standards

A tire information system that provides consumers with ratings for a tire's traction, temperature and treadwear. Ratings are determined by tire manufacturers using government testing procedures. The ratings are molded into the sidewall of the tire.

Vehicle capacity weight

Rated cargo and luggage load plus 68 kilograms (150 lbs) times the vehicle's designated seating capacity.

Vehicle maximum load on the tire

Load on an individual tire that is determined by distributing to each axle its share of the maximum loaded vehicle weight and dividing it by two.

Rotating tires

Warning!



Rotate front and rear wheels only if the tires are of the same dimension.

If your vehicle is equipped with mixed-size tires (different tire dimensions front vs. rear), tire rotation is not possible.

Tire rotation can be performed on vehicles with tires of the same dimension all around. If your vehicle is equipped with tires of the same dimension all around, tires can be rotated, observing a front-to-rear rotation pattern that will maintain the intended rotation (spinning) direction of the tire (\triangleright page 320).

In some cases, such as when your vehicle is equipped with mixed-size tires (different tire dimension front vs. rear), tire rotation is not possible.

If applicable to your vehicle's tire configuration, tires can be rotated according to the tire manufacturer's recommended intervals in the tire manufacturer's warranty pamphlet located in your vehicle literature portfolio. If none is available, tires should be rotated every 3000 to 6000 miles (5000 to 10000 km), or sooner if necessary, according to the degree of tire wear. The same rotation (spinning) direction must be maintained (▷ page 320).

Rotate tires before the characteristic tire wear pattern becomes visible (shoulder wear on front tires and tread center wear on rear tires).

Thoroughly clean the mounting face of wheels and brake discs, i.e. the inner side of the wheels/tires, during each rotation. Check for and ensure proper tire inflation pressure.

Warning!



Have the tightening torque checked after changing a wheel. Wheels could become loose if not tightened with a torque of 80 lb-ft (110 Nm).

Only use genuine Mercedes-Benz wheel bolts specified for your vehicle's rims.

For information on wheel change, see the "Practical hints" section (\triangleright page 388) and (\triangleright page 408).

Winter driving

Before the onset of winter, have your vehicle winterized at an authorized Mercedes-Benz Center. This service includes:

- Checking anticorrosion and antifreeze concentration.
- Adding of cleaning concentrate to the water of the windshield and headlamp cleaning* system. Add MB Concentrate "S" to a pre-mixed windshield washer solvent/antifreeze which is formulated for temperatures below freezing point (▷ page 456).
- Battery test. Battery capacity drops with decreasing ambient temperature.
 A well charged battery helps to make sure the engine can be started, even at low ambient temperatures.
- Tire change.

!

When scraping ice or snow from the rear window, be careful not to damage the sealing strip or apertures along the side of the window.

Winter tires

Always use winter tires at temperatures below 45°F (7°C) and whenever wintry road conditions prevail. Not all M+S rated tires provide special winter performance. Make sure the tires you use show M+S and the mountain/snowflake Amarking on the tire sidewall. These tires meet specific snow traction performance requirements of the Rubber Manufacturers Association (RMA) and the Rubber Association of Canada (RAC) and have been designed specifically for use in snow conditions. Using winter tires is the only way to achieve the maximum effectiveness of the ABS and ESP® in winter operation.

For safe handling, make sure all mounted winter tires are of the same make and have the same tread design.

Warning!



Winter tires with a tread depth under $^{1}/_{6}$ in (4 mm) must be replaced. They are no longer suitable for winter operation.

Always observe the speed rating of the winter tires mounted to your vehicle. If the maximum speed for which your tires are rated is below the speed rating of your vehicle, you must place a notice to this effect where it will be seen by the driver. Such notices are available at your tire dealer or any authorized Mercedes-Benz Center.

Winter driving

Warning!



If you use your spare tire when winter tires are fitted on the other wheels, be aware that the difference in tire characteristics may very well impair turning stability and that overall driving stability may be reduced.

Adapt your driving style accordingly.

Have the spare tire replaced with a winter tire at the nearest authorized Mercedes-Benz Center.

Snow chains

Snow chains should only be driven on snow-covered roads at speeds not higher than 30 mph (50 km/h). Remove chains as soon as possible when driving on roads without snow.



When driving with snow chains, you may wish to deactivate the ESP[®] (▷ page 85) before setting the vehicle in motion. This will improve the vehicle's traction.

Please observe the following guidelines when using snow chains:

- Use of snow chains is not permissible with all wheel/tire combinations.
- Snow chains should only be used on the rear wheels. Follow the manufacturer's mounting instructions.

- Only use snow chains that are approved by Mercedes-Benz. Your authorized Mercedes-Benz Center will be glad to advise you on this subject.
- Use of snow chains may be prohibited depending on location. Always check local and state laws before installing snow chains.



Some tire sizes do not leave adequate clearance for snow chains. To help avoid serious damage to your vehicle or tires, use of snow chains is not permitted with the collapsible tire and MOExtended tires in general, and/or the following tire sizes:

- 225/45 R17
- 245/40 R17
- 225/40 ZR18 92Y XL (Extra Load)
- 245/35 ZR18 92Y XL (Extra Load)

Maintenance

In the "Operation" section you will find detailed information on operating, maintaining, and caring for your vehicle.

We strongly recommend that you have your vehicle serviced by an authorized Mercedes-Benz Center, in accordance with the Maintenance Booklet at the times called for by the maintenance service indicator display.

Failure to have the vehicle maintained in accordance with the Maintenance Booklet and maintenance service indicator at the designated times/mileage will result in vehicle damage not covered by the Mercedes-Benz Limited Warranty.

The maintenance service indicator will notify you when your next maintenance service is due.

Starting approximately one month before maintenance service is due, one of the following messages will appear in the multifunction display while you are driving or when you switch on the ignition (example service A):

Service A in XXXXX miles (km) Service A in XXX days Service A in X day Carry out service A

The maintenance services will be indicated by showing a service type A through type H in the multifunction display.

Types A through H are classified based on estimated time needed to perform the maintenance service, ranging:

from Service A

(approx. 1 hour)

to Service H

(approx. 8 hours)





Vehicles equipped with FSS PLUS (Flexible Service System PLUS) only (Canada vehicles): The interval between maintenance services depends on your driving habits. A gentle driving style, moderate engine speeds and the avoidance of short-distance trips will lengthen the interval between maintenance services.

Maintenance

Clearing the maintenance service indicator

The maintenance service indicator is automatically cleared after 30 seconds.

You can also clear it yourself.

Press reset button

(▷ page 25) for clearing the maintenance service indicator.

The maintenance service indicator is cleared and the standard display menu appears in the multifunction display (> page 128).

Maintenance service term exceeded

If you have exceeded the suggested maintenance service term, you will see the following message in the multifunction display:

Service A exceeded by XXXXX miles (km) Service A exceeded by XXX days Service A exceeded by X day

In addition, a signal sounds when the message appears.

Any authorized Mercedes-Benz Center will reset the maintenance service indicator following a completed maintenance service.

Calling up the maintenance service indicator

- Switch on the ignition (▷ page 36).
 The standard display menu appears in the multifunction display (▷ page 128).
- Press button or repeatedly on the multifunction steering wheel until the maintenance service indicator appears in the multifunction display (▷ page 124). ▷▷

Maintenance

 $\triangleright \triangleright$



If the battery is disconnected, the days of disconnection will not be included in the count shown by the maintenance service indicator. To arrive at the true maintenance service deadline, you will need to subtract these days from the days shown in the maintenance service indicator.

Do not confuse the maintenance service indicator with the engine oil level indicator ...

Resetting the maintenance service indicator

In the event that the maintenance service on your vehicle is not carried out by an authorized Mercedes-Benz Center, you can have the maintenance service indicator reset. The automotive maintenance facility carrying out the maintenance service will find the information for resetting the maintenance service indicator in the maintenance-relevant information for your vehicle. Such information is available from either your authorized Mercedes-Benz Center or directly from Mercedes-Benz.



If the maintenance service indicator was inadvertently reset, have an authorized Mercedes-Benz Center correct it.

Only reset if the proper maintenance service has been performed. Resetting the system without performing the proper maintenance service as called for by the maintenance service indicator will result in engine damage and/or other vehicle damage not covered by the Mercedes-Benz Limited Warranty.

▼ Vehicle care

Cleaning and care of vehicle

Warning!



Many cleaning products can be hazardous. Some are poisonous, others are flammable. Always follow the instructions on the particular container. Always open your vehicle's doors or windows when cleaning the inside.

Never use fluids or solvents that are not designed for cleaning your vehicle.

Always lock away cleaning products and keep them out of reach of children.

While in operation, even while parked, your vehicle is subjected to varying external influences which, if gone unchecked, can attack the paintwork as well as the undercarriage and cause lasting damage.

Such damage is caused not only by extreme and varying climatic conditions, but also by:

- Air pollution
- · Road salt
- Tar
- Gravel and stone chipping

To avoid paint damage, you should immediately remove:

- · Grease and oil
- Fuel
- Coolant
- · Brake fluid
- Bird droppings
- Insects
- Tree resins, etc.

Frequent washing reduces and/or eliminates the aggressiveness and potency of the above adverse influences.

More frequent washings are necessary to deal with unfavorable conditions:

- near the ocean
- in industrial areas (smoke, exhaust emissions)
- · during winter operation

You should check your vehicle from time to time for stone chipping or other damage. Any damage should be repaired as soon as possible to prevent corrosion.

In doing so, do not neglect the underbody of the vehicle. A prerequisite for a thorough check is a washing of the underbody followed by a thorough inspection. Damaged areas need to be re-undercoated.

Your vehicle has been treated at the factory with a wax-base rustproofing in the body cavities which will last for the lifetime of the vehicle. Post-production treatment is neither necessary nor recommended by Mercedes-Benz because of the possibility of incompatibility between materials used in the production process and others applied later.

Operation

Vehicle care

We have selected car-care products and compiled recommendations which are specially matched to our vehicles and which always reflect the latest technology. You can obtain Mercedes-Benz approved car-care products at an authorized Mercedes-Benz Center.

Scratches, corrosive deposits, corrosion or damage due to negligent or incorrect care cannot always be removed or repaired with the car-care products recommended here. In such cases it is best to seek aid at an authorized Mercedes-Benz Center.

The following topics deal with the cleaning and care of your vehicle and give important "how-to" information as well as references to Mercedes-Benz approved car-care products.

Power washer



Follow the instructions provided by the power washer manufacturer on maintaining a distance between the vehicle and the nozzle of the power washer.

Never use a round nozzle to power-wash tires. The intense jet of water can result in damage to the tire.

Always replace a damaged tire.

Always keep the jet of water moving across the surface. Do not aim directly at electrical parts, electrical connectors, seals, or other rubber parts.

Tar stains

Quickly remove tar stains before they dry and become more difficult to remove. A tar remover is recommended.

Paintwork, painted body components



Affixing stickers, adhesive tape or similar materials to painted body components may damage the paintwork.

Mercedes-Benz approved Paint Care should be applied when water drops on the paint surface do not "bead up". This should normally be done every 3 to 5 months, depending on the climate and washing detergent used.

Mercedes-Benz approved Paint Cleaner should be applied if the paint surface shows signs of embedded dirt (i.e. loss of gloss).

Do not apply any of these products or wax if your vehicle is parked in the sun or if the hood is still hot.

► Use the appropriate MB-Touch-Up Stick for quick and provisional repairs of minor paint damage (i.e. chips from stones, vehicle doors, etc.).

Engine cleaning

Prior to cleaning the engine compartment, make sure to protect electrical components and connectors from the intrusion of water and cleaning agents.

Corrosion protection, such as MB Anticorrosion Wax should be applied to the engine compartment after every engine cleaning. Before applying, all control linkage bushings and joints should be lubricated. The poly-V-belt and all pulleys should be protected from any wax.

Vehicle washing

In the winter, thoroughly remove all traces of road salt as soon as possible.

Hand-wash

Do not use hot water or wash your vehicle in direct sunlight.

- Use only a mild car wash detergent, such as Mercedes-Benz approved Car Shampoo.
- ► Thoroughly spray the vehicle with a diffused jet of water.
 - Direct only a very weak spray towards the ventilation intake.
- ► Use plenty of water and rinse the sponge and chamois frequently.
- ► Rinse with clean water and thoroughly dry with a chamois.

Do not allow cleaning agents to dry on the finish.

Automatic car wash

You can have your car washed in an automatic car wash from the start. Automatic car washes without brushes are preferable.

If the vehicle is very dirty, prewash it before running it through the automatic car wash.



Due to the width of the vehicle, fold in exterior rear view mirrors prior to running the vehicle through an automatic car wash to prevent damage to the mirrors.

Make sure that the windshield wiper switch is set to **0** (▷ page 56). Otherwise, the rain sensor could activate and cause the wipers to move unintentionally. This may lead to vehicle damage.



After running the vehicle through an automatic car wash, wipe any wax off of the windshield (▷ page 357). This will prevent smears and reduce wiping noise which can be caused by residual wax on the windshield.

When leaving the car wash, make sure that the mirrors are folded out. Otherwise they may vibrate.

Ornamental moldings

For regular cleaning and care of very dirty chrome-plated parts, use a chrome cleaner.

Headlamps, tail lamps, side makers, turn signal lenses

 Use a mild car wash detergent, such as Mercedes-Benz approved Car Shampoo, with plenty of water.



Only use window cleaners that are suitable for plastic lamp lenses. Window cleaners which are not suitable may damage the plastic lamp lenses of the headlamps. Therefore, do not use abrasives, solvents or cleaners that contain solvents.

Never apply strong force and use only a soft, non-scratchy cloth when cleaning the lenses. Do not attempt to wipe dirty lenses with a dry cloth or sponge.

Otherwise you may scratch or damage the lens surface.

Cleaning the windows and the wiper blades



The windshield wipers must be in a vertical position before folding them away from the windshield. They could otherwise damage the hood.

Never open the hood when the wiper arms are folded forward.

- Switch on the ignition (▷ page 36).
- Turn combination switch to wiper setting II (▷ page 56).
- ▶ With wiper arms in vertical position, switch off the ignition (▷ page 36).

Warning!



For safety reasons, switch off wipers and remove SmartKey from starter switch before cleaning the windshield. Otherwise, the wiper motor could suddenly turn on and cause injury.

- ► Fold the wiper arms forward until it snaps into place.
- ► Clean the wiper blade inserts with a clean cloth and detergent solution.
- Use a clean cloth and window cleaning solution on all outside and inside glass surfaces.

An automotive glass cleaner is recommended. $\quad \rhd \rhd$

 $\triangleright \triangleright$



To clean the window interior, do not use a dry cloth, abrasives, solvents or cleaners containing solvents. Do not touch the inside of the front, rear or side windows with hard objects such as an ice scraper or ring. Doing so may damage the windows.



Fold the windshield wiper arms back onto the windshield before turning the SmartKey in the starter switch.

Hold on to the wiper when folding the wiper arm back. If released, the force of the impact from the tensioning spring could crack the windshield.

Rear window cleaning

Clean the rear window with the hardtop fully raised and closed.

Warning!



Do not clean the rear window with the hardtop in a position other than the fully raised and closed position. Otherwise, the hardtop may move unexpectedly which may result in

personal injury to you or others.

 Use a clean cloth and window cleaning solution on all outside and inside glass surfaces.

An automotive glass cleaner is recommended.

Light alloy wheels

If possible, clean wheels once a week.

Use Mercedes-Benz approved Wheel Care, a soft bristle brush and a strong spray of water for cleaning the light alloy wheels.



Only use acid-free cleaning materials. Acid may cause corrosion or damage the clear coat.



The vehicle should not be parked for an extended period of time immediately after it has been cleaned, especially not after the wheel rims have been cleaned with wheel rim cleaner. Wheel rim cleaners can lead to increased corrosion of the brake discs and brake pads. Therefore, the vehicle's brake system should always be warmed-up before it is parked after cleaning. To do so, please drive your vehicle for several minutes to allow the brakes to dry.

When applying Mercedes-Benz approved Tire Care and Mercedes-Benz approved Wheel Care products, take care not to spray them on the brake discs.

Plastic and rubber parts

 Use a gentle dishwashing detergent or mild detergent for delicate fabrics as a washing solution.

!

Do not use oil or wax on these parts.

Instrument cluster and cup holders

- ► Use a gentle dishwashing detergent or mild detergent for delicate fabrics as a washing solution.
- ► Wipe with a cloth moistened in a lukewarm solution.

!

To prevent scratches, do not use scouring agents.

Hard plastic trim items

► Use Pour Mercedes-Benz approved Interior Care, a soft, lint-free cloth and apply with light pressure onto.

!

To prevent scratches, do not use scouring agents.

Steering wheel and gearshift/gear selector lever

Wipe with a damp cloth and dry thoroughly or clean with Mercedes-Benz approved Leather Care.

Carpets

 Use Mercedes-Benz approved Carpet and Fabric Care for cleaning the carpets.

Operation

Vehicle care

Headliner and shelf below rear window

Use a soft bristle brush or a dry-shampoo cleaner in case of excessive dirt.

Seat belts

Use only clear, lukewarm water and soap.



The webbing must not be treated with chemical cleaning agents. Do not dry the webbing at temperatures above 176°F (80°C) or in direct sunlight.

Warning!



Do not bleach or dye seat belts as this may severely weaken them. In a crash they may not be able to provide adequate protection.

Upholstery

Using aftermarket seat covers or wearing clothing that have the tendency to give off coloring (e.g. when wet, etc.) may cause the upholstery to become permanently discolored. By lining the seats with a proper intermediate cover, contact-discoloration will be prevented.

Leather upholstery

Wipe leather upholstery with a damp cloth and dry thoroughly or clean with Mercedes-Benz approved Leather Care.

Exercise particular care when cleaning perforated leather as its underside should not become wet.

Wood trims

▶ Dampen cloth using water and use damp cloth to clean wood trims in your vehicle.



Do not use solvents like tar remover or wheel cleaner nor polishes or waxes as these may be abrasive.

What to do if ...

Where will I find ...?

Unlocking/locking in an emergency

Opening/closing in an emergency

Replacing SmartKey batteries

Replacing bulbs

Replacing wiper blades

Flat tire

Battery

Jump starting

Towing the vehicle

Fuses



Lamps in instrument cluster

General information:

If any of the following lamps in the instrument cluster fails to come on during the bulb self-check when switching on ignition (> page 36), have the respective bulb checked and replaced if necessary.

Problem



The yellow ABS indicator lamp comes on while driving.

Possible cause/consequence

The ABS has detected a malfunction and has switched off. The BAS and ESP® are also switched off (see messages in display).

The brake system is still functioning normally but without the ABS available.

If the ABS control unit is malfunctioning, other systems such as the automatic transmission* may also be malfunctioning.

The charging voltage has fallen below 10 volts and the ABS has switched off.

The battery might not be charged sufficiently.

Suggested solution

- Continue driving with added caution.
 Wheels may lock during hard braking, reducing steering capability.
- ► Read and observe messages in the multifunction display (> page 368).
- ► Have the system checked at an authorized Mercedes-Benz Center as soon as possible.

Failure to follow these instructions increases the risk of an accident.

- Switch off electrical consumers that are currently not needed, e.g. seat heating*.
- If necessary, have the generator and battery checked.

When the voltage is above this value again, the ABS is operational again.

Problem			Possible cause/consequence	Suggested solution
	(USA only) (Canada only)	The red brake warning lamp comes on while driving and you hear a warning sound.	You are driving with the parking brake set.	▶ Release the parking brake (▷ page 52).
		The red brake warning lamp comes on while driving.		▶ Risk of accident! Carefully stop the vehicle and notify an authorized Mercedes-Benz Center. Do not add brake fluid! This will not solve the problem.

Warning!



Driving with the brake warning lamp illuminated can result in an accident. Have your brake system checked immediately if the brake warning lamp stays on. Do not add brake fluid before checking the brake system. Overfilling the brake fluid reservoir can result in spilling brake fluid on hot engine parts and the brake fluid catching fire. You can be seriously burned.

If you find that the brake fluid in the brake fluid reservoir has fallen to the minimum mark or below, have the brake system checked for brake pad thickness and leaks.

Proble	m		Possible cause/consequence	Suggested solution
CHECK (USA only)	(USA only) (Canada only)	The yellow engine malfunction indicator lamp comes on while driving.	There is a malfunction in: the fuel management system the ignition system the emission control system systems which affect emissions Such malfunctions may result in excessive emissions values and may switch the engine to its limp-home (emergency operation) mode.	Have the vehicle checked as soon as possible by an authorized Mercedes-Benz Center. An on-board diagnostic connector is used by the service station to link the vehicle to the shop diagnostics system. It allows the accu- rate identification of system malfunctions through the readout of diagnostic trouble codes. It is located in the front left area of the footwell near the hood release.
			Your fuel tank is empty.	 After refueling start, turn off and restart the engine three or four times in succession. The limp-home mode is canceled. You do not need to have your vehicle checked.
		Additionally you see the message Check gas cap See Operator's Manual in the multi- function display.	A loss of pressure has been detected in the fuel system. The fuel cap may not be closed properly or the fuel system may be leaking.	 ▶ Check the fuel cap (▷ page 304). If it is not closed properly: ▶ Close the fuel cap. If it is closed properly: ▶ Have the fuel system checked by an authorized Mercedes-Benz Center.

Proble	m	Possible cause/consequence	Suggested solution
\triangle	The yellow ESP® warning lamp comes on while driving.	The ESP® is deactivated.	► Switch the ESP® back on (> page 86).
		Risk of accident!	If the ESP® cannot be switched back on, have the
		Adapt your speed and driving to the prevailing road, weather and traffic conditions.	system checked at an authorized Mercedes-Benz Center as soon as possible.
	The yellow ESP® warning lamp flashes while driving.	The ESP® or traction control has come into operation because of de-	► When driving off, apply as little throttle as possible.
		tected traction loss in at least one tire.	▶ While driving, ease up on the accelerator.
			► Adapt your speed and driving to the prevailing road and weather conditions.
			Do not deactivate the ESP [®] . Exceptions: (▷ page 84).
			Failure to follow these instructions increases the risk of an accident.
	The yellow fuel reserve warning lamp	_	► Refuel at the next gas station (▷ page 304).
	comes on while driving. Additionally you see the message Reserve fuel in the multifunction	serve mark.	After refueling you will see the message 1 message in the multifunction display.
	display.		▶ Press reset button to confirm the message (> page 24).

What to do if ...

Problem		Possible cause/consequence	Suggested solution
	The yellow fuel reserve warning lamp flashes after starting the engine.	The fuel cap is not closed properly.	► Close the fuel cap.
茶	The red seat belt telltale comes on after starting the engine with all doors closed.	The seat belt telltale reminds you and your passenger to fasten your seat belts before driving off.	► Fasten your seat belts (> page 71).
	The red seat belt telltale flashes and you additionally hear an intermittent warning signal with increasing intensity for a maximum of 60 seconds when the vehicle's speed exceeds 15 mph (25 km/h).	,	 Fasten your seat belts (▷ page 71). Remove the items from the passenger seat and put them in a safe place.
SRS	The red SRS indicator lamp comes on while driving.	There is a malfunction in the restraint systems. The air bags or emergency tensioning devices (ETDs) could deploy unexpectedly or fail to deploy in an accident.	▶ Drive with added caution to the nearest authorized Mercedes-Benz Center.

Warning!



In the event that a malfunction of the SRS is indicated as outlined above, the SRS may not be operational. For your safety, we

strongly recommend that you visit an authorized Mercedes-Benz Center immediately to have the system checked; otherwise the SRS may not be activated when needed in an accident, which could result in serious or fatal injury, or it might deploy unexpectedly and unnecessarily which could also result in an accident and/or injury to you or to others.

Lamp in center console

Problem		Possible cause/consequence	Suggested solution
PASS AIR BAG OFF	The passenger front air bag off indicator lamp comes on and remains illuminated (▷ page 77).	A BabySmart TM child seat is installed on the passenger seat. Therefore the passen- ger front air bag is switched off.	
		The system is malfunctioning when there is no BabySmart $^{\text{TM}}$ child seat installed on the passenger seat.	► Have the system checked at an authorized Mercedes-Benz Center as soon as possible.
	The passenger front air bag off indicator lamp does not come on or does not remain illuminated with a BabySmart™ child seat properly installed on the passenger seat.	The system is malfunctioning.	► Make sure there is nothing between seat cushion and child seat.
			► Check installation of the child seat (> page 75).
			If the passenger front air bag off indicator lamp remains out:
			► Have the system checked at an authorized Mercedes-Benz Center as soon as possible.
			Do not use the BabySmart TM restraint to transport children on the front passenger seat until the system has been repaired.

What to do if ...

Vehicle status messages in the multifunction display

Warning and malfunction messages appear in the multifunction display located in the instrument cluster.

Certain warning and malfunction messages are accompanied by an audible signal.

Address these messages accordingly and follow the additional instructions given in this Operator's Manual.

Selecting the vehicle status message memory menu in the control system (> page 132) displays both cleared and uncleared messages.

High-priority messages appear in the multifunction display in red color.

Certain messages of high priority cannot be cleared from the multifunction display using the reset button (\triangleright) page 24) or button (\triangleright) , (\triangleright) , or (\triangleright) on the steering wheel.

Other high-priority messages and messages of less immediate priority (regular display colors) can be cleared from the multifunction display using the reset button (▷ page 24) or button (▷ page 24), or button (▷ page 24), or the steering wheel. They are then stored in the vehicle status message memory (▷ page 132). Remember that clearing a message will only make the message disappear. Clearing a message will not correct the condition that caused the message to appear.

Warning!



All categories of messages contain important information which should be taken note of and, where a malfunction is indicated, addressed as soon as possible at an authorized Mercedes-Benz Center.

Failure to repair condition noted may cause damage not covered by the Mercedes-Benz Limited Warranty, or result in property damage or personal injury.

Warning!



No messages will be displayed if either the instrument cluster or the multifunction display is inoperative.

Contact your nearest authorized Mercedes-Benz Center.



Switching on ignition (> page 36) causes all instrument cluster lamps (except high beam headlamp indicator lamp and turn signal indicator lamps unless activated) as well as the multifunction display to come on. Make sure the lamps and multifunction display are in working order before starting your journey.

On the pages that follow, you will find a compilation of the most important warning and malfunction messages that may appear in the multifunction display.

For your convenience the messages are divided into two sections:

- Text messages (⊳ page 370)
- Symbol messages (▷ page 374)

What to do if ...

Text messages

Display message	•	Possible cause/consequence	Possible solution
ABS	malfunction Visit workshop	The ABS has detected a malfunction and has switched off. The ESP® and the BAS are also deactivated.	 Continue driving with added caution. Wheels may lock during hard braking, reducing steering capability.
		The brake system is still functioning normally but without the ABS avail-	► Have the system checked at an authorized Mercedes-Benz Center as soon as possible.
		able.	Failure to follow these instructions increases the risk of an accident.
	Display malfunction Visit workshop	The ABS or the ABS display is mal- functioning.	 Continue driving with added caution. Wheels may lock during hard braking, reducing steering capability.
			► Have the system checked at an authorized Mercedes-Benz Center as soon as possible.
			Failure to follow these instructions increases the risk of an accident.
Cruise control	Cruise control Drive to workshop	Cruise control is malfunctioning.	► Have cruise control checked by an authorized Mercedes-Benz Center.

Display message		Possible cause/consequence	Possible solution
ESP	malfunction Visit workshop	The ESP® was deactivated because of a malfunction. The ABS might not be operational.	 Continue driving with added caution. Visit an authorized Mercedes-Benz Center as soon as possible.
		The brake system is still functioning normally but without the ESP® available.	Failure to follow these instructions increases the risk of an accident.
	unavailable See Operator's Manual	The self-diagnosis has not been completed.	The display will clear after driving a short distance at more than 12 mph (20 km/h).
		The brake system is still functioning normally but without the ESP® available.	
		The charging voltage has fallen below ten volts. The ESP® has switched off.	► Continue driving with added caution.
		The brake system is still functioning	When the voltage is above this value again, the ESP® is operational again.
		normally but without the ESP® available.	► If necessary, have the generator and battery checked.

Display messag	ge	Possible cause/consequence	Possible solution
ESP	Display malfunction Visit workshop	The ESP® or the ESP® display is malfunctioning.	 Continue driving with added caution. Visit an authorized Mercedes-Benz Center as soon as possible. Failure to follow these instructions increases the risk of an accident.
SRS	Restraint system malfunction Drive to workshop	The SRS system is malfunctioning.	▶ Drive with added caution to the nearest authorized Mercedes-Benz Center.
Transmis- sion	Visit workshop	Vehicles with automatic transmission*: The provided operating safety of the automatic transmission is reduced.	▶ Drive with added caution to the nearest authorized Mercedes-Benz Center.

Display messages		Possible cause/consequence	Possible solution
	Run Flat Indicator inactive	The Run Flat Indicator* is malfunctioning.	► Have the Run Flat Indicator* checked by an authorized Mercedes-Benz Center.
	Tire pressure Check tires	The pressure is too low in one or more tires.	► Carefully bring the vehicle to a halt, avoiding abrupt steering and braking maneuvers. Observe the traffic situation around you.
			► Check and adjust the tire inflation pressure as required (> page 329).
			\blacktriangleright If necessary, change the wheel (\triangleright page 408).
			► Reactivate the Run Flat Indicator* after adjusting the tire inflation pressure values (▷ page 304).
	Check tires	There was a warning message about a loss in tire inflation pressure and	► Make sure that the correct tire inflation pressure is set for each tire.
	Then reactivate Run Flat Indicator	the Run Flat Indicator* has not been reactivated yet.	► Then reactivate the Run Flat Indicator*.
	Run Flat Indicator unavailable	The Run Flat Indicator* has been switched off due to an error.	► Have the Run Flat Indicator* checked by an authorized Mercedes-Benz Center.

Warning!



Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle.

You may lose control of the vehicle. Continued driving with a flat tire will cause excessive heat build-up and possibly a fire.

What to do if ...

Symbol messages

Display symbol	Display message	Possible cause/consequence	Possible solution
- •	Battery/Alternator Visit workshop	The battery is no longer charging. Possible causes: • Alternator malfunctioning • Broken poly-V-belt	 Stop immediately and check the poly-V-belt. If it is broken: Do not continue to drive. Notify an authorized Mercedes-Benz Center.
		Do not forget that the brake system requires electrical energy and may be operating with restricted capability. Considerably greater brake pedal force is required and the stopping distance is increased.	 If it is in order: Drive immediately to the nearest authorized Mercedes-Benz Center. Adjust driving to be consistent with reduced braking responsiveness.

Display symbol	Display message	Possible cause/consequence	Possible solution
USA only:	Release parking brake	You are driving with the parking brake set.	► Release parking brake (▷ page 52).
Canada only:			
USA only:	Brake fluid Visit workshop	There is insufficient brake fluid in the reservoir.	► Risk of accident! Stop the vehicle and notify an authorized Mercedes-Benz Center. Do
Canada only:			not add brake fluid! This will not solve the problem.
	Brake wear Visit workshop	The brake pads have reached their wear limit.	► Have the brake pads replaced as soon as possible.

Warning!



Driving with the message Brake fluid Visit workshop displayed can result in an accident. Have your brake system checked immediately. Do not add brake fluid before checking the brake system.

Overfilling the brake fluid reservoir can result in spilling brake fluid on hot engine parts and the brake fluid catching fire. You can be seriously burned.



If you find that the brake fluid in the brake fluid reservoir has fallen to the minimum mark or below, have the brake system checked for brake pad thickness and leaks.



Brake pad thickness must be visually checked by a qualified technician at the intervals specified in the Maintenance Booklet.

What to do if ...

Display symbol	Display message	Possible cause/consequence	Possible solution
• • • • • • • • • • • • • • • • • • •	Coolant	•	► Stop the vehicle and immediately turn off the engine.
	Stop, engine off	broken.	► Check the poly-V-belt (> page 437).
			If it is broken:
			▶ Do not continue to drive. Otherwise the engine will overheat due to an inoperative water pump which may result in damage to the engine. Notify an authorized Mercedes-Benz Center.
			If it is in order:
			▶ Do not continue to drive the vehicle with this message displayed. Doing so could result in serious engine damage that is not covered by the Mercedes-Benz Limited Warranty. Drive immediately to the nearest authorized Mercedes-Benz Center.
			▶ Observe the coolant temperature display (▷ page 128).

During severe operating conditions and stop-and-go city traffic, the coolant temperature may rise close to 248°F (120°C).



The engine should not be operated with the coolant temperature above 248°F (120°C).

Doing so may cause serious engine damage which is not covered by the Mercedes-Benz Limited Warranty.

Display symbol	Display message	Possible cause/consequence	Possible solution
E	Coolant	The coolant is too hot.	► Stop the vehicle and turn off the engine.
	Stop, engine off		► Only start the engine again after the message disappears. You could otherwise damage the engine.
	Coolant Check level	The coolant level is too low.	 ▶ Add coolant (▷ page 313). ▶ If you have to add coolant frequently, have the cooling system checked by an authorized Mercedes-Benz Center.

Warning!



Driving when your engine is badly overheated can cause some fluids which may have leaked into the engine compartment to catch fire. You could be seriously burned.

Steam from an overheated engine can cause serious burns and can occur just by opening the hood. Stay away from the engine if you see or hear steam coming from it. Turn off the engine, get out of the vehicle and do not stand near the vehicle until the engine has cooled down.

The engine should not be operated with the coolant temperature above 248°F (120°C). Doing so may cause serious engine damage which is not covered by the Mercedes-Benz Limited Warranty.

Warning!



Do not spill antifreeze on hot engine parts. Antifreeze contains ethylene glycol which may burn if it comes into contact with hot engine parts. You can be seriously burned.

!

Do not ignore the low engine coolant level warning. Extended driving with this message and symbol displayed may cause serious engine damage not covered by the Mercedes-Benz Limited Warranty.

Do not drive without sufficient amount of coolant in the cooling system. The engine will overheat, causing major engine damage.

Display symbol	Display message	Possible cause/consequence	Possible solution
res	Display malfunction Visit workshop	Certain electronic systems are un- able to relay information to the con- trol system. The following systems may have failed:	► Have the electronic systems checked by an authorized Mercedes-Benz Center.
		Coolant temperature display	
		 Tachometer 	
		Cruise control display	
4	Display malfunction Visit workshop	The instrument cluster display is malfunctioning.	When the display is malfunctioning, warnings and malfunction messages might not be displayed.
			► Continue driving with added caution.
			► Visit an authorized Mercedes-Benz Center as soon as possible.
		The displays for several systems have malfunctioned. Some systems themselves may also have malfunctioned.	 Continue driving with added caution. Have the electronic systems checked by an authorized Mercedes-Benz Center.
(1)	Doors open	You are attempting to drive with one or more doors open.	► Close all doors.

Display symbol	Display message	Possible cause/consequence	Possible solution
***	Check oil level when next refueling	SLK 280 and SLK 350 only: The engine oil level has dropped to a critical level.	 Check the engine oil level (▷ page 308) and add engine oil as required (▷ page 312). If you must add engine oil frequently, have the engine checked for possible leaks.
	USA only: Add 1 qt. engine oil when next refueling	SLK 55 AMG only: The engine oil level is too low.	► Add engine oil (▷ page 312) and check the engine oil level (▷ page 308).
	Canada only: Add 1 liter engine oil when next refueling		

When the message Add 1 qt. (Canada: 1 liter) engine oil when next refueling (SLK 55 AMG) or Check oil level when next refueling (SLK 280, SLK 350) appears while the engine is running and at operating temperature, the engine oil level has dropped to approximately the minimum level.

When this occurs, the warning will first come on intermittently and then stay on if the oil level drops further.

Visually check for oil leaks. If no obvious oil leaks are noted, drive to the nearest service station where the engine oil should be topped to the required level with an approved oil specified in the Factory Approved Service Products pamphlet.



The engine oil level warnings should not be ignored. Extended driving with the symbol displayed could result in serious engine damage that is not covered by the Mercedes-Benz Limited Warranty.

Display symbol	Display message	Possible cause/consequence	Possible solution
	Engine oil level Stop, engine off	SLK 55 AMG only: There is no oil in the engine. There is a danger of engine damage.	 Carefully bring the vehicle to a halt as soon as possible. Turn off the engine. Add engine oil (▷ page 312) and check the engine oil level (▷ page 308).
	Engine oil level Visit workshop	SLK 55 AMG only: The measuring system is malfunctioning.	► Have the measuring system checked by an authorized Mercedes-Benz Center.
	Engine oil level Reduce oil level	SLK 55 AMG only: You have added too much engine oil. There is a risk of damaging the engine or the catalytic converter.	► Have oil siphoned or drained off. Observe all legal requirements with respect to its disposal.
	Engine oil Visit workshop	SLK 55 AMG only: There may be water in the engine oil.	► Have the engine oil checked.

Display symbol	Display message	Possible cause/consequence	Possible solution
	Fuel reserve	The fuel level has dropped below the reserve mark.	► Refuel at the next gas station (▷ page 304).
	Check gas cap	The fuel cap may not be closed	► Check the fuel cap (▷ page 304).
	See Operator's Manual	properly.	If it is not closed properly:
			► Close the fuel cap.
			If it is closed properly:
			► Have the fuel system checked by an authorized Mercedes-Benz Center.
€	Lock retractable roof	You are driving with the retractable hardtop not properly locked.	► Stop the vehicle in a safe location. Observe the traffic situation around you.
			Push the retractable hardtop switch forward or rearward until the retractable hardtop is completely closed or open (▷ page 252).
	Retractable roof Visit workshop	The retractable hardtop is malfunctioning.	► Have the retractable hardtop checked by an authorized Mercedes-Benz Center.
∂	Close hood!	You are driving with the hood open.	► Close the hood (▷ page 307).
	Replace key	The SmartKey is malfunctioning.	▶ Visit an authorized Mercedes-Benz Center.

Display symbol	Display message	Possible cause/consequence	Possible solution
	3rd brake light	The high mounted brake lamp is malfunctioning. This message will only appear if a critical number of LEDs have stopped working.	► Visit an authorized Mercedes-Benz Center as soon as possible.
	Tail lamp / brake lamp left Back-up lamp on	The left tail lamp/brake lamp is malfunctioning. This message will only appear if a critical number of LEDs have stopped working. A backup bulb has been brought into use.	➤ Visit an authorized Mercedes-Benz Center as soon as possible.
	Tail lamp / brake lamp right Back-up lamp on	The right tail lamp/brake lamp is malfunctioning. This message will only appear if a critical number of LEDs have stopped working. A backup bulb has been brought into use.	► Visit an authorized Mercedes-Benz Center as soon as possible.
	Brake lamp Visit workshop	Brake lamp illumination is delayed or lamp is permanently on.	► Visit an authorized Mercedes-Benz Center as soon as possible.
	Front foglamp, L	The left front fog lamp is malfunctioning.	► Visit an authorized Mercedes-Benz Center as soon as possible.
	Front foglamp, R	The right front foglamp is malfunctioning.	► Visit an authorized Mercedes-Benz Center as soon as possible.

Display symbol	Display message	Possible cause/consequence	Possible solution
☆	Rear foglamp Back-up lamp on	The rear fog lamp on the driver's side is malfunctioning. A backup bulb has been brought into use.	▶ Replace the bulb as soon as possible.
	High beam, left	The left high beam lamp (halogen headlamps)/high beam flasher lamp (Bi-Xenon* headlamps) is malfunctioning.	▶ Replace the bulb as soon as possible.
	High beam, right	The right high beam lamp (halogen headlamps)/high beam flasher lamp (Bi-Xenon* headlamps) is malfunctioning.	▶ Replace the bulb as soon as possible.
	Lamp sensor Drive to workshop The light sensor is malfunctioning. The headlamps switch on automati-	► In the control system, set lamp operation to manual (> page 143).	
		cally.	► Switch on headlamps using the exterior lamp switch (▷ page 110).
			► Visit an authorized Mercedes-Benz Center as soon as possible.
	Left license plate lamp malfunction	The left license plate lamp is mal- functioning.	▶ Replace the bulb as soon as possible.
	Right license plate lamp malfunction	The right license plate lamp is malfunctioning.	▶ Replace the bulb as soon as possible.

Display symbol	Display message	Possible cause/consequence	Possible solution
☼	Left reverse lamp malfunction	The left backup lamp is malfunctioning.	▶ Replace the bulb as soon as possible.
	Right reverse lamp malfunction	The right backup lamp is malfunctioning.	► Replace the bulb as soon as possible.
	Low beam, left	The left low beam lamp is malfunctioning.	 Halogen headlamp: ▶ Replace the bulb as soon as possible. Bi-Xenon* headlamp: ▶ Visit an authorized Mercedes-Benz Center as soon as possible.
	Low beam, right	The right low beam lamp is malfunctioning.	 Halogen headlamp: ▶ Replace the bulb as soon as possible. Bi-Xenon* headlamp: ▶ Visit an authorized Mercedes-Benz Center as soon as possible.
	Park. light, front left	The left front parking lamp is mal- functioning.	▶ Replace the bulb as soon as possible.
	Park. light, front right	The right front parking lamp is malfunctioning.	▶ Replace the bulb as soon as possible.
	Remove key	You have forgotten to remove the SmartKey.	► Remove the SmartKey from the starter switch.

Display symbol	Display message	Possible cause/consequence	Possible solution
- ∯-	Side marker lamp, front left	The left front side marker lamp is malfunctioning.	▶ Replace the bulb as soon as possible.
	Side marker lamp, front right	The right front side marker lamp is malfunctioning.	▶ Replace the bulb as soon as possible.
	Rear left side marker lamp malfunction	The left rear side marker lamp is malfunctioning. This message will only appear if a critical number of LEDs have stopped working.	► Visit an authorized Mercedes-Benz Center as soon as possible.
	Rear right side marker lamp malfunction	The right rear side marker lamp is malfunctioning. This message will only appear if a critical number of LEDs have stopped working.	► Visit an authorized Mercedes-Benz Center as soon as possible.
	Tail light, left Back-up lamp on	The left tail lamp is malfunctioning. This message will only appear if a critical number of LEDs have stopped working. A backup bulb has been brought into use.	► Visit an authorized Mercedes-Benz Center as soon as possible.
	Tail light, right Back-up lamp on	The right tail lamp is malfunctioning. This message will only appear if a critical number of LEDs have stopped working. A backup bulb has been brought into use.	➤ Visit an authorized Mercedes-Benz Center as soon as possible.

Display symbol	Display message	Possible cause/consequence	Possible solution
☼	Turn off lights	You have forgotten to switch off the headlamps when exiting the vehicle and no SmartKey is in the starter switch.	► Switch off the headlamps.
	Turn signal in mirror, left	The left turn signal in the side mirror is malfunctioning. This message will only appear if a critical number of LEDs have stopped working.	► Visit an authorized Mercedes-Benz Center as soon as possible.
	Turn signal in mirror, right	The right turn signal in the side mirror is malfunctioning. This message will only appear if a critical number of LEDs have stopped working.	► Visit an authorized Mercedes-Benz Center as soon as possible.
	Turn signal, front left	The left front turn signal is malfunctioning.	▶ Replace the bulb as soon as possible.
	Turn signal, front right	The right front turn signal is mal- functioning.	▶ Replace the bulb as soon as possible.
	Rear left turn signal Back-up lamp on	The left rear turn signal is malfunctioning. A backup bulb has been brought into use.	▶ Replace the bulb as soon as possible.
	Rear right turn signal Back-up lamp on	The right rear turn signal is malfunctioning. A backup bulb has been brought into use.	▶ Replace the bulb as soon as possible.

Display symbol	Display message	Possible cause/consequence	Possible solution
茶	Seat belt system Visit workshop	The seat belt system is malfunctioning.	► Visit an authorized Mercedes-Benz Center as soon as possible.
	Function Not available	This display appears if button or on the multifunction steering wheel is pressed and the vehicle is not equipped with a telephone*.	
\Leftrightarrow	Close trunk lid!	This message will appear whenever the trunk lid is open.	► Close the trunk lid.
&	Washer fluid Top up	The fluid level in the windshield washer fluid reservoir has dropped below its minimum mark.	► Add washer fluid (▷ page 315).

Where will I find ...?

First aid kit

The first aid kit is stored in a parcel net behind the driver's seat.

Vehicle tool kit, vehicle jack


The vehicle tool kit is stored in a storage compartment under the trunk floor.

The following is included:

- · Collapsible chock
- · Vehicle jack
- · Protective wrap
- Alignment bolt
- Towing eye bolt
- Wheel wrench
- Spare fuses
- Fuse extractor
- Valve extractor
- Electric air pump
- TIREFIT kit*

Removing the vehicle tool kit

Vehicles with spare wheel



- (1) Spare wheel
- (2) Vehicle tool kit (under collapsible tire, together with wheel bolts for spare wheel with collapsible tire)
- 3) Retaining screw
- Open the trunk (▷ page 98).
- Lift up trunk floor.
- ► Loosen retaining screw ③ by turning it counter-clockwise.
- ▶ Remove spare wheel ①.
- Remove vehicle tool kit 2.



- 1 Collapsible wheel chock
- 2 Vehicle jack
- ③ Protective wrap
- 4 Alignment bolt
- 5 Towing eye bolt
- (6) Wheel wrench
- ③ Spare fuses, fuse extractor and valve extractor
- (8) Electric air pump

Where will I find ...?

Vehicles with TIREFIT*



- 1 TIREFIT kit
- 2 Vehicle jack
- (3) Collapsible wheel chock
- (4) Towing eye bolt
- (5) Alignment bolt
- (6) Wheel wrench
- Spare fuses, fuse extractor and valve extractor
- (8) Electric air pump
- ▶ Open the trunk (> page 98).
- Lift up trunk floor.

Vehicle jack


Warning!



The jack is designed exclusively for jacking up the vehicle at the jack take-up brackets built into both sides of the vehicle. To help avoid personal injury, use the jack only to lift the vehicle during a wheel change. Never get beneath the vehicle while it is supported by the jack. Keep hands and feet away from the area under the lifted vehicle. Always firmly set parking brake and block wheels before raising vehicle with jack.

Do not disengage parking brake while the vehicle is raised. Be certain that the jack is always vertical (plumb line) when in use, especially on hills. Always try to use the jack on level surface. Make sure the jack arm is fully seated in the jack take-up bracket. Always lower the vehicle onto sufficient capacity jackstands before working under the vehicle.


The vehicle jack is located in the storage compartment underneath the trunk floor.



Storage position

- Remove vehicle jack from its compartment.
- ► Turn crank handle in the direction of arrow as far as it will go.

Where will I find ...?



Operational position


Turn crank handle clockwise.

Before storing the vehicle jack in its compartment:

- It should be fully collapsed.
- The handle must be folded in (storage position).

Setting up the collapsible wheel chock

The collapsible wheel chock serves to additionally secure the vehicle, e.g. while changing the wheel.




- (1) Tilt the plate upward
- ② Fold the lower plate outward
- ③ Insert the plate

- Tilt both plates upward (1).
- ► Fold the lower plate outward ②.
- Guide the tabs of the lower plate all the way into the openings of the base plate (3).

Where will I find ...?

Spare wheel with collapsible tire

The spare wheel is stored in the storage compartment underneath the trunk floor.



- Spare wheel, spare wheel bolts (located under plastic cover on the outside of spare wheel rim)
- ② Vehicle tool kit (under collapsible tire)
- 3 Retaining screw
- ► Loosen retaining screw ③ by turning it counterclockwise.
- Remove spare wheel 1.
- ► Take off the wheel bolts for spare wheel ①.

Storing the spare wheel with collapsible tire

If you wish to store the spare wheel after use, carry out the following steps. Otherwise the spare wheel will not fit the storage compartment.

!

Make sure the collapsible tire is dry when storing it.

- Unscrew the valve cap from the valve of the collapsible tire.
- ► Take the valve extractor from the vehicle tool kit (> page 388).
- ► Unscrew the valve insert from the valve and allow the air to escape.



It may take a few minutes for the collapsible tire to deflate completely.

- Screw the valve insert back into the valve.
- ► Screw the valve cap back on the valve.
- ► Pull the protective wrap provided with the vehicle tool kit over the spare wheel.
- ➤ Store the spare wheel and the valve extractor in the storage compartment underneath the trunk floor.
- ► Pierce the protective wrap with retaining screw ③.
- ➤ Secure the spare wheel by turning retaining screw ③ clockwise.

Where will I find ...?

Warning!




The dimensions of the spare wheel with collapsible tire are different from those of the road wheels. As a result, the vehicle handling characteristics change when driving with a spare wheel with collapsible tire mounted.

The spare wheel with collapsible tire should only be used temporarily, and should be replaced with a regular road wheel as quickly as possible. In case of a flat tire, you may temporarily use the spare wheel with collapsible tire when observing the following restrictions:

- Do not exceed a vehicle speed of 50 mph (80 km/h).
- Drive to the nearest tire repair facility to have the flat tire repaired or replaced as appropriate.
- Do not operate vehicle with more than one spare wheel with collapsible tire mounted.

For more information, see "Rims and tires" (▷ page 439).

Spare wheel bolts



- (1) Wheel bolt for light alloy rims
- ② Wheel bolt for spare wheel with collapsible tire (located under plastic cover on the outside of spare wheel rim)

Where will I find...?



Wheel bolts ② must be used when mounting the spare wheel with collapsible tire. The use of any wheel bolts other than wheel bolts ② for the spare wheel with collapsible tire will physically damage the vehicle's brakes.

Warning!



Make sure to use the original length wheel bolts when remounting the original wheel after it has been repaired.

Unlocking/locking in an emergency

Unlocking the vehicle

If you cannot unlock the vehicle with the SmartKey, open the driver's door and the trunk using the mechanical key.



Unlocking and opening the driver's door and/or the trunk with the mechanical key will trigger the anti-theft alarm system.

To cancel the alarm, do one of the following:


- Press button or fonthe smartKey.
- Insert the SmartKey in the starter switch.

Removing the mechanical key



- 1 Mechanical key locking tab
- (2) Mechanical key
- ▶ Move locking tab (1) direction of arrow.
- ► Slide mechanical key ② out of the housing.

Unlocking the driver's door



- 1 Unlocking
- Insert the mechanical key into the driver's door lock until it stops.
- ► Turn the mechanical key counterclockwise to position (1).


The driver's door is unlocked.

Unlocking/locking in an emergency

Unlocking and opening the trunk

A minimum height clearance of 5.78 ft (1.76 m) is required to open the trunk lid.

The trunk lid lock is located next to the handle above the rear license plate recess.



Trunk lid lock

1 Unlocking in an emergency

- ► Fully insert the mechanical key into the trunk lid lock.
- ► Turn the mechanical key counterclockwise to position ① until it stops, and simultaneously
- pull the trunk lid handle and lift lid.

!

Always make sure there is sufficient overhead clearance.

 Turn the mechanical key back and remove it from the trunk lid lock.

Locking the vehicle


If you cannot lock the vehicle with the SmartKey, do the following:

- ► Close the passenger door and the trunk lid.
- Press the central locking switch in the upper part of the center console (> page 102).
- Check to see whether the locking knob on the passenger door has moved down.
- ► If necessary, push it down manually.

 The passenger door is locked.
- Exit the vehicle and close the driver's door.



Unlocking/locking in an emergency



- 1 Locking
- ► Insert the mechanical key into the driver's door lock until it stops.
- ► Turn the mechanical key clockwise to position ①.

The driver's door is locked.

Manually unlocking the gear selector lever (automatic transmission*)

In case of power failure, the gear selector lever can be manually unlocked, e.g. to tow the vehicle.



- (1) Gear selector lever cover
- (2) Release

- Insert flat, blunt object (e.g. screwdriver) into the left edge of cover ① at the position indicated by the arrows.
- ► Loosen cover (1) using this object.
- Using your hands, pull cover ① out and remove.
- Push down and hold release ② in direction of arrow.
- ► Simultaneously move gear selector lever out of position **P**.

The gear selector lever is unlocked now.



The gear selector lever is locked again as soon as you place it in position **P** again.

Opening/closing in an emergency

▼ Opening/closing in an emergency

Raising retractable hardtop manually

Warning!



If the retractable hardtop does not completely open or close, the roof hydraulics will lose pressure and the retractable hardtop is lowered

- after approximately 7 minutes when the ignition is switched on
- after approximately 15 seconds when the ignition is switched off

Shortly before the hardtop is lowered, a warning will sound. In the multifunction display you will see and the message
Retractable roof being opened.

 Properly lock retractable hardtop before continuing to drive (▷ page 252).

Warning!



Manually closing the retractable hardtop is a complicated and technically demanding procedure and should only be performed by an authorized Mercedes-Benz Center or qualified technician. Attempting to manually close the retractable hardtop may cause damage to the retractable hardtop and/or personal injury.

Warning!



To prevent possible accidents, drive the vehicle only with the retractable hardtop either completely closed and locked, or fully lowered into its storage compartment.

Replacing SmartKey batteries

If the batteries in the SmartKey are discharged, the vehicle can no longer be locked or unlocked. It is recommended to have the batteries replaced at an authorized Mercedes-Benz Center.

Warning!



Keep the batteries out of reach of children. If a battery is swallowed, seek medical help immediately. Batteries contain materials that can harm the environment if disposed of improperly. Recycling of batteries is the preferred method of disposal. Many states require sellers of batteries to accept old batteries for recycling.



When inserting the batteries, make sure they are clean and free of lint.

When replacing batteries, always replace both batteries.


The required replacement batteries are available at any Mercedes-Benz Center.

Replacing SmartKey batteries

SmartKey


Replacement batteries: Lithium, type CR 2025 or equivalent.

Remove mechanical key ① (▷ page 394).



- (1) Mechanical key
- (2) Slide
- 3 Battery compartment

- ► Insert mechanical key ① in direction of arrow in side opening.
- ▶ Using mechanical key ①, push gray slide ② to unlatch battery compartment ③.
- ► Pull battery compartment ③ out of the housing in direction of arrow.
- Remove the discharged batteries in direction of arrow.



- 4 Battery
- ⑤ Contact spring

- ► Using a lint-free cloth, insert new batteries ④ under contact spring ⑤ with the positive terminal (+) facing up.
- ► Return battery compartment ② into the housing until it locks into place.
- ► Slide mechanical key ① back into the SmartKey.
- ► Check the operation of the SmartKey.

Replacing bulbs

Safe vehicle operation depends on proper exterior lighting and signaling. It is therefore essential that all bulbs and lamp assemblies are in good working order at all times.

Correct headlamp adjustment is extremely important. Have headlamps checked and readjusted at regular intervals and when a bulb has been replaced. See an authorized Mercedes-Benz Center for headlamp adjustment.




If the headlamps are fogged up on the inside as a result of high humidity, driving the vehicle a short distance with the lights on should clear up the fogging.



Backup bulbs will be brought into use when lamps malfunction. Observe the messages in the multifunction display (> page 382).

Bulbs



Front lamps

		Lamp	Туре
	1	Additional turn signal lamp	LED
	2	Turn signal lamp	PY 21 W
	3	Halogen headlamp: Low beam	H7 (55 W)
		Bi-Xenon* headlamp: Low and high beam ¹	D2S-35W
	4	Front fog lamp	HB4 (51 W)
	5	Parking and standing lamp	W 5 W
	6	Halogen headlamp: High beam/high beam flasher	H7 (55 W)
		Bi-Xenon* headlamp: High beam flasher	H7 (55 W)
	7	Side marker lamp	W 5 W

Vehicles with Bi-Xenon* headlamps: Low beam and high beam use the same D2S-35W lamp. Do not replace the Bi-Xenon* bulbs yourself. See an authorized Mercedes-Benz Center.

Rear lamps

	Lamp	Туре
8	Rear fog lamp (driver's side only)	P 21 W
9	High mounted brake lamp	LED
10	Tail, parking, standing, side marker lamp and brake lamp	LED
11)	License plate lamps	C 5 W
12	Backup lamp	P 21 W
13	Turn signal lamp	PY 21 W



Vehicles equipped with corner-illuminating front fog lamps*: Front fog lamps use H7 (55 W) lamps.

Warning!



Bulbs and bulb sockets can be very hot. Allow the lamp to cool down before changing a bulb.

Keep bulbs out of reach of children.

Halogen lamps contain pressurized gas. A bulb can explode if you:

- touch or move it when hot
- · drop the bulb
- scratch the bulb

Wear eye and hand protection.

Because of high voltage in Xenon lamps, it is dangerous to replace the bulb or repair the lamp and its components. We recommend that you have such work done by a qualified technician.

Notes on bulb replacement

- Only use 12-volt bulbs of the same type and with the specified watt rating.
- Switch lights off before changing a bulb to prevent short circuits.
- Always use a clean lint-free cloth when handling bulbs.
- Your hands should be dry and free of oil and grease.
- If the newly installed bulb does not come on, visit an authorized Mercedes-Benz Center.

Have the LEDs and bulbs for the following lamps replaced by an authorized Mercedes-Benz Center:

- Additional turn signal lamps in the exterior rear view mirrors
- Bi-Xenon* lamps
- Front fog lamps
- High mounted brake lamp
- · Brake lamps
- Front and rear side marker lamps
- Parking/standing lamps in the tail lamp assemblies




Have the headlamp adjustment checked regularly.

Replacing bulbs for front lamps

Before you start to replace a bulb for a front lamp, do the following first:

- Turn the exterior lamp switch to position (> page 110).
- Open the hood (▷ page 307).




- Housing cover for low beam (halogen headlamps only)
 Housing cover for Bi-Xenon* headlamps. Do not remove.
- (2) Bulb socket for turn signal lamp
- 3 Bulb socket for high beam/high beam flasher lamp
- (4) Bulb socket for parking and standing light lamp

Warning!



Do not remove the cover ① for the Bi-Xenon* headlamp. Because of high voltage in Bi-Xenon lamps, it is dangerous to replace the bulb or repair the lamp and its components. We recommend that you have such work done by a qualified technician.



(5) Bulb socket for low beam bulb (Halogen headlamps only)

Replacing bulbs

Low beam bulb (Halogen headlamps only)

- ► Turn housing cover ① counterclockwise and remove.
- ► Turn bulb socket ⑤ with the bulb counterclockwise and remove.
- ▶ Pull the bulb out of bulb socket (5).
- ▶ Press the new bulb into bulb socket (5).
- Place bulb socket (5) back into the lamp and turn it clockwise.
- ▶ Reinstall housing cover (1).

High beam/high beam flasher bulb (Halogen headlamps) / High beam flasher bulb (Bi-Xenon* headlamps)

- ► Turn bulb socket ③ with the bulb counterclockwise and remove.
- ▶ Pull the bulb out of bulb socket ③.
- Press the new bulb into bulb socket (3).
- ► Place bulb socket ③ back into the lamp and turn it clockwise.

Front turn signal bulb

- ► Turn bulb socket ② with the bulb counterclockwise and remove.
- ▶ Press gently onto the bulb and turn it counterclockwise out of bulb socket ②.
- ► Press the new bulb gently into bulb socket (2) and turn it clockwise.
- ► Place bulb socket ② back into the lamp and turn it clockwise.

Parking and standing lamp bulb

- ► Turn bulb socket ④ with the bulb counterclockwise and remove.
- ▶ Pull the bulb out of bulb socket ④.
- Press the new bulb into bulb socket 4.
- ► Place bulb socket ④ back into the lamp and turn it clockwise.

Replacing bulbs for rear lamps

Before you start to replace a bulb for a rear lamp, do the following first:

- ► Turn the exterior lamp switch to position (> page 110).
- ▶ Open the trunk lid (> page 98).


Tail lamp unit



- (1) Bulb socket for rear fog lamp (driver's side only)
- 2 Bulb socket for turn signal lamp
- 3 Bulb socket for backup lamp

- ► Fold corresponding trim to side.
- ► Turn the respective bulb socket counterclockwise and remove.
- Press gently onto the bulb and turn counterclockwise out of its bulb socket.
- ► Press the new bulb gently into its bulb socket and turn clockwise.
- Reinstall the bulb socket and turn clockwise until it engages.
- ▶ Reinstall trim.

License plate lamp



- 1) Screw
- ► Loosen both screws ①.
- ▶ Remove the license plate lamp.
- ▶ Replace the bulb.
- ► Reinstall the license plate lamp.
- Retighten screws ①.

Replacing wiper blades

Removing wiper blades

Warning!




For safety reasons, switch off wipers and remove the SmartKey from the starter switch before replacing a wiper blade. Otherwise, the motor could suddenly turn on and cause injury.



To avoid damage to the hood, the wiper arms should only be folded forward when in the vertical position.


- ► Turn the SmartKey in the starter switch to position 1.
- ► Turn combination switch to wiper setting II (> page 56).
- With wiper arms in vertical position, turn the SmartKey in the starter switch to position 0.
- ► Fold the wiper arms forward until they engage.



- (1) Wiper blade
- (2) Tabs
- (3) Attachment
- 4 Cover
- ► Press tabs ② together and tilt wiper blade ① in direction of arrow.
 - Tabs ② on both recesses of attachment ③ are detached.
- ► Maintaining its tilted position, remove wiper blade (1) out of attachment (3).

Replacing wiper blades

Installing wiper blades



- (1) Cover
- (2) Guide tab
- (3) Attachment
- (4) Tabs

- ► Maintaining a tilted position of the wiper blade, place cover ① onto attachment ③ so that guide tab ② is under cover ①.
- ► Tilt the wiper blade in direction of the arrow towards the wiper arm.
- Simultaneously press tabs (4) together and let the wiper blade engage into both recesses of attachment (3).
- ► Check if the wiper blade is securely fastened.
- ► Fold the wiper arm backward to rest on the windshield.

Make sure you hold on to the wiper arm when folding it back.

!

Never open the hood when the wiper arms are folded forward.

Hold on to the wiper when folding the wiper arm back. If released, the force of the impact from the tensioning spring could crack the windshield.

Do not allow the wiper arms to contact the windshield glass without a wiper blade inserted.

Make sure the wiper blades are properly installed. Improperly installed wiper blades may cause windshield damage.

For your convenience, you should have this work carried out by an authorized Mercedes-Benz Center.

Flat tire

The SLK 55 AMG with Performance Package* is equipped with a TIREFIT kit.

Preparing the vehicle

- ► Park the vehicle as far as possible from moving traffic on a hard surface.
- ► Turn on the hazard warning flashers.
- Turn the steering wheel so that the front wheels are in a straight ahead position.
- Set the parking brake (▷ page 52).
- Move the gear selector lever* to P (manual transmission to first or reverse gear).

- ► Turn off the engine (> page 61).
- Remove the SmartKey from the starter switch.



Open door only when conditions are safe to do so.

Have any passenger exit the vehicle at a safe distance from the roadway.

Sealing tires with TIREFIT



SLK 55 AMG with Performance Package* only.

Warning!



Keep TIREFIT away from sparks, open flame or heat source.

Do not smoke.

Small tire punctures, particularly those in the tread, can be sealed with TIREFIT. TIREFIT can be used in ambient temperatures down to -4°F (-20°C).

Warning!



TIREFIT is a limited repair device. TIREFIT cannot be used for cuts or punctures larger than approx. 0.16 in (4 mm) and tire damage caused by driving with extremely low tire inflation pressure, or on a flat tire, or a damaged wheel.

Do not drive the vehicle under such circumstances.

Contact your nearest Mercedes-Benz Center for assistance or call Roadside Assistance.

- Foreign objects (e.g. screws or nails) should not be removed from the tire.
- ► Take TIREFIT, the sticker, and the electric air pump out of the trunk.
- Attach the sticker where it will be easily seen by the driver on the instrument cluster.

Warning!



Take care not to allow the contents of TIREFIT to come in contact with hair, eyes or clothing. TIREFIT is harmful if inhaled, swallowed or absorbed through the skin - causes skin, eye and respiratory irritation.

Any contact with eyes or skin should be flushed immediately with plenty of water.

If clothing comes in contact with TIREFIT, change clothing as soon as possible.

In case of allergic reaction or rash, consult a physician immediately.

Warning!



Keep TIREFIT out of reach of children. If swallowed, rinse mouth immediately with plenty of water and drink plenty of water.


Do not induce vomiting!

Consult a physician immediately.

Keep away from open flame or heat source.



If sealant has leaked out, let it dry. You can then peel it off.




- (1) TIREFIT container
- (2) Flap
- (3) Notch
- (4) Electrical plug
- 5 Air hose
- 6 Flange
- Open flap ② on the electric air pump.
- ► Pull plug ④ and air hose ⑤ out of the pump housing. ▷▷



Flat tire

- Screw the air pump's air hose ⑤ onto flange ⑥ of the TIREFIT container.
 - Stick TIREFIT container ① upside down into notch ③ of the electric air pump.



- (7) Tire valve
- (8) Electric air pump switch
- (9) Pressure gauge and vent screw
- (10) Filler hose

Warning!



Observe safety instructions on air pump label.

- ► Unscrew the valve cap from tire valve ⑦.
- ▶ Screw filler hose (10) onto tire valve (7).
- ► Close vent screw (9) on air hose (4).
- Insert electrical plug ④ into the power outlet in the passenger footwell (> page 271).

!

The cigarette lighter (\triangleright page 270) is not designed for use with the electric air pump. Use the power outlet in the passenger footwell (\triangleright page 271) for electric air pump operation.

- Turn the SmartKey in the starter switch to position 1 (▷ page 36).
 - Press I on electric air pump switch (8).

 The electric air pump should now switch on and inflate the tire.

!

Do not operate the electric air pump longer than 6 minutes without interruption. Otherwise it may overheat.

You may operate the air pump again after it has cooled off.

After 5 minutes, the pressure gauge must display at least 26 psi (1.8 bar). The air hose can become hot during inflation. Please exercise appropriate caution.

- ▶ If this tire inflation pressure is not attained, turn off the electric air pump, detach the filler hose from the tire valve, and drive vehicle back and forth very slowly approximately 30 ft (10 m).
 - This serves to better distribute the TIREFIT sealant material inside the tire.
- Unscrew the air pump's air hose (5) from flange (6) of the TIREFIT container.
- ► Screw air hose ⑤ onto tire valve ⑦.
- ▶ Inflate the tire again.

Warning!



If a tire inflation pressure of 26 psi (1.8 bar) is not attained, tire is too severely damaged for TIREFIT to provide a reliable tire repair.

In this case, TIREFIT cannot properly seal the tire.

Do not drive the vehicle.

Contact the nearest Mercedes-Benz Center or call Roadside Assistance.

- After attaining a tire inflation pressure of 26 psi (1.8 bar), press 0 on electric air pump switch (8).
 - The electric air pump should now be switched off.
- ► Turn the SmartKey in the ignition to position **0** (▷ page 36).
- Detach the electric air pump.

The air hose may still be hot. Please exercise appropriate caution.

- Store the electrical plug and the air hose behind the flap and place the electrical air pump back in the trunk.
- Close the trunk lid.
- ▶ Drive off immediately.

The TIREFIT sealant will distribute itself evenly inside the tire.

Warning!



Do not exceed vehicle speed of 50 mph (80 km/h). A TIREFIT repair is not designed to operate at higher speeds.

The sticker must be attached on the instrument cluster where it will be easily seen by the driver.

Vehicle handling characteristics may change. Adapt your driving accordingly.

▶ After driving the vehicle for an initial 10 minutes, check the tire inflation pressure using pressure gauge ⑨ on the air pump.

Warning!



If tire inflation pressure has fallen below 20 psi (1.3 bar) do not continue to drive the vehicle.

Park your vehicle safely away from the roadway and contact the nearest authorized Mercedes-Benz Center or Roadside Assistance.

If tire inflation pressure is at least 20 psi (1.3 bar), inflate tire to correct pressure (see placard on the driver's door B-pillar), and drive vehicle to nearest tire repair facility to have tire repaired or replaced.

Recommended duration of use: 300 miles (500 km) at 50 mph (80 km/h) with the recommended tire inflation pressure.



 $\triangleright \triangleright$

Warning!



Follow recommend inflation pressures.

Do not overinflate tires. Overinflating tires can result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes, etc.

Do not underinflate tires. Underinflated tires wear unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overload the tires by exceeding the specified vehicle capacity weight (as indicated by the label on the pillar in the driver's door opening). Overloading the tires can overheat them, possibly causing a blowout.

- Visit an authorized Mercedes-Benz Center as soon as possible to obtain a new TIREFIT kit.
- Bring used TIREFIT materials to an authorized Mercedes-Benz Center for proper disposal.

Warning!



Do not exceed vehicle speed of 50 mph (80 km/h). A TIREFIT repair is not designed to operate at higher speeds.

The sticker must be attached on the instrument cluster where it will be easily seen by the driver.

Vehicle handling characteristics may change. Adapt your driving accordingly.

 Replace your TIREFIT container every 4 years. Replacement containers are available at your authorized Mercedes-Benz Center.

Mounting the spare wheel

Warning!



The dimensions of the spare wheel with collapsible tire are different from those of the road wheels. As a result, the vehicle handling characteristics change when driving with a spare wheel with collapsible tire mounted. Adapt your driving style accordingly.

The spare wheel with collapsible tire is for temporary use only. When driving with spare wheel with collapsible tire mounted, ensure proper tire inflation pressure and do not exceed vehicle speed of 50 mph (80 km/h).

Drive to the nearest Mercedes-Benz Center as soon as possible to have the spare wheel with collapsible tire replaced with a regular road wheel.

Never operate the vehicle with more than one spare wheel with collapsible tire mounted.

Do not switch off the ESP[®] when a spare wheel with collapsible tire is mounted.

Preparing the vehicle

Prepare the vehicle as described (\triangleright page 408).

► Take the collapsible tire, wheel wrench, wheel bolts, jack, and electric air pump out of the trunk (▷ page 388).

Lifting the vehicle

Prevent the vehicle from rolling away by blocking wheels with wheel chocks (not included) or other sizeable objects.

One wheel chock is included with the vehicle tool kit (\triangleright page 388).

When changing wheel on a level surface:

Place the wheel chock in front of and another sizeable object behind the wheel that is diagonally opposite to the wheel being changed.

Always try lifting the vehicle using the jack on a level surface. However, should circumstances require you to do so on a hill, place the wheel chock and the other sizeable object as follows:


Place the wheel chock and another sizeable object on the downhill side blocking both wheels of the axle not being worked on.

Warning!




The jack is designed exclusively for jacking up the vehicle at the jack take-up brackets built into either side of the vehicle. To help avoid personal injury, use the jack only to lift the vehicle during a wheel change. Never get beneath the vehicle while it is supported by the jack. Keep hands and feet away from the area under the lifted vehicle. Always firmly set parking brake and block wheels before raising vehicle with jack.

Do not disengage parking brake while the vehicle is raised. Be certain that the jack is always vertical (plumb line) when in use, especially on hills. Always try to use the jack on level surface. Be sure the jack arm is fully seated in the jack take-up bracket. Always lower the vehicle onto sufficient capacity jackstands before working under the vehicle.



- (1) Wheel wrench
- On wheel to be changed, loosen but do not yet remove the wheel bolts in direction of arrow (approximately one full turn with wheel wrench 1).

The jack take-up brackets are located directly behind the front wheel housings and in front of the rear wheel housings.




- (2) Jack
- 3 Take-up bracket
- ▶ Place jack ② on firm ground.
- Position jack ② under take-up bracket ③ so that it is always vertical (plumb-line) as seen from the side, even if the vehicle is parked on an incline.

Warning!



Position the jack only on the jack take-up brackets designed for this purpose. If the jack is not properly positioned, the vehicle may fall off of the jack.



Jack up the vehicle until the wheel is a maximum of 1.2 in (3 cm) from the ground. Never start engine while vehicle is raised.

Warning!



The jack is intended only for lifting the vehicle briefly for wheel changes. It is not suited for performing maintenance work under the vehicle.

- Never start the engine when the vehicle is raised.
- Never lie down under the raised vehicle.

Removing the wheel




- 4 Alignment bolt
- Unscrew the upper-most wheel bolt and remove.
- ► Replace this wheel bolt with alignment bolt (4) supplied in the vehicle tool kit.
- ▶ Remove the remaining bolts.

!

Do not place wheel bolts in sand or dirt. This could result in damage to the bolt and wheel hub threads.

Remove the wheel.

Mounting the spare wheel



- 1 Wheel bolt for light alloy rims
- ② Wheel bolt for spare wheel with collapsible tire (located under plastic cover on the outside of spare wheel rim)

Flat tire



Wheel bolts ② must be used when mounting the spare wheel with collapsible tire. The use of any wheel bolts other than wheel bolts ② for the spare wheel with collapsible tire will physically damage the vehicle's brakes.

 Clean contact surfaces of wheel and wheel hub.



To avoid paint damage, place wheel flat against hub and hold it there while installing first wheel bolt.

Warning!



Always replace wheel bolts that are damaged or rusted.

Never apply oil or grease to wheel bolts.

Damaged wheel hub threads should be repaired immediately. Do not continue to drive under these circumstances! Contact an authorized Mercedes-Benz Center or call Roadside Assistance.

Incorrect wheel bolts or improperly tightened wheel bolts can cause the wheel to come off. This could cause an accident. Be sure to use the correct wheel bolts.



- Guide the spare wheel onto the alignment bolt and push it on.
- ► Insert the wheel bolts and tighten them slightly.

Warning!



Use only genuine equipment Mercedes-Benz wheel bolts. Other wheel bolts may come loose.

Do not tighten the wheel bolts when the vehicle is raised. Otherwise the vehicle could fall off the jack.

- Unscrew the alignment bolt, install last wheel bolt and tighten slightly.
- Inflate the collapsible tire (▷ page 417).

Inflating the collapsible tire

Warning!



Inflate collapsible tire only after the wheel is properly mounted.

Inflate the collapsible tire using the electric pump (▷ page 388) <u>before</u> lowering the vehicle.


Warning!



Observe instructions on air pump label.

!

Do not lower the vehicle before inflating the collapsible tire. Otherwise the rim may be damaged.



- 1 Flap
- 2 Air pump switch
- (3) Electrical plug
- (4) Air hose with pressure gauge and vent screw
- (5) Union nut

Flat tire

- ► Take the electric air pump out of the trunk (> page 388).
- Open flap 1 on air pump.
- ▶ Pull out electrical plug ③ and air hose with pressure gauge ④.
- ► Close vent screw on air hose (4).
- Remove the valve cap from the tire valve.
- ► Screw air hose ④ with union nut ⑤ onto the collapsible tire valve.
- ► Make sure electric air pump switch ② is set to **0**.
- Insert electrical plug ③ into the power outlet in the passenger footwell (▷ page 271).

!

The cigarette lighter (\triangleright page 270) is not designed for use with the electric air pump. Use the power outlet in the passenger footwell (\triangleright page 271) for electric air pump operation.

- ► Turn the SmartKey in the starter switch to position 1.
- Press I on electric air pump switch ②.
 The electric air pump switches on and inflates the collapsible tire.
- ► Inflate the collapsible tire to approximately 51 psi (3.5 bar).

This takes about 5 minutes for the collapsible tire. Air hose 4 and union nut 5 can become hot during inflation. Exercise proper caution to avoid burning yourself when using the equipment.

!

Do not operate the electric air pump longer than 6 minutes without interruption. Otherwise it may overheat.

You may operate the electric air pump again after it has cooled off.

Press 0 on electric air pump switch (2).

- Turn the SmartKey in the starter switch to position **0**.
 - The electric air pump should now be switched off.
- ▶ If the tire inflation pressure is above 51 psi (3.5 bar), release excess tire inflation pressure using the vent screw on air hose (4).

Warning!



Follow recommended tire inflation pressures.

Do not underinflate tires. Underinflated tires wear excessively and / or unevenly, adversely affect handling and fuel economy, and are more likely to fail from being overheated.

Do not overinflate tires. Overinflated tires can adversely affect handling and ride comfort, wear unevenly, increase stopping distance, and result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.

- ▶ Detach the electric air pump.
- ▶ Reinstall collapsible tire valve cap.
- ► Store electrical plug ③ and air hose ④ behind flap ① and place the electric air pump back in the trunk.
- ► Lower the vehicle (> page 419).


Lowering the vehicle

Warning!




Inflate the collapsible tire using the electric pump (> page 417) before lowering the vehicle.

- ► Lower vehicle by turning the crank counterclockwise until vehicle is resting fully on its own weight.
- ► Remove the jack.



1 - 5 Wheel bolts



► Tighten the five wheel bolts evenly in the direction of the arrow, following the diagonal sequence illustrated (1) to (5), until all bolts are tight. Observe a tightening torque of 80 lb-ft (110 Nm).

 $\triangleright \triangleright$

Flat tire

 $\triangleright \triangleright$

Warning!



Have the tightening torque checked after changing a wheel. The wheels could come loose if they are not tightened to a torque of 80 lb-ft (110 Nm).

- ► Fully collapse the jack.
- ▶ Place the vehicle tool kit, electric air pump, and the jack back in the storage compartment underneath the trunk floor.
- Wrap the damaged wheel in the protective sheet provided with the spare wheel and put the wheel in the trunk.



The flat tire may be transported in the trunk when the retractable hardtop is closed.

Battery

▼ Battery

The battery is located in the engine compartment on the right-hand side below the windshield washer fluid reservoir.



- 1 Battery
- (2) Positive terminal
- 3 Negative terminal

Warning!



Failure to follow these instructions can result in severe injury or death.

Observe all safety instructions and precautions when handling automotive batteries, see "Battery" (> page 314).

Never lean over batteries while connecting them, as you could otherwise be injured.

Battery fluid contains sulfuric acid. Do not allow this fluid to come into contact with eyes, skin or clothing. In case it does, immediately flush affected area with water and seek medical help if necessary.

A battery will also produce hydrogen gas, which is flammable and explosive. Keep flames or sparks away from battery, avoid improper connection of jumper cables, smoking, etc.

Warning!



Do not place metal objects on the battery as this could result in a short circuit.

Use leak-proof batteries only to avoid the risk of acid burns in the event of an accident.



Never loosen or detach battery terminal clamps while the engine is running or the SmartKey is in the starter switch. Otherwise the alternator and other electronic components could be severely damaged.

Have the battery checked regularly by an authorized Mercedes-Benz Center.

Refer to Maintenance Booklet for maintenance intervals or contact an authorized Mercedes-Benz Center for further information.

Battery


Disconnecting the battery

Warning!



With a disconnected battery

- you will no longer be able to turn the SmartKey in the starter switch
- automatic transmission*: the gear selector lever will remain locked in position P



- 1) Water tray
- 2 Lock

- Pull up parking brake lever firmly and move gear selector lever* to position P (manual transmission to Neutral).
- Switch off all electrical consumers.
- ► Remove SmartKey from starter switch.
- ▶ Open the hood (> page 307).
- ► Turn locks ② one quarter turn.
- Remove water tray ①.
- Read and observe safety instructions and precautions (▷ page 421).
- Use a 10 mm open-end wrench to disconnect the negative lead from battery negative terminal ③ (▷ page 421).
- Remove the cover from the positive terminal.
- Use a 10 mm open-end wrench to disconnect the positive lead from battery positive terminal ② (> page 421).

Removing the battery

- Remove the screw on the swivel bar.
- Remove the swivel bar.
- Pull out the battery ventilation tube from the battery (depending on battery arrangement in your vehicle model, the ventilation tube is located either on the left or right side of the battery).
- Take out the battery.

Battery

Charging and reinstalling battery

Warning!



Never charge a battery while still installed in the vehicle unless the accessory battery charge unit approved by Mercedes-Benz is being used. Gases may escape during charging and cause explosions that may result in paint damage, corrosion or personal injury.

An accessory battery charge unit specially adapted for Mercedes-Benz vehicles and tested and approved by Mercedes-Benz is available, permitting the charging of the battery in its installed position. Contact an authorized Mercedes-Benz Center for information and availability. Charge battery in accordance with the separate instructions for the accessory battery charger.

- ► Charge battery in accordance with the instructions of the battery charger manufacturer.
- Reinstall the charged battery. Follow the previously described steps in reverse order.



The battery, its filler caps and the vent tube must always be securely installed when the vehicle is in operation.

Reconnecting the battery

- Turn off all electrical consumers.
- Connect the positive lead and fasten its cover.
- Connect the negative lead.



Never invert the terminal connections!

► Reinstall the water tray.



The following procedures must be carried out following any interruption of battery power (e.g. due to reconnection):

- Set the clock (▷ page 139).
- Synchronize the power windows (> page 251).

Batteries contain materials that can harm the environment if disposed of improperly. Large 12-volt storage batteries contain lead. Recycling of batteries is the preferred method of disposal. Many states require sellers of batteries to accept old batteries for recycling.

Jump starting

Warning!



Failure to follow these directions will cause damage to the electronic components, and can lead to a battery explosion and severe injury or death.

Never lean over batteries while connecting or jump starting, as you could otherwise be injured.

Battery fluid contains sulfuric acid. Do not allow this fluid to come in contact with eyes, skin or clothing. In case it does, immediately flush affected area with water, and seek medical help if necessary.

A battery will also produce hydrogen gas, which is flammable and very explosive. Keep flames or sparks away from battery, avoid improper connection of jumper cables, smoking, etc.

Attempting to jump start a frozen battery can result in it exploding, causing personal injury.

Read all instructions before proceeding.

If the battery is discharged, the engine can be started with jumper cables and the battery of another vehicle. Observe the following:

- Jump starting should only be performed when the engine and catalytic converter are cold.
- Do not start the engine if the battery is frozen. Let the battery thaw out first.
- Only jump start from batteries with the same voltage rating (12V). Jump starting with a more powerful battery could damage the vehicle's electrical system, which will not be covered by the Mercedes-Benz Limited Warranty.
- Only use jumper cables with sufficient cross-section and insulated terminal clamps.
- Always make sure the jumper cables are not on or near pulleys, fans, or other parts that move when an engine is started or running.

!

Avoid repeated and lengthy starting attempts.

Do not attempt to start the engine using a battery quick charge unit.

If the engine does not run after several unsuccessful starting attempts, have it checked at the nearest authorized Mercedes-Benz Center.

Excessive unburned fuel generated by repeated failed starting attempts may damage the catalytic converter and may present a fire risk.

Make sure the jumper cables do not have loose or missing insulation.

Make sure the cable clamps do not touch any other metal part while the other end is still attached to a battery.

Jump starting


Warning!



Keep flames or sparks away from battery. Do not smoke.

Observe all safety instructions and precautions when handling automotive batteries (> page 314).

- Make sure the two vehicles do not touch.
- ► Turn off all electrical consumers.
- Apply parking brake.
- Shift gear selector lever* to position P (manual transmission to Neutral).
- ▶ Open the hood (▷ page 307).
- Flip up cover from positive under hood terminal ② in front of water tray ① (▷ page 422).



- 1) Positive terminal of charged battery
- 2 Positive under hood terminal in front of water tray
- ③ Negative under hood terminal in front of water tray
- 4 Negative terminal of charged battery
- ► Connect positive terminal ① of the charged battery with positive under hood terminal ② in front of the water tray with one jumper cable. Clamp the cable to positive terminal ① of the charged battery first.
 - !

Never invert the terminal connections.

- Start the engine of the vehicle with the charged battery and run at idle speed.
- ► Connect negative terminal ④ of the charged battery with negative under hood terminal ③ in front of the water tray with the second jumper cable. Clamp the cable to negative terminal ④ of the charged battery first.
- ► Start the engine of the disabled vehicle.

You can now turn on the electrical consumers. Do not turn on the lights under any circumstances.

▶ Remove the jumper cables first from negative terminals ③ and ④ and then from positive terminals ② and ①.

You can now turn on the lights.

Have the battery checked at the nearest authorized Mercedes-Benz Center.



Vehicles with automatic transmission*: Do not tow-start vehicle.

Towing the vehicle

Mercedes-Benz recommends that the vehicle be transported with all wheels off the ground using flatbed or appropriate wheel lift/dolly equipment.

!

Vehicles with automatic transmission*: Do not tow-start vehicle.

!

Use flatbed or wheel lift/dolly equipment with the SmartKey in the starter switch in position **0**.

Do not tow with sling-type equipment. Towing with sling-type equipment over bumpy roads will damage radiator and supports.

To prevent damage during transport, do not tie down vehicle by its chassis or suspension parts.

Switch off the tow-away alarm (> page 88) and the automatic central locking (> page 101).

When circumstances do not permit the recommended towing methods, the vehicle may be towed with all wheels on the ground or front wheels raised only so far as necessary to have the vehicle moved to a safe location where the recommended towing methods can be employed.

!

To be certain to avoid a possibility of damage to the transmission, however, we recommend the drive shaft be disconnected at the rear axle drive flange for any towing beyond a short tow to a nearby garage.

!

If the vehicle is towed with the front axle raised, the engine must be shut off (SmartKey in starter switch position **0** or **1**). Otherwise, the ESP® will immediately be engaged and will apply the rear wheel brakes.

When towing the vehicle with all wheels on the ground, the gear selector lever* must be in position **N** (manual transmission: gear shift lever in neutral position) and the SmartKey must be in starter switch position **1**.

When towing the vehicle with all wheels on the ground or the front axle raised, the vehicle may be towed only for distances up to 30 miles (50 km) and at a speed not to exceed 30 mph (50 km/h).

Towing the vehicle

Warning!



If circumstances require towing the vehicle with all wheels on the ground, always tow with a tow bar if:

- the engine will not run
- there is a malfunction in the power supply or in the vehicle's electrical system

as that will be necessary to adequately control the towed vehicle.

Prior to towing the vehicle with all wheels on the ground, make sure the SmartKey is in starter switch position **2**.

If the SmartKey is left in starter switch position **0** for an extended period of time, it can no longer be turned in the switch. In this case, the steering is locked. To unlock, remove SmartKey from starter switch and reinsert.

Warning!



With the engine not running, there is no power assistance for the brake and steering systems. In this case, it is important to keep in mind that a considerably higher degree of effort is necessary to brake and steer the vehicle. Adapt your driving accordingly.



To signal turns while being towed with the hazard warning flasher in use, switch on ignition and activate the combination switch for the left or right turn signal in the usual manner – only the selected turn signal will operate.

Upon canceling the turn signal, the hazard warning flasher will operate again.



When towing the vehicle with all wheels on the ground, please note the following:

With the automatic central locking activated and the SmartKey in starter switch position **2**, the vehicle doors lock if the left front wheel as well as the right rear wheel are turning at vehicle speeds of approx. 9 mph (15 km/h) or more.

To prevent the vehicle door locks from locking, deactivate the automatic central locking (▷ page 101).

Switch off the tow-away alarm (\triangleright page 88).

The vehicle should only be towed using a properly installed towing eye bolt. Never attach a tow cable, tow rope or tow rod to the vehicle chassis, frame or suspension parts.

Towing the vehicle



The gear selector lever* will remain locked in position **P** (vehicles with automatic transmission*) and the SmartKey will not turn in the starter switch if the battery is disconnected or discharged. See notes on the battery (▷ page 421) or on jump starting (▷ page 424).

Vehicles with automatic transmission*: For information on manual unlocking of gear selector lever, see (> page 396).


Installing towing eye bolt

The towing eye bolt is supplied with the vehicle tool kit, located in the compartment underneath the trunk floor (> page 388).

The towing eyes are located on the passenger side in the front and rear bumper.

► Take vehicle tool kit out of trunk (> page 388).

Front cover



1) Cover in front bumper

Removing

- Press mark on cover (1).
- Cover ① springs open at the top right corner.
- ▶ Pull at the protruding part of cover ① and fold cover down to reveal the threaded hole for the towing eye bolt.
 - Do not disconnect cover ① from its check strap.
- Screw towing eye bolt in to its end stop and tighten with lug wrench.

Installing


- ► Unscrew the towing eye bolt using the lug wrench.
- ► To reinstall cover ①, tilt the marked lower left corner towards the opening.
- Maintaining its tilted position, insert cover 1 by applying the latches at the top left and lower right corner into the opening.
- ► To close cover ①, press on the diagonal opposite side of the marked corner until it fully engages.



Make sure the cover's check strap does not get caught when closing.

Towing the vehicle

Rear cover



(1) Cover in rear bumper

Removing

- Press mark on cover (1).
- ► Cover ① springs open at the top.
- Pull at the protruding part of cover ① and fold cover down to reveal the threaded hole for the towing eye bolt.
 Do not disconnect cover ① from its check strap.
- Screw towing eye bolt in to its end stop and tighten with lug wrench.

Installing

- Unscrew the towing eye bolt using the lug wrench.
- ► To reinstall cover ①, tilt the marked lower edge towards the opening.
- Maintaining its tilted position, insert cover ① by applying the latches at the marked lower edge into the opening.
- ► To close cover ①, press on the unmarked top until it fully engages.



Make sure the cover's check strap does not get caught when closing.

Fuses

Fuses are designed to protect the electrical circuits in your vehicle from a short circuit. If a fuse is blown, the component(s) and systems secured by that fuse will stop working.

The following aids are available to help you replace fuses:

- · Fuse chart
- Spare fuses
- Fuse extractor

Warning!



Only use fuses approved by Mercedes-Benz with the specified amperage for the system in question. Using other fuses may cause an overload and leading to a fire, and/or cause damage to electrical components and/or systems.

!

Never attempt to repair or bridge a blown fuse. Have the cause determined and remedied by an authorized Mercedes-Benz Center.

!

Keep the fuse boxes free by contamination and wetness. Otherwise, electrical parts or systems could be damaged.

The electrical fuses are located in different fuse boxes:

- Main fuse box in passenger compartment (> page 431).
- Fuse box in engine compartment (▷ page 432).

Aids for replacing fuses

Fuse chart

The fuse chart is located in the main fuse box in the passenger compartment (▷ page 431). The amperages of the fuses are also given there.


Spare fuses

Spare fuses are located in the vehicle tool kit in the spare wheel well (▷ page 388).

Fuse extractor

The fuse extractor is located in the vehicle tool kit in the spare wheel well (> page 388).

Main fuse box in passenger compartment



(1) Main fuse box cover



Do not use sharp objects such as a screw driver to open the fuse box cover ① in the dashboard, as this could damage it.

Opening

- ► Open the driver's door.
- ► Insert flat, blunt object as a lever into recess on the edge of cover ① at the position indicated by the arrow.
- ► Loosen cover ① from dashboard using the lever.
- ► Using your hands, pull cover ① out and remove.

Closing


- ► Attach cover (1) in the front.
- ► Fold cover (1) in until it engages.

Practical hints

Fuses

Fuse box in engine compartment

The fuse box is located in the engine compartment on the driver's side.



- 1) Fuse box
- 2 Clamp
- (3) Fuse box cover

Opening

- ▶ Open the hood (> page 307).
- ► With a dry cloth, remove any moisture from the fuse box.
- ▶ Release clamps ②.
- ▶ Remove fuse box cover ③.

Closing

- ► Make sure the sealing rubber is properly positioned.
- ▶ Press fuse box cover ③ down and secure with clamps ②.

Parts service
Warranty coverage
Identification labels
Layout of poly-V-belt drive
Engine
Rims and tires
Electrical system
Main Dimensions
Weights

Fuels, coolants, lubricants, etc.



Parts service

The "Technical data" section provides the necessary technical data for your vehicle.

All authorized Mercedes-Benz Centers maintain a stock of genuine Mercedes-Benz parts required for maintenance and repair work. In addition, strategically located parts distribution centers provide quick and reliable parts service.

More than 300 000 different parts for Mercedes-Benz models are available.

Genuine Mercedes-Benz parts are subjected to stringent quality inspections. Each part has been specifically developed, manufactured or selected for and adapted to Mercedes-Benz vehicles.

Therefore, genuine Mercedes-Benz parts should be installed.



The use of non-genuine Mercedes-Benz parts and accessories not authorized by Mercedes-Benz could damage the vehicle, which is not covered by the Mercedes-Benz Limited Warranty, or could compromise the vehicle's durability or safety.

Warranty coverage

▼ Warranty coverage

Your vehicle is covered under the terms of the warranties printed in the Service and Warranty Information booklet. Your authorized Mercedes-Benz Center will exchange or repair any defective parts originally installed in the vehicle in accordance with the terms of the following warranties:

- New Vehicle Limited Warranty
- Emission System Warranty
- Emission Performance Warranty
- California, Maine, Massachusetts, and Vermont Emission Control Systems Warranty

Replacement parts and accessories are covered by the Mercedes-Benz Parts and Accessories warranties, copies of which are available at any authorized Mercedes-Benz Center.

Loss of Service and Warranty Information Booklet

Should you lose your Service and Warranty Information booklet, have an authorized Mercedes-Benz Center arrange for a replacement. It will be mailed to you.


Identification labels



(1) Certification label (includes paintwork code)



② Vehicle Identification Number (VIN), located behind the passenger seat under the floor cover



- (3) Engine number (engraved on engine)
- (4) VIN, visible (lower edge of windshield)
- (5) Vacuum line routing diagram label
- 6 Emission control information label, includes both federal and California certification exhaust emission standards




When ordering parts, please specify vehicle identification and engine numbers.

Layout of poly-V-belt drive


▼ Layout of poly-V-belt drive

SLK 280, SLK 350



- 1 Idler pulley
- ② Idler pulley
- 3 Automatic belt tensioner
- 4 Power steering pump
- (5) Air conditioning compressor
- (6) Crankshaft
- Occional pump
- (8) Generator (alternator)

SLK 55 AMG



- (1) Automatic belt tensioner
- (2) Power steering pump
- (3) Air conditioning compressor
- (4) Crankshaft
- (5) Coolant pump
- 6 Generator (alternator)
- 7 Idler pulley

Engine

Model	SLK 280 (171.454) ¹	SLK 350 (171.456) ¹	SLK 55 AMG (171.473) ¹
Engine	272	272	113
Mode of operation	4-stroke engine, gasoline injection	4-stroke engine, gasoline injection	4-stroke engine, gasoline injection
No. of cylinders	6	6	8
Bore	3.47 in (88.00 mm)	3.66 in (92.90 mm)	3.82 in (97.00 mm)
Stroke	3.24 in (82.20 mm)	3.39 in (86.00 mm)	3.60 in (92.00 mm)
Total piston displacement	182.8 cu in (2996 cm ³)	213.5 cu in (3498 cm ³)	331.8 cu in (5439 cm ³)
Compression ratio	11.3:1	10.7:1	11:1
Output according to SAE J 1349	228 hp / 6 000 rpm ² (170 kW / 6 000 rpm)	268 hp/6000 rpm ² (200 kW/6000 rpm)	355 hp / 5750 rpm ² (265 kW / 5750 rpm)
Maximum torque according to SAE J 1349	221 lb-ft / 2700 - 5000 rpm (300 Nm / 2700 - 5000 rpm)	258 lb-ft / 2400 - 5000 rpm (350 Nm / 2400 - 5000 rpm)	376 lb-ft / 4000 rpm (510 Nm / 4000 rpm)
Maximum engine speed	6500 rpm	6 500 rpm	6700 rpm
Firing order	1-4-3-6-2-5	1-4-3-6-2-5	1-5-4-2-6-3-7-8
Poly-V-belt	2404 mm	2404 mm	2380 mm

The quoted data apply only to the standard vehicle. See an authorized Mercedes-Benz Center for the corresponding data of all special bodies and special equipment.
 Premium fuel required. Performance may vary with fuel octane rating.

Rims and tires

▼ Rims and tires



Only use tires which have been tested and approved for your vehicle by Mercedes-Benz. Tires approved by Mercedes-Benz are developed to provide best possible performance in conjunction with the driving safety systems on your vehicle such as ABS or ESP®. Tires specially developed for your vehicle and tested and approved by Mercedes-Benz can be identified by finding the following on the tire's sidewall:

- MO = Mercedes-Benz Original equipment tires
- MOE = Mercedes-Benz Original <u>Extended</u> (tires with limited run-flat characteristics) original equipment tires

Using tires other than those approved by Mercedes-Benz may result in damage that is not covered by the Mercedes-Benz Limited Warranty.



For information on driving with MO*Extended* tires, see "MO*Extended* system*" (▷ page 333).

!

Using tires other than those approved by Mercedes-Benz can have detrimental effects, such as

- poor handling characteristics
- · increased noise
- increased fuel consumption

Moreover, tires and rims not approved by Mercedes-Benz may, under load, exhibit dimensional variations and different tire deformation characteristics that could cause them to come into contact with the vehicle body or axle parts. Damage to the tires or the vehicle may be the result.



Further information on tires and rims is available at any authorized Mercedes-Benz Center. A placard with the recommended tire inflation pressures is located on the driver's door B-pillar. Some vehicles may have supplemental tire inflation pressure information for driving at high speeds (▷ page 328) or for vehicle loads less than the maximum loaded vehicle condition (⊳ page 328). If such information is provided, it can be found on the placard located on the inside of the fuel filler flap. The tire inflation pressure should be checked regularly and should only be adjusted on cold tires. Follow tire manufacturer's maintenance recommendation included with vehicle.

Rims and tires



The following pages also list the approved wheel rim and tire sizes for equipping your vehicles with winter tires. Winter tires are not available as standard or optional factory equipment, but can be purchased from an authorized Mercedes-Benz Center.

Depending on vehicle model and the standard or optional factory-equipped wheel rim/tire configuration on your vehicle (Sport Package etc.), equipping your vehicle with winter tires approved for your vehicle model may also require the purchase of two or four wheel rims of the recommended size for use with these winter tires. See an authorized Mercedes-Benz Center for more information.

Rims and tires

Same size tires

Model	SLK 280	SLK 280 SLK 350
Summer tires ¹	-	-
Rims (light alloy)	-	-
Wheel offset	-	-

Winter tires 1,2	205/55 R16 91H M+S 🛕	225/45 R17 91H M+S 🛕
Rims (light alloy)	7 J x 16 H2	7.5 J x 17 H2
Wheel offset	1.34 in (34 mm)	1.42 in (36 mm)

Winter tires* 1,2,3	225/45 R17 91H M+S 🛕 MOExtended
Rims (light alloy)	7.5 J x 17 H2
Wheel offset	1.42 in (36 mm)

¹ Radial-ply tires

Not available as factory equipment.
 Must be used in conjunction with Run Flat Indicator* only.

Rims and tires

Model	SLK 280 (Sport Package*) SLK 350 (Sport Package*) SLK 55 AMG	SLK 55 AMG (Performance Package*)
Summer tires ¹	-	-
Rims (light alloy)	-	-
Wheel offset	-	-

Winter tires 1,2,3	205/50 R17 89H M+S or 225/45 R17 91H M+S	225/40 R18 92H XL (Extra Load) M+S 🛕
Rims (light alloy)	7.5 J x 17 H2	7.5 J x 18 H2
Wheel offset	1.46 in (37 mm)	1.46 in (37 mm)

Radial-ply tires
Not available as factory equipment.
For use with snow chains contact an authorized Mercedes-Benz Center.

Rims and tires

Mixed size tires

	SLK 280	SLK 280* SLK 350
Front axle:		
Rims (light alloy)	7 J x 16 H2	7.5 J x 17 H2
Wheel offset	1.34 in (34 mm)	1.42 in (36 mm)
Summer tires ¹	205/55 R16 91W	225/45 R17 91W or 225/45 R17 91W MO <i>Extended</i> ²
Rear axle:		
Rims (light alloy)	8 J x16 H2	8.5 J x17 H2
Wheel offset	1.18 in (30 mm)	1.18 in (30 mm)
Summer tires 1,3	225/50 R16 92W	245/40 R17 91W or 245/40 R17 91W MO <i>Extended</i> ²

 $^{^1}$ Radial-ply tires 2 Must be used in conjunction with Run Flat Indicator $\!\!\!\!\!^\star$ only.

³ Must not be used with snow chains.

Rims and tires

	SLK 280 (Sport Package*) SLK 350 (Sport Package*)	SLK 55 AMG (Performance Package*)
Front axle:		
Rims (light alloy)	7.5 J x 17 H2	7.5 J x 18 H2
Wheel offset	1.46 in (37 mm)	1.46 in (37 mm)
Summer tires ^{1,3}	225/45 R17 91W or 225/45 R17 91W MO <i>Extended</i> ²	225/40 ZR18 92Y XL (Extra Load)
Rear axle:		
Rims (light alloy)	8.5 J x17 H2	8.5 J x18 H2
Wheel offset	1.18 in (30 mm)	1.18 in (30 mm)
Summer tires ^{1,3}	245/40 R17 91W or 245/40 R17 91W MO <i>Extended</i> ²	245/35 ZR18 92Y XL (Extra Load)

Radial-ply tires

Must be used in conjunction with Run Flat Indicator* only.

Must not be used with snow chains.

Spare wheel with collapsible tire

	All models
Rim (light alloy)	4.5 B x 17 H2
Wheel offset	0.47 in (12 mm)
Collapsible tire	145/70-17 92P ¹

Must not be used with snow chains.



Please compare the recommended tire inflation pressure for your vehicle with the tire inflation pressure on the yellow label located on the spare wheel rim.

If the tire inflation pressure on the yellow label on the spare wheel rim differs from the values given in this Operator's Manual, inflate the collapsible tire to the recommended tire inflation pressure given on the yellow label on the spare wheel rim.



Please note that the tire inflation pressure of the collapsible tire differs from the tire inflation pressure of the road tires.

Inflate the collapsible tire to approximately 51 psi (3.5 bar).



The SLK 55 AMG with Performance Package* does not have a spare wheel. The SLK 55 AMG with Performance Package* is equipped with TIREFIT (⊳ page 408).

Electrical system

Model	SLK 280	SLK 350	SLK 55 AMG
Generator (alternator)	14 V/150 A	14 V/150 A	14 V/150 A
Starter motor	12 V/1.4 kW	12 V/1.7 kW	12 V/1.7 kW
Battery	12 V/62 Ah	12 V/74 Ah	12 V/74 Ah
Spark plugs	NGK PLKR 6A	Bosch Platin Y 7 MPP33 NGK PLKR 6A	NGK IFR6D10
Electrode gap	0.031 in (0.8 mm)	0.031 in (0.8 mm)	0.039 in (1.0 mm)
Tightening torque	15 - 22 lb-ft (20 - 30 Nm)	15 - 22 lb-ft (20 - 30 Nm)	18 - 22 lb-ft (25 - 30 Nm)

Main Dimensions

▼ Main Dimensions

Model	SLK 280	SLK 350	SLK 55 AMG
Overall vehicle length	160.7 in (4082 mm)	160.7 in (4082 mm)	160.9 in (4087 mm)
Overall vehicle width	70.4 in (1788 mm)	70.4 in (1788 mm)	70.6 in (1794 mm)
Overall vehicle height	51.0 in (1296 mm)	51.1 in (1298 mm)	50.0 in (1271 mm)
Wheelbase	95.7 in (2430 mm)	95.7 in (2430 mm)	95.7 in (2430 mm)
Track, front	60.2 in (1530 mm)	60.1 in (1526 mm)	60.0 in (1524 mm)
Track, rear	61.0 in (1549 mm)	61.0 in (1549 mm)	61.0 in (1549 mm)

Weights

Model	SLK 280 SLK 350	SLK 55 AMG
Maximum roof load	110 lb (50 kg)	110 lb (50 kg)
Maximum trunk load	220 lb (100 kg)	220 lb (100 kg)



This vehicle is not designed to carry items on its roof. Roof rails and any roof-mounted devices, unless expressly approved by Mercedes-Benz for use on this vehicle model, must not be used as they will damage the vehicle and retractable hardtop.

At time of printing, Mercedes-Benz does not offer any roof racks or any other roof-mounted devices for use on this vehicle.



This vehicle is not designed to carry any items on its trunk lid or accommodate any type of trunk lid rack or device. Using such devices may damage the vehicle and retractable hardtop mechanism.

Fuels, coolants, lubricants, etc.

▼ Fuels, coolants, lubricants, etc.

Capacities

Vehicle components and their respective lubricants must match. Therefore, only use products tested and approved by Mercedes-Benz.

Please refer to the Factory Approved Service Products pamphlet, or inquire at your authorized Mercedes-Benz Center.

	Model	Capacity	Fuels, coolants, lubricants etc.
Engine with oil filter	SLK 280, SLK 350	8.5 US qt (8.0 I)	Approved engine oils
	SLK 55 AMG	8.5 US qt (8.0 I)	
Automatic transmission*	SLK 280, SLK 350	10.4 US qt (9.8 I)	MB Automatic Transmission Fluid
	SLK 55 AMG	10.4 US qt (9.8 I)	
Manual transmission	SLK 280, SLK 350	1.6 US qt (1.5 I)	MB Manual Transmission Oil
Rear axle	SLK 280	1.1 US qt (1.0 l)	Hypoid gear oil SAE 85 W 90
	SLK 350	1.2 US qt (1.1 I)	
	SLK 55 AMG	1.3 US qt (1.2 I)	
Power steering	SLK 280, SLK 350	1.1 US qt (1.0 l)	MB Power Steering Fluid (Pentosin CHF 11S)
	SLK 55 AMG	1.1 US qt (1.0 l)	
Front wheel hubs		approx. 2.1 oz (60 g) each	High temperature roller bearing grease
Brake system		0.5 US qt (0.5 I)	MB Brake Fluid (DOT 4+)

Fuels, coolants, lubricants, etc.

	Model	Capacity	Fuels, coolants, lubricants etc.
Cooling system	SLK 280	approx. 10.4 US qt (9.8 I)	MB 325.0 Anticorrosion/Antifreeze Agent
	SLK 350	approx. 11.2 US qt (10.2 l)	
	SLK 55 AMG	approx. 11.7 US qt (11.1 l)	
Fuel tank including a reserve of	SLK 280, SLK 350 SLK 55 AMG	approx. 18.5 US gal (70.0 l) approx. 2.4 US gal (9.0 l) approx. 18.5 US gal (70.0 l)	Premium unleaded gasoline: Minimum posted Octane 91 (average of 96 RON / 86 MON)
		approx. 2.6 US gal (10.0 l)	
Air conditioning system			R-134a refrigerant and special PAG lubricant oil (never R-12)
Hydraulic system for retractable hardtop		0.19 US qt (0.18 I)	MB Hydraulic Fluid
Windshield washer system and headlamp cleaning system*		7.4 US qt (7.0 I)	MB Windshield washer concentrate ¹

Use MB Windshield Washer Concentrate "S" and water for temperatures above freezing point or MB Windshield Washer Concentrate "S" and commercially available premixed windshield washer solvent/antifreeze for temperatures below freezing point. Follow suggested mixing ratios (> page 456).

Fuels, coolants, lubricants, etc.

Engine oils

Engine oils are specifically tested for their suitability in our engines and durability for our service intervals. Therefore, only use approved engine oils and oil filters required for vehicles with Maintenance System (U.S. vehicles) or FSS PLUS (Canada vehicles). For a listing of approved engine oils and oil filters, refer to the Factory Approved Service Products pamphlet, or contact an authorized Mercedes-Benz Center.

!

Using engine oils and oil filters of specification other than those expressly required for the Maintenance System (U.S. vehicles) or FSS PLUS (Canada vehicles), or changing of oil and oil filter at change intervals longer than those called for by the Maintenance System (U.S. vehicles) or FSS PLUS (Canada vehicles) will result in engine damage not covered by the Mercedes-Benz Limited Warranty.

Please follow Maintenance System (U.S. vehicles) or FSS PLUS (Canada vehicles) recommendations for scheduled oil changes. Failure to do so will result in engine damage not covered by the Mercedes-Benz Limited Warranty.

Engine oil additives

Do not blend oil additives with engine oil. They may damage the engine. Damage or malfunctions resulting from blending oil additives are not covered by the Mercedes-Benz Limited Warranty.

Air conditioning refrigerant

R-134a (HFC) refrigerant and special PAG lubricating oil are used in the air conditioning system. Never use R-12 (CFC) or mineral-based lubricating oil, otherwise damage to the system will occur.

Brake fluid

During vehicle operation, the boiling point of the brake fluid is continuously reduced through the absorption of moisture from the atmosphere.

Warning!



Under extremely strenuous operating conditions, this moisture content can lead to the formation of bubbles in the system, thus reducing the system's efficiency.

Therefore, the brake fluid must be replaced regularly. Refer to your vehicle's Maintenance Booklet for replacement interval.

Only brake fluid approved by Mercedes-Benz is recommended. Your authorized Mercedes-Benz Center will provide you with additional information.

Fuels, coolants, lubricants, etc.

Premium unleaded gasoline

Warning!



Gasoline is highly flammable and poisonous. It burns violently and can cause serious injury. Whenever you are around gasoline, avoid inhaling fumes and skin contact, extinguish all smoking materials. Never allow sparks, flame or smoking materials near gasoline!

!

To maintain the engine's durability and performance, premium unleaded gasoline must be used. If premium unleaded is not available and low octane fuel is used, follow these precautions:

- Have the fuel tank only partially filled with unleaded regular and fill up with premium unleaded as soon as possible.
- Avoid full throttle driving and abrupt acceleration.
- Do not exceed an engine speed of 3000 rpm if the vehicle is loaded with a light load such as two persons and no luggage.
- Do not exceed ²/₃ of maximum accelerator pedal position if the vehicle is fully loaded or operating in mountainous terrain.

Fuel requirements

Only use premium unleaded fuel:

 The octane number (posted at the pump) must be 91 min. It is an average of both the Research (R) octane number and the Motor (M) octane number: (R+M) / 2). This is also known as the ANTI-KNOCK INDEX.

Unleaded gasoline containing oxygenates such as ethanol, IPA, IBA, and TBA can be used provided the ratio of any one of these oxygenates to gasoline does not exceed 10%; MTBE not to exceed 15%.

The ratio of methanol to gasoline must not exceed 3% plus additional cosolvents.

Using mixtures of ethanol and methanol is not allowed. Gasohol, which contains 10% ethanol and 90% unleaded gasoline, can be used.

These blends must also meet all other fuel requirements, such as resistance to spark knock, boiling range, vapor pressure, etc.

Fuels, coolants, lubricants, etc.

Gasoline additives

A major concern among engine manufacturers is carbon build-up caused by gasoline. Mercedes-Benz only recommends the use of quality gasoline containing additives that prevent the build-up of carbon deposits.

After an extended period of using fuels without such additives, carbon deposits can build up especially on the intake valves and in the combustion area, leading to engine performance problems such as:

- Warm-up hesitation
- Unstable idle
- Knocking/pinging
- Misfire
- Power loss

In areas where carbon deposits may be encountered due to lack of availability of gasolines which contain these additives, Mercedes-Benz recommends the use of additives approved by us for use on Mercedes-Benz vehicles. Refer to the Factory Approved Service Products pamphlet for a listing of approved product(s). Follow directions on product label.

Do not blend other fuel additives with fuel. This only results in unnecessary costs and may be harmful to engine operation.

Damage or malfunction resulting from poor fuel quality or from blending additional fuel additives other than those tested and approved by us for use on Mercedes-Benz vehicles listed in the Factory Approved Service Products pamphlet are not covered by the Mercedes-Benz Limited Warranty.

Coolants

The engine coolant is a mixture of water and anticorrosion/antifreeze, which provides:

- Corrosion protection
- Freeze protection
- Boiling protection (by increasing the boiling point)

The cooling system was filled at the factory with a coolant providing freeze protection to approximately -22°F (-30°C) and corrosion protection.

If the antifreeze mixture is effective to -22°F (-30°C), the boiling point of the coolant in the pressurized cooling system is reached at approximately 266°F (130°C).

The coolant solution must be used year round to provide the necessary corrosion protection and increase boil-over protection. Refer to Maintenance Booklet for information on replacement intervals.

Fuels, coolants, lubricants, etc.

Coolant system design and coolant used determine the replacement interval. The replacement interval published in the Maintenance Booklet is only applicable if MB 325.0 anticorrosion/antifreeze solution or other Mercedes-Benz approved products of equal specification (see Factory Approved Service Products pamphlet) are used to renew the coolant concentration or bring it back up to the proper level.

To provide important corrosion protection, the solution must be at least 45% anticorrosion/antifreeze (equivalent to freeze protection to approx. -22°F [-30°C]). If you use a solution that is more than 55% anticorrosion/antifreeze (freeze protection to approx. -49°F [-45°C]), the engine temperature will increase due to the lower heat transfer capability of the solution. Therefore, do not use more than this amount of anticorrosion/antifreeze.

If the coolant level is low, water and MB Anticorrosion/Antifreeze should be used to bring it up to the proper level (have cooling system checked for signs of leakage). Please make sure the mixture is in accordance with label instructions.

The water in the cooling system must meet minimum requirements, which are usually satisfied by normal drinking water. If you are not sure about the water quality, consult an authorized Mercedes-Benz Center.

Anticorrosion/antifreeze

Your vehicle contains a number of aluminum parts. The use of aluminum components in motor vehicle engines necessitates that anticorrosion/antifreeze coolant used in such engines be specifically formulated to protect the aluminum parts. (Failure to use such anticorrosion/antifreeze coolant will result in a significantly shortened service life.)

Therefore, the following product is strongly recommended for use in your vehicle: Mercedes-Benz 325.0 anticorrosion/antifreeze agent.

Before the start of the winter season (or once a year in hot southern regions), you should have the anticorrosion/antifreeze concentration checked. The coolant is also regularly checked each time you bring your vehicle to an authorized Mercedes-Benz Center for service.

Fuels, coolants, lubricants, etc.

Anticorrosion/antifreeze quantity

Model	Approx. freeze protection	
	-35°F (-37°C)	-49°F (-45°C)
SLK 280, SLK 350	5.4 US qt (5.1 I)	6.0 US qt (5.6 I)
SLK 55 AMG	5.9 US qt (5.5 I)	6.4 US qt (6.1 I)

Fuels, coolants, lubricants, etc.

Windshield washer system and headlamp cleaning system*

Both the windshield washer system and the headlamp cleaning system* are supplied from the windshield washer fluid reservoir.

The washer fluid reservoir has a capacity of approximately 7.4 US qt (7.0 l).

Refill the reservoir with MB Windshield Washer Concentrate "S" and water (or concentrate and commercially available premixed windshield washer solvent/antifreeze, depending on ambient temperatures).

Warning!



Washer solvent/antifreeze is highly flammable. Do not spill washer solvent/antifreeze on hot engine parts because it may ignite and burn. You could be seriously burned.

Windshield washer and headlamp cleaning* fluid mixing ratio

For temperatures above freezing point, use MB Windshield Washer Concentrate "S" and water:

1 part "S" to 100 parts water [40 ml (1.34 fl oz) "S" to 1 gallon (4 l) water]

For temperatures below freezing point, use MB Windshield Washer Concentrate "S" and commercially available premixed windshield washer solvent/antifreeze:

1 part "S" to 100 parts solvent
 [40 ml (1.34 fl oz) "S" to 1 gallon (4 l) solvent].

ABS

(Antilock Brake System)

Prevents the wheels from locking up during braking so that the vehicle can continue to be steered.

Accessory weight

(⊳ page 344)

Air pressure

(⊳ page 344)

AIRSCARF neck-level heating*

AIRSCARF neck-level heating provides the surrounding area of the occupants' necks with a heated air stream flowing from openings in the head restraints.

Alignment bolt

Metal pin with thread. The centering pin is an aid used when changing a tire to align the wheel with the wheel hub.

Aspect ratio

(⊳ page 344)

BabySmart[™] air bag deactivation system

This system detects if a special system-compatible child restraint seat is installed on the passenger seat. The system will automatically deactivate the passenger front air bag when such a seat is properly installed (the system will indicator lamp located in the center console comes on and remains illuminated).

BabySmart[™] compatible child seats

Special restraint system for children. The sensor system for the passenger seat prevents deployment of the passenger front air bag if a BabySmart™ compatible child seat is installed. See an authorized Mercedes-Benz Center for availability.

Bar

(⊳ page 344)

BAS

(Brake Assist System)
System for potentially reducing braking distances in emergency braking situations. The system is activated when it senses an emergency based on how fast the brake is applied.

Bead

(⊳ page 344)

Bi-Xenon headlamps*

Headlamps which use an electric arc as the light source and produce a more intense light than filament headlamps. Bi-Xenon headlamps produce low beam and high beam.

CAC

(<u>Customer Assistance Center</u>) Mercedes-Benz customer service center, which can help you with any questions about your vehicle and provide assistance in the event of a breakdown.

CAN system

(Controller Area Network)
Data bus network serving to control vehicle functions such as door locking or windshield wiping.

Cockpit

All instruments, switches, buttons and indicator/warning lamps in the passenger compartment needed for vehicle operation and monitoring.

Cold tire inflation pressure

(⊳ page 344)

Collapsible tire

An especially compact spare tire that must be inflated with a provided air pump before using. It should only be used to bring the vehicle to the nearest service station.

COMAND*

(<u>Co</u>ckpit <u>Man</u>agement and <u>D</u>ata System)

vehicle sound and communications systems, including the radio, CD changer and navigation system, as well as other optional equipment (e.g. telephone).

Information and operating center for

Control system

The control system is used to call up vehicle information and to change component settings. Information and messages appear in the multifunction display. The driver uses the buttons on the multifunction steering wheel to navigate through the system and to adjust settings.

Cruise control

Driving convenience system for automatically maintaining the vehicle speed set by the driver.

Curb weight

(⊳ page 344)

DOT

(<u>D</u>epartment <u>of</u> <u>T</u>ransportation) (▷ page 344)

Engine number

The number set by the manufacturer and placed on the cylinder block to uniquely identify each engine produced.

Engine oil viscosity

Measurement for the inner friction (viscosity) of the oil at different temperatures. The higher the temperature an oil can tolerate without becoming thin, or the lower the temperature it can tolerate without becoming viscous, the better the viscosity.

ESP®

(Electronic Stability Program) Improves vehicle handling and directional stability.

ETD

(Emergency Tensioning Device)
Device which deploys in certain frontal and rear collisions exceeding the system's threshold to tighten the seat belts. ->SRS

FSS PLUS (Canada vehicles)

(Flexible Service System PLUS) Maintenance service indicator in the multifunction display that informs the driver when the next vehicle maintenance service is due. FSS PLUS evaluates engine temperature, oil level, vehicle speed, engine speed, distance driven and the time elapsed since your last maintenance service, and calls for the next maintenance service accordingly.

GAWR

(Gross Axle Weight Rating) (▷ page 344)

Gear range*

Number of gears which are available to the automatic transmission for shifting. The automatic gear shifting process can be adapted to specific operating conditions using the selector lever.

GPS

(Global Positioning System)
Satellite-based system for relaying geographic location information to and from vehicles equipped with special receivers.

GVW

(Gross Vehicle Weight) (▷ page 344)

GVWR

(Gross Vehicle Weight Rating) (▷ page 345)

Head-thorax air bag

Installed in the doors, these air bags protect occupants during side impact collisions exceeding a preset threshold. Unlike normal side air bags, head-thorax air bags are also designed to provide protection for the head area.

Instrument cluster

The displays and indicator/warning lamps in the driver's field of vision, including the tachometer, speedometer, coolant temperature and fuel gauge.

Kickdown*

Depressing the accelerator past the point of resistance shifts the automatic transmission down to the lowest possible gear. This very quickly accelerates the vehicle and should not be used for normal acceleration needs.

Kilopascal (kPa)

(⊳ page 345)

Line of fall

The direct line an object moves downhill when influenced by the force of gravity alone.

Locking knob

Button on the door which indicates whether the door is locked or unlocked. Pushing the locking knob down on an individual door from inside locks that door.

Maintenance System (U.S. vehicles)

Maintenance service indicator in the multifunction display that informs the driver when the next vehicle maintenance service is due. The Maintenance System in your vehicle tracks distance driven and the time elapsed since your last maintenance service, and calls for the next maintenance service accordingly.

Maximum loaded vehicle weight

(⊳ page 345)

Maximum load rating

(⊳ page 345)

Maximum tire inflation pressure

(⊳ page 345)

Memory function*

Used to store three individual seat, steering wheel and mirror positions.

MON

(Motor Octane Number)

The Motor Octane Number for gasoline as determined by a standardized method. It is an indication of a gasoline's ability to resist undesired detonation (knocking). The average of both the MON (Motor Octane Number) and ->RON (Research Octane Number) is posted at the pump, also known as ANTI-KNOCK INDEX.

Multifunction display

Two display fields in the instrument cluster used to present information provided by the control system.

Multifunction steering wheel

Steering wheel with buttons for operating the control system.

Normal occupant weight

(⊳ page 345)

Overspeed range

Engine speeds within the red marking of the tachometer dial. Avoid this engine speed range, as it may result in serious engine damage that is not covered by the Mercedes-Benz Limited Warranty.

Poly-V-belt drive

Drives engine components (alternator, AC compressor, etc.) from the engine.

Power train

Collective term designating all components used to generate and transmit motive power to the drive axles, including

- Engine
- Clutch/torque converter
- Transmission
- Transfer case
- Drive shaft
- Differential
- · Axle shafts/axles

Production options weight

(⊳ page 345)

Program mode selector switch*

Used to switch the automatic transmission between standard operation (S) and comfort operation (C).

Vehicles with steering wheel gearshift control and manual shift program: in addition to **S** and **C** (for regular **S** or comfort **C** operation, see above), you can use **M** for manual shift program.

PSI

(Pounds per square inch) (▷ page 345)

Recommended tire inflation pressure

(⊳ page 345)

REST

(Residual engine heat utilization)
Feature that uses the engine heat
stored in the coolant to heat the vehicle interior for a short time after the engine has been turned off.

Restraint systems

Seat belts, belt tensioners, air bags and child restraint systems. As independent systems, their protective functions complement one another.

Rim

(⊳ page 345)

Retractable hardtop

Hardtop that can be opened and closed at the push of a button and stored in the trunk.

Roll bar

Occupant protection system which consists of tubular steel sheathed in plastic.

RON

(Research Octane Number)

The Research Octane Number for gasoline as determined by a standardized method. It is an indication of a gasoline's ability to resist undesired detonation (knocking). The average of both the ->MON (Motor Octane Number) and RON (Research Octane Number) is posted at the pump, also known as ANTI-KNOCK INDEX.

Shift lock*

When the vehicle with automatic transmission is parked, this lock prevents the gear selector lever from being inadvertently moved out of position **P** without the SmartKey turned and the brake pedal depressed.

Sidewall

(⊳ page 345)

SRS

(Supplemental Restraint System) Seat belts, emergency tensioning device and air bags. Though independent systems, they are closely interfaced to provide effective occupant protection.

Tele Aid system

($\underline{\text{Tele}}$ matic $\underline{\text{A}}$ larm $\underline{\text{Identification on }}$ $\underline{\text{D}}$ emand)

The Tele Aid system consists of three types of response: automatic and manual emergency, Roadside Assistance and information. Tele Aid is initially activated by completing a subscriber agreement and placing an acquaintance call.

The Tele Aid system is operational provided that the vehicle's battery is charged, properly connected, not damaged and cellular and GPS coverage is available.

Tightening torque

Force times lever arm (e.g. a lug wrench) with which threaded fasteners such as wheel bolts are tightened.

TIN

(<u>Tire Identification Number</u>) (⊳ page 346)

Tire load rating

(⊳ page 346)

Tire ply composition and material used

(⊳ page 346)

Tire speed rating

(⊳ page 346)

Traction

(⊳ page 346)

Tread

(⊳ page 346)

Treadwear indicators

(⊳ page 346)

Uniform Tire Quality Grading Standards

(⊳ page 346)

Vehicle capacity weight

(⊳ page 346)

Vehicle maximum load on the tire

(⊳ page 346)

VIN

(Vehicle Identification Number)
The number set by the manufacturer and placed on the body to uniquely identify each vehicle produced.

Wind screen

Screen for deflecting wind from the vehicle interior when the hardtop is lowered.

Α	Anticorrosion/antifreeze 454	Automatic locking
ABS 82, 457	Antilock brake system see ABS	Control system 147
Display message 370	Anti-theft systems 87	When driving 101
Indicator lamp 362	Alarm system 87	Automatic shift program* 163
Accessory weight 344	Immobilizer 87	Automatic transmission* 157
Accident 58	Tow-away alarm 88	Automatic transmission fluid
Adjusting (Getting started) 38	Ashtray 269	(ATF) 313
Air bags 65	Aspect ratio 344	Driving 53
BabySmart™ 77, 457	AUDIO menu (Control system) 129	Emergency operation
Children 66	Audio system 203	(Limp Home Mode) 172
Front 70	Audio and telephone*, operation 203	Fluid level 313
Head-thorax 71, 459	CD changer* 223	Gear ranges 160
Kneebag 70	CD operation 219	Gear selector lever 157
Passenger front air bag off indicator	Introduction to satellite radio*	Gear selector lever (Unlocking
lamp 78	(USA only) 214	manually) 396
Safety guidelines 68	MP3 220	Gear shifting malfunctions 172
Air conditioning	Operating and display elements 204	Gearshift pattern 51
Automatic climate control* 200	Auto-dimming* for rear view mirrors 174	Kickdown 162
Climate control 187	Automatic climate control*	Manual shifting 164
Air conditioning refrigerant 451	Air conditioning 200	One-touch gearshifting 164
Air pressure see Tire inflation pressure	Automatic mode, basic setting 194	Program mode selector switch 163
AIRSCARF neck level heating*	Control panel 192	
(Seats) 105, 457	Deactivating 194	
Alarm system see Anti-theft systems	Overview 190	
Alignment bolt (Vehicle tool kit) 388,		

415, 457

В	С	Cigarette lighter 270
BabySmart™	CAC 457	Cleaning tires 319
Air bag deactivation system 457	California, important notice 11	Climate control 178
Compatible child seats 76, 457	CAN system 458	Air conditioning 187
Passenger front air bag off indicator	Capacities (Fuels, coolants, lubricants,	Air recirculation mode 185
lamp 77	etc.) 449	Control panel, overview 179
Back-up lamp 401	Cargo compartment cover 253	Switching on/off 181
Bar 344	Carpets, cleaning 359	Clock 122
BAS 83, 457	Catalytic converter 302	Cockpit 458
Battery (SmartKey)	CD	Overview 22
Replacing 398	Changer* 219, 266	Cold tire inflation pressure 344
Battery (Vehicle) 314, 421	Player/Changer*, operation 131,	Collapsible tire 458
Jump starting 424	219	Collapsible wheel chock 390
Bead 344	CD changer* (Audio system) 223	COMAND* 122, 458
Bi-Xenon* 457	Center console 28	Navigation 132
Headlamps 401	Lamp 367	Radio transmitter 301
Brake Assist System see BAS	Central locking	Combination switch 114
Brakes 294	Automatic 101, 147	High beam flasher 114
Brake fluid 306, 451	From outside (SmartKey) 62	High beam headlamps 55, 114
Display message 375	Locking/unlocking from inside 102	Low beam headlamps 55
SLK 55 AMG 295	Certification label 436	Turn signals 55
Warning lamp 363	CHECK ENGINE indicator lamp 364	Windshield wipers 56
Break-in period 292	Child safety	Comfort driving
Bulbs	Air bags 66	Transmission program mode* 163
Front/rear lamps 401	Children in the vehicle 75	Compatible child seat see BabySmart™
Replacing 400, 401		

Control system 123, 458	Convenience closing*	D
AUDIO menu 129	Power windows 249	Date (Control system) 141, 142
Convenience* submenu 147	Retractable hardtop 257	Daytime running lamp mode 112
Coolant temperature 128	Coolant 313	Control system 143
Instrument cluster submenu 137	Adding water 306	Deep water see Standing water
Lighting submenu 143	Anticorrosion/antifreeze 454	Defrosting
Maintenance service indicator 350	Fuels, coolants, lubricants, etc. 453	Rear window 177
Menus 124	Technical data 449	Windshield (Automatic climate
Messages in display 368	Temperature 303	control*) 197
Multifunction display 123	Temperature, checking (Control	Windshield (Climate control) 184
Multifunction steering wheel 124	system) 128	Department of Transportation see DOT
NAV* menu 132	Corner-illuminating front fog lamps*	Difficulties with starting 52
Overview (Menus) 126	(Lighting) 115	Direction of rotation (Tires) 320
Overview (Settings submenus) 136	Cruise control 260, 458	Display text see Messages in display
Resetting 134	Display message 370	Doors
Settings menu 134	Cup holder 268	Control panel, overview 31
Standard display 128	Curb weight 344	Entry lamps 119
TEL* menu 151	Customer Assistance Center see CAC	Locking/unlocking from outside 95
Time/date submenu 139		Opening from inside 97
Trip computer menu 149		Unlocking with Tele Aid 280
Vehicle status message memory		DOT 344
menu 132		Drink holder see Cup holder
Vehicle submenu 147		Drinking and driving 293
Controller Area Network see CAN system		Driver's air bag see Air bags

Index

Driver's door	E	Engine oil 308, 451
Locking in an emergency 395	Easy-entry/exit feature* 43, 148	Adding 312
Unlocking in an emergency 394	Electric air pump 391	Additives 451
Driving 53	Electric air pump (Vehicle tool kit) 388	Checking level (Control system) 309
Automatic transmission* 53	Electrical system (Technical data) 446	Checking level (Dipstick) 311
Driving off 296	Electronic Stability Program see ESP®	Consumption 308
Fuel saving 293	Emergency call (911) 243	Display message 310
Hydroplaning 297	Emergency call system 273	Viscosity 458
In winter 299	Tele Aid 275	ESP [®] 84, 458
Instructions 47, 293	Emergency operations	Display message 371
Manual transmission 53	Automatic transmission* 172	Warning lamp 365
Standing water 300	Releasing trunk lid from inside 100	ETD 73, 74, 459
Tires 297	Remote door unlock (Tele Aid) 280	Safety guidelines 68
Traveling abroad 301	Retractable hardtop 397	Seat belt force limiter 74
Driving safety systems 82	Selector lever*, unlocking	Exterior lamp switch 110
ABS 82	manually 396	Exterior lighting
BAS 83	Unlocking/locking the vehicle 394	Lamps 401
ESP® 84	Emergency tensioning device see ETD	Replacing bulbs 401
	Emission control 302, 436	Exterior rear view mirrors see Mirrors
	Engine	
	Cleaning see Vehicle care	
	Compartment 307	
	Driving after replacement 292	
	Number 436, 458	
	Technical data 438	
	Turning off 61	

F	Refueling 304	G
First aid kit 388	Reserve warning lamp 365, 366	Garage door opener* 281
Flat tire 408	RON 304	Gasoline see Fuel
Inflating collapsible spare tire 417	Technical data 449	GAWR 344
Lifting vehicle 413	Fuel filler flap	Gear range (Automatic
Lowering vehicle 419	Localization 25	transmission*) 160, 459
Mounting spare wheel 412, 415	Fuel gauge (Instrument cluster) 25	Limiting 160
TIREFIT kit* 408	Fuse extractor (Vehicle tool kit) 388	Shifting into optimal 164
Floormat (Driver's side only) 271	Fuses 430	Gear selector lever (Automatic
Fog lamps 113, 401	Auxiliary fuse box 432	transmission*) 157
Corner-illuminating front fog	Main fuse box 431	Position 157, 159
lamps* 115	Spare fuses (Vehicle tool kit) 388	Global locking/unlocking see SmartKey
Footwell lighting* 118		Global Positioning System see GPS
FSS PLUS (Canada vehicles) 459		Glove box 266
Control system 350		Good visibility 173
Fuel		GPS 87, 88, 459
Additives 453		Tele Aid system 273
Consumption statistics (Control		Gross Axle Weight Rating see GAWR
system) 149		Gross Vehicle Weight Rating see GVWR
Filler flap 304		Gross Vehicle Weight see GVW
Fuel tank capacity 450		GSM network phones (Telephone*) 229
MON 304		GVW 344
Premium unleaded gasoline 304,		GVWR 345
452		

H Hard plastic trim items, cleaning 359 Hazard warning flasher 117 Head restraint height (Seats) 41 Headlamps Bi-Xenon* 401, 457 Cleaning system* 173, 315, 456 Night security illumination (Control system) 145 Switching off 60 Switching on 55 Headliner, cleaning 360 Head-thorax air bag 71, 459 Heating	I Identification labels see Labels Ignition (Position in starter switch) 36 Immobilizer see Anti-theft systems Infant and child restraint systems 75 Instrument cluster 25, 120, 459 Clock 122 Lamps, indicator and warning 362 Overview 24 Instruments and controls see Cockpit Interior rear view mirror see Mirrors Intermittent/interval wiping see Windshield wipers	K Key 209 Kickdown (Automatic transmission*) 162, 459 Kilopascal 345 Kneebag see Air bags
Seats* 104 Steering wheel* 288 High beam Flasher 115 Headlamps 55, 115 Headlamps, bulbs 401	Jack (Vehicle tool kit) 388 Lifting vehicle 413 Lowering vehicle 419 Jump starting 424	
High mounted brake lamp 401 High-performance brake system (SLK 55 AMG) 295 Hood 307 Horn 23		

Hydroplaning 297

Lighting 110		Limp Home Mode (Automatic
Labels 436	Combination switch 114	transmission*) 172
Lamp in center console 367	Corner-illuminating front fog	Line of fall 460
Lamps in instrument cluster 362	lamps* 115	Loading 265, 320, 344
Lamps, indicator and warning	Daytime running lamp mode 112	Loading the vehicle 320
ABS 362	Door entry lamps 119	Locator lighting (Control system) 144
Battery (SmartKey) 95	Exterior lamp switch 110	Locking
Brakes 363	Exterior lamps, cleaning 357	And parking 59
CHECK ENGINE 364	Fog lamps 113	Centrally (Control system) 147
ESP [®] 84, 86, 365	Footwell lighting* 118	Centrally from inside 102
Fuel reserve 365, 366	Hazard warning flasher 117	Locking knob (Doors) 97, 460
Passenger front air bag off 367	Headlamp mode,	Locking the vehicle 62
Seat belts 366	automatic/manual 111	Long trip, checking before 305
SRS 64, 65, 366	High beam 115	Loss of
Language in multifunction display (Control	High beam flasher 115	Service and Warranty Booklet 435
system) 137	Individual settings (Control	SmartKey or mechanical key 97
Layout of poly-V-belt drive 437	system) 143	Low beam headlamps 110, 401
License plate lamps 401	Instrument cluster illumination 120	Lubricants, technical data 449
Light alloy wheels	Interior lighting 117	
Cleaning 358	Low beam headlamps 110	
Technical data 441, 442	Night security illumination (Control	
Lighter see Cigarette lighter	system) 145	
	Reading lamps 119	
	Standing lamps 110	
	Trunk 118	

М	Settings 134	MOExtended system* 333
Main dimensions 447	Settings submenus 135	MON 304, 460
Maintenance service indicator (Control system) 350	Standard display 128 TEL* 151	Motor Octane Number see MON MP3 220
Maintenance System (U.S. vehicles) 460 Service indicator, calling up 351	Time/Date submenu 139 Trip computer 149	Multifunction display 123, 460 Engine oil messages 309
Manual seat see Seats	Vehicle status message memory 132	Messages 132
Manual shift program SLK 55 AMG 169	Vehicle submenu 147	Messages with symbols 374
Manual transmission 155	Messages in display 368	Messages with text 368
Driving 53	Cruise control 370	Operation see Control system
Gearshift pattern 51	ESP [®] 371	Multifunction steering wheel 26, 124,
Starting with SmartKey 51	Maintenance service indicator 350	460
Maximum inflation pressure 345	SRS 372	Heating* 288
Maximum load rating 345	Symbols 374	
Maximum loaded vehicle weight 345	Transmission 372	
Mechanical key see SmartKey	Vehicle status message memory 132	
Memory function* 107, 460	Mirror lamp* see Sun visors	
Menus	Mirrors 173	
AUDIO 129	Additional turn signals 401	
Convenience* submenu 147	Adjusting 45	
Instrument cluster submenu 137	Antiglare position 173	
Lighting submenu 143	Auto-dimming* 174	
NAV* 132	Exterior rear view mirrors 45	
Overview (Control system) 126, 127,	Interior rear view mirror 45	
136	Parking position* 108, 148, 175	

N	P	Power washer see Vehicle care
NAV* menu 132	Paintwork see Vehicle care	Power windows 246
Navigation system see NAV*	Panic alarm 80	Operating rear side windows 248
Neck-level heating see AIRSCARF* (Seats)	Parcel net (Storage compartment) 267	Operating with retractable hardtop
Night security illumination (Control	Parking 296	switch 248
system) 145	And locking 59	Summer opening/convenience
Normal occupant weight 345	Parking aid see Parking position*	closing* 249
0	Parking brake 52, 59	Synchronizing 251
_	Parking lamps 110, 401	Practical hints
Occupant distribution 345	Parking position* 108	Fuses 430
Occupant safety 64 Children 66, 75	Activation (Control system) 148	Lamps in instrument cluster 362
•	Exterior rear view mirrors 175	Spare wheel bolts 392
Infant and child restraint systems 72, 75	Parts service 434	Towing vehicle 426
· ·	Passenger air bag see Air bags	Vehicle jack 389
Seat belts 47, 68, 71 Oil see Engine oil	Passenger compartment 301	What to do if 362
One-touch gearshifting* 164	Passenger front air bag off indicator	Premium unleaded gasoline 452
Operating safety 16, 203	lamp 367	Problems
Operating salety 16, 203 Operating vehicle outside the USA and	Passenger safety see Occupant safety	While driving 58
Canada 13	Phone book see Telephone*	With vehicle 17
Operator's Manual 10	Plastic parts, cleaning 359	Product information 9
Ornamental moldings see Vehicle care	Poly-V-belt drive 437, 460	Production options weight 345
Outside temperature indicator 121, 129	Potential problems associated with under-	Program mode selector switch* 461
Outside temperature/speed 138	inflated and overinflated tires 332	Automatic transmission* 163
Overhead control panel 30	Power outlet 271	PSI 345
Overspeed range 121, 460	Power seat* see Seats	
Overspeed range 121, 400	Dower train 141	

Power train 461

R	REST 461	S
Radio	Automatic climate control* 202	Safety belts see Seat belts
Operation (Audio system) 209	Climate control 188	Safety defects, reporting 18
Operation (Control system) 129	Restraint systems 461	Safety, occupant 64
Satellite* (USA only) 130	Retractable hardtop 252, 461	Satellite radio* (USA only) 130, 214
Radio transmitters, control and	Locking after raising/lowering 255	Seat belts 71
operation 301	Opening and closing 252	Cleaning 360
Reading lamps 119	Operating manually 397	Fastening 47
Rear view mirrors see Mirrors	Problems when operating 255	Force limiter 74
Rear window defroster 177	Summer opening/convenience	Proper use of 49, 73
Recommended inflation pressure 345	closing* 257	Release button 49
Recovery services for stolen vehicle	Wind screen 259	Safety guidelines 68
(Tele Aid) 280	Rims 345, 439	Warning lamp 366
Refrigerant (Air conditioning) 451	Roadside Assistance 12, 277	Seating capacity 322
Refueling 304	Roll bar 462	Seats 104
Regular checks 305	RON 304, 462	Adjusting 38
Remote control see SmartKey	Roof rack 265	Easy-entry/exit feature* 43
Remote door unlock with Tele Aid 280	Rubber parts, cleaning 359	Head restraint height 41
Reporting, safety defects 18	Run Flat Indicator* 329	Heating* 104
Research Octane Number see RON		Power seats* 40
Reset button (Instrument cluster) 25		Selective setting see SmartKey
Residual engine heat utilization see REST		Selector lever* lock 51, 462

Service	Loss of SmartKey or mechanical	Standard display menu (Control
Information 12	key 97	system) 128
Maintenance Booklet 12	Mechanical key 394	Standing lamps 110, 401
Service and warranty	Panic button 80	Standing water, driving instructions 300
Booklet 435	Positions in starter switch 36	Starter switch positions 36
Information 10	Power windows,	Starting 36, 50
Service life (Tires) 318	opening/closing* 249	Difficulties with 52
Service system	Remote control 92	Position in starter switch 36
Maintenance service indicator 350	Replacing batteries 398	Steering column see Steering wheel
Parts service 434	Restoring to factory setting 96	Steering wheel
Settings menu (Control system) 134	Retractable hardtop,	Adjusting 42
Shelf behind roll bar 268	opening/closing* 257	Heating* 288
Shelf below rear window, cleaning 360	Selective setting 95	Steering wheel gearshift control
Shift lock* 462	Starting engine 50	SLK 280* 165
Side marker lamps 401	Turning off engine 61	SLK 350* 165
Side windows see Power windows	Unlocking the trunk lid 96	SLK 55 AMG 167
Sidewall 345	Snow chains 349	Stolen vehicle, Recovery services
SmartKey 92	Spare fuses (Vehicle tool kit) 388	(Tele Aid) 280
Checking batteries 97	Spare parts see Parts service	Storage compartments 266
Factory setting 94	Spare wheel 391	Storing tires 319
Global locking 95	SRS 73, 462	Summer opening*
Global unlocking 94	Display message 372	Power windows 249
Locking and unlocking 92	Indicator lamp 366	Retractable hardtop 257
		Sun visors 176
		Supplemental Restraint System see SRS
		Symbols in display 374

Г	Tele Aid system 273, 462	Tire inflation pressure 410
Tachometer 121	Call priority 279	Air pressure 344
Tail lamps 401	Initiating an emergency call 276	Checking 327, 329
Tar stains see Vehicle care	Remote door unlock 280	Tire inflation pressure see the placard on
TDMA or CDMA network phones	Requirements 273	the fuel filler flap
(Telephone*) 236	Roadside Assistance 277	Tire inspection 318
Technical data	Stolen Vehicle Recovery	Tire load rating 346
Air conditioning refrigerant 451	services 280	Tire ply composition and material
Brake fluid 451	System self-check 274	used 346
Coolants 453	Telephone* 272	Tire speed rating 336, 346
Electrical system 446	Compartment 266	Tire terminology 344
Engine 438	GSM network phones 229	TIREFIT kit* (Vehicle tool kit) 388, 389
Engine oil 451	Operation 151, 203	TIREFIT*
Fuel additives 453	Tightening torque 462	Instructions for use 408
Fuel requirements 452	Wheel bolts 419	Tires 317, 439
Fuels, coolants, lubricants, etc. 449	Time and date synchronization with head	Cleaning 319
Headlamp cleaning system* 456	unit* (Control system) 139	Collapsible (Spare wheel) 458
Main dimensions 447	TIN 346	Direction of rotation 320
Parts service 434	Tire and Loading Information 321	Driving instructions 297
Premium unleaded gasoline 452	Tire and loading terminology 344	Flat tire 408
Rims and tires 439	Tire care and maintenance 318	Important guidelines 317
Weights 448	Tire Identification Number see TIN	Inflating with air pump 417
Windshield washer system 456		MO <i>Extended</i> system* 333
		Mounting wheel 415

U Removing wheel 415 Transmission, display message 372 Retreads 317 **Uniform Tire Quality Grading** Transporting the vehicle 89 Rims and tires 439 Traveling abroad 301 Standards 346 Rotating 347 Tread 346 Unlocking 34 Run Flat Indicator* 329 Tread depth 319, 348 Centrally from inside 102 Service life 318 Treadwear indicators 297, 346 In an emergency 280 Sizes 439 Trip computer menu (Control With SmartKey 34 Snow chains 349 system) 149 Upholstery Spare wheel 391 Trunk 98 Cleaning 360 Speed rating 298 Cargo compartment cover 253 Useful features Storing 319 Lighting 118 Ashtray 269 Supplemental tire inflation pressure Trunk lid emergency release 100 Cigarette lighter 270 Trunk lid lock 395 information 304 Cup holder 268 Temperature 343 Unlocking with SmartKey 96 Floormat (Driver's side only) 271 Traction 298 Turn signals 55, 401 Garage door opener* 281 Additional in mirrors 401 Tread depth 319, 348 Heated steering wheel* 288 Parcel net 267 Treadwear indicators (TWI) 297 TWI see Treadwear indicators Wear pattern 347 Power outlet 271 Wheel chock (Vehicle tool kit) Storage compartments, interior 266 Winter 348 Tele Aid 273 Tools see Vehicle tool kit Telephone* 272 Tow-away alarm see Anti-theft systems Towing (Vehicle) 426 Traction 163, 346

V	W	Windshield
Valve extractor (Vehicle tool kit) 388	Warning sounds	Washer fluid reservoir 315
Vehicle	Anti-theft alarm system 87	Washer system 456
Battery 314, 421	Driver's seat belt 71	Windshield wipers 56
Bulbs 401	Exterior lighting 61, 111	Replacing wiper blades 406
Fuses 430	Maintenance service indicator 351	Wiper blades, cleaning 357
Individual settings (Control	Panic alarm 80	Winter driving 348
system) 134	Parking brake 53, 363	Instructions 299
Jump starting 424	Tow-away alarm 88	Snow chains 349
Lifting with jack 413	Warranty coverage 435	Tires 348
Locking 62	Washing the vehicle see Vehicle care	Winter tires see Tires
Proper use of 16	Wear pattern (Tires) 347	Wood trims, cleaning 360
Towing 426	Weights 448	
Unlocking/locking in an	Wheel bolts 392	
emergency 394	Wheel chock (Vehicle tool kit) 388	
Vehicle capacity weight 346	Wheel wrench (Vehicle tool kit) 388	
Vehicle care 353	Wheels see Tires	
Vehicle Identification Number see VIN	Wheels, tightening torque 419	
Vehicle jack 389	Where will I find? 388	
Vehicle loading terminology 344	Wind screen 259, 463	
Vehicle status message memory menu	Windows see Power windows	
(Control system) 132		
Vehicle tool kit 388		

VIN 436, 463

Collapsible wheel chock 390 Vehicle washing see Vehicle care

Service and Literature

Your authorized Mercedes-Benz Center has trained technicians and original Mercedes-Benz parts to service your vehicle properly. For expert advice and quality service, see an authorized Mercedes-Benz Center.

If you are interested in obtaining service literature for your vehicle, please contact an authorized Mercedes-Benz Center. We consider this the best way for you to obtain accurate information for your vehicle.

For further information you can find us on the Mercedes-Benz web-site www.mbusa.com or www.mercedes-benz.ca.

Warning!



To help avoid personal injury, be extremely careful when performing any service work or repairs. Improper or incomplete service or the use of incorrect or inappropriate parts or materials may damage the vehicle or its equipment, which may in turn result in personal injury.

If you have questions about carrying out any type of service, turn to the advice of an authorized Mercedes-Benz Center.

We reserve the right to modify the technical details of the vehicle as given in the data and illustrations of this Operator's Manual.

Reprinting, translation and copying, even of excerpts, is not permitted without our prior authorization in writing.

Title illustration no. P00.01-2930-31

Press time April 8, 2005 GSP/TIP Printed in Germany